

Remote control instructions

1. Long press the remote button to power on, LED indicator will blink.
2. Search and pair with bluetooth name on your cellphone, LED indicator will stop flashing after successfully connected. Use the remote control to capture pictures, LED flash once at a time.
3. The remote control will automatically shut down in 5 mins if not paired.
4. The remote control will automatically sleep in 10 mins without any operation. and auto shut down after another 10 mins if not awoken.
5. Long press the remote button to power off, LED indicator flashes 3 times then shut down.

Product parameters

mount holder	2.9-4.5"
Extended length	690-1700 mm

Reminder:

The Wireless selfie stick tripod uses remote control to take photos instead of clicking on your cellphone camera app. compatible with Android and iOS smart phones.(For Android phones only:set your volume Key function as capture in camera app setting for the selfie stick to work properly)

If you are not clear about the specific steps, please read another detailed operation or mail details page

FCC Warning:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

The device has been evaluated to meet general RF exposure requirement.

Anleitung zur Fernbedienung

1. Drücken Sie zum Einschalten lange auf die Fernbedienungstaste. Die LED-Anzeige blinkt.
2. Suchen und koppeln Sie den wireless-Namen auf Ihrem Mobiltelefon
Nach erfolgreicher Verbindung hört die LED-Anzeige auf zu blinken. Verwenden Sie die Fernbedienung, um Bilder aufzunehmen, die LED blinkt jeweils einmal
3. Die Fernbedienung schaltet sich nach 5 Minuten automatisch ab, wenn sie nicht gekoppelt ist
4. Die Fernbedienung schaltet nach 10 Minuten automatisch in den Ruhezustand Betrieb. und schaltet sich nach weiteren 10 Minuten automatisch ab, wenn man nicht aufwacht
5. Drücken Sie lange auf die Fernbedienungstaste, um das Gerät auszuschalten. Die LED-Anzeige blinkt 3 mal dann abgeschaltet

Produktparameter

Halterung	2.9-4.5"
Erweiterte Länge	690-1700 mm

Erinnerung:

Das kabellose Selfie-Stick-Stativ nutzt die Fernbedienung zum Aufnehmen von Fotos, anstatt auf die Kamera-App Ihres Mobiltelefons zu klicken. Kompatibel mit Android- und iOS-Smartphones. (Nur für Android-Telefone: Stellen Sie Ihre Lautstärketastenfunktion als Aufnahme in der Kamera-App-Einstellung ein, damit der Selfie-Stick ordnungsgemäß funktioniert.)

Wenn Sie sich über die genauen Schritte nicht im Klaren sind, lesen Sie bitte eine andere detaillierte Bedienungsanleitung oder die Mall-Detailseite.

