





A3

Wireless Neckband Earphones
Use Instructions

About Earphones



Product Specifications

Version: V5.4

Usage time: 35 hours

Distance: 10-20 meters (unobstructed straight line)

Driver: $\Phi 10\text{mm}$

Impedance: 32Ω

Working environment: $-10\sim 45^{\circ}\text{C}$

Standby time: ~ 20 days

Battery capacity: 280mAh

Charging time: ~ 1.5 hours

Charging power: $5\text{V}\sim 150\text{mA}$

Working voltage: $3.1\sim 4.2\text{V}$

Frequency: $2.4\sim 2.480\text{GHz}$

Working current: $5\sim 15\text{mA}$

Indicator Light Description

Power on: Flashing blue three times

Pairing: Flashing red and blue alternately

Work: Indicator off

Charging: Steady red

Power off: Flashing red three times

Fully charged: Light turned off

Pairing

1. When this earphones is off, long press the power button to enter pairing mode, the indicator light will flash blue and red alternately.
2. Turn on the Bluetooth function on your device and find "A3" on the Bluetooth settings screen and pairing. When connected, the indication light will turn off.
3. If this earphones is not connected to a device for 3 minutes, it will automatically shut down.

Pairing to Another Device

When it connects to a device, turn off the Bluetooth function of the device, you can connect A3 to another device according to above operation process. When connected, you can turn on the Bluetooth function of the first device again.

Keys Operation

Power on - Press and hold the power button for 2 seconds

Power off - Press and hold the power button for 4 seconds

Language switching - Triple-click the power button before pairing

Answer a call - Click the power button when there is an incoming call

Hang up - Click the power button during the call

Play/Pause - Click the power button while listening to the song

Reject a call - Long press the power button when there is an incoming call

EQ switch - Double click the power button after Bluetooth connected

Game/Music mode - Triple click the power button after pairing

Calling for voice assistant - Press and hold the power button for 2 seconds

Previous song - Long press the "+" key

Increase Volume - Click the "+" key

Next Song - Long Press the "-" key

Reduce volume - Click the "-" key

Warranty Description

Warranty period: 12 months from the date of purchase of the product.

The following situations are not covered by warranty:

1. The product repair label is damaged;
2. Damage caused by self disassembly;
3. Failures caused by water ingress or falling and considered mechanical damage;
4. Failure or damage caused by force majeure.

Attention:

1. Long term use of earphones may cause hearing damage, please arrange the usage time reasonably.
2. The working hours and charging time vary due to various factors such as playback environment, volume, and sound source.

This product has been inspected by our company's quality control department and its performance parameters meet technical standards.

