

Mibro Watch GS Explorer

User Manual


mibro

User Manual

Please read this manual carefully before using the product and keep it properly.

Product description

Packing list: Mibro Watch GS Explorer(Including Silicone strap) X 1,User manual X 1,
Magnetic charger X 1,Woven strap X1.




① Function button

Turning On: Long press the button for 3 seconds until the screen lights up
Turning Off: Long press the button for 3 seconds until the screen turns off
Return: Click

② Home button

List/Rotating: menu scrolling operations

③ Full touch display



④ Shortcut Button:Custom /Confirm

⑤ Charging port (Positive)

⑥ Charging port(Negative)

⑦ Heart rate sensor

⑧ Barometer bore

Connect the watch

①Please scan the QR code to download the "Mibro Fit" App.

②Please use "Mibro Fit" to scan the QR code for pairing.

Untie a watch

① Android system: select "Delete current device" in the App to unbind the device.

②iOS system: select "Delete current device" in the App, and jump to the Bluetooth interface of mobile phone system according to the prompt,Select Ignore Current Device to unbind the device.



Charging instructions

1. Do not charge in a humid environment;
2. Make sure that the metal contact on the watch body and magnetic charger are not dirty or corroded;
3. Please clean the metal contact on the back of the watch and the magnetic charger with a clean flannel regularly. Make sure that the contacts of the watch and the magnetic charger are in full contact to ensure normal charging;
4. This product is not equipped with a power adapter. In order to ensure the safety of your family and property, you can use a computer USB port or choose a power adapter with an output not exceeding 5V=1A when charging. Please purchase power adapters through formal channels, and never use low-quality and fake power adapters to avoid bursting or fire.



Features

	Daily activities	Daily activity record, only record the data of the day, and the data will be clear at 00:00 every day.
	Sports	Support 150 sports modes.
	Heart rate	Record the daily exercise data, including steps, distance, calories, activity duration, activity times.
	Data	Intelligently monitor heart rate.
	Blood oxygen	Intelligently monitor blood oxygen.
	Sleep	Intelligently monitor your sleep quality.
	Weather	After connecting it to the mobile phone, you can synchronize the weather.
	Training status	Record the training status of the last 7 days and grasp the recovery time.
	Pressure	Monitor the change of your stress value in a day and form an analysis icon.
	Music	You can control music playing on mobile phone after connecting the watch to the mobile phone.
	Alarm	Watch alarm clock setting function.
	World Clock	There are times in 5 countries at the same time, showing the difference between the current time and the time in other countries.
	Women's health	Record women's physiological period conditions and give early warning.
	Breath training	Different frequency and time can be set for respiratory adjustment training.

	Search your phone	After connecting the phone, you can find the phone through the watch.
	Compass	Watch compass function.
	Altitude pressure	Measure altitude pressure and altitude.
	Timer	Watch quick timer.
	Stopwatch	Start the stopwatch function.
	Calculator	Watch mini calculator.
	Calendar	Watch Gregorian calendar function.
	Key card	Only the watch with NFC writing function is supported, and a maximum of 3 access cards can be enabled for a watch.
	Setting	Display & Brightness, Vibration Mode, Message Notifications, Password Settings, Preferences, Workout Settings, System, Shutdown and Restart, Language Settings, Connect a New Phone, Factory Reset, Do not disturb Mode, Phone Connect Portable, Personal Data, Notifications, Energy Saving Mode, Data Recovery, Time and Other Settings.

Trouble shooting and after sales regulations

Name	Bluetooth watch
Mibro Watch GS Explorer	1. Do not turn on. 2. The display screen is not lit or the touch screen is not functional. 3. Cannot be charged.

Non warranty regulations

1. Wear and dirt caused by users' use, such as scratches and color changes; As well as damage caused by contact with chemical reagents, sharp objects, falling, extrusion and deformation.
2. Unauthorized maintenance, collision, misuse, negligence, abuse, water ingress, accidents, and failures caused by the use of non-standard accessories of the product.
3. Tearing, altering labels, forging anti-counterfeiting marks, etc.
4. Damage caused by force majeure.
5. Non compliance with performance faults listed in the performance fault table.

Attention instructions

1. The measurement results of this product are for reference only, not for any medical purpose or basis. Please follow the doctor's instructions and never make self-diagnosis and treatment based on the measurement results.
2. The waterproof grade of this product is 10ATM, but it is not against sea water, Do not dive to a depth of 30 meters or soak in water for a long time. At the same time, it doesn't prevent hot water, because steam will affect the watch.
3. The company reserves the right to modify the contents of this manual with out any notice. Some functions are different in the corresponding software version, which is normal.

Disposal of electrical and electronic equipment



The symbol of the crossed-out wheeled garbage can Symbol on your product. The symbol of the crossed-out wheeled garbage can on your product, battery, or packaging is a reminder that all electronic products and batteries must be disposed of separately at the end of their life and should not be disposed of with other household waste. It is the user's responsibility to dispose of the device at an official collection point or service for the separate recycling of electrical and electronic equipment and batteries in accordance with the applicable local legislation (WEEE - Waste of Electrical & Electronic Equipment).

Options for Returning Old Devices

Owners of old devices may hand in these devices within the framework of the possibilities for the return or collection of old devices set up and available by public waste management authorities, to ensure proper disposal of the old devices. The following link provides an online list of collection and return points: <https://www.ear-svstem.de/ear-verzeichnis/sammel-und-ruecknahmestellen>.

Data Protection

We would like to remind all end users of waste electrical and electronic device that you are responsible for deleting personal data on the waste devices to be disposed of.

CE Declaration of Conformity

Zhenshi Information Technology (Shenzhen) Co., Ltd., hereby declare that this device is in compliance with the essential requirements and other applicable provisions of European Directives 2015/53 /EU and 2011/65/ EU. For the full EU Declaration of Conformity, please refer to our website.<https://www.mibrofit.com/downloads/downloads-smart-watch>

Specifications

Name: Mibro Watch GS Explorer

Model: XPAW017

Size: $\phi 44.1 \times 13 \text{mm}$

Operational Frequency: 2400-2483.5MHz

signal transmission: $\leq 20 \text{dBm}$

Battery capacity: 460mAh

Nominal voltage: 3.8V

Charging cut-off voltage: 4.35V

Input: 5V $\approx$ 1A Max.

FCC ID: 2BAYW-XPAW017

Compatible with: Android 5.0 or iOS 10.0 and above

After-sales service Email: service@mibrofit.com

Manufacturer: ZhenShi Information Technology (Shanghai) Co., Ltd

Address: Room 4015, Building 2, No.588 Zixing Road, Minhang District, Shanghai, China

Exporter: ZhenShi Information Technology (Shenzhen) Co., Ltd

Address: RM1401-1403, 1408, Tower E, Galaxy World, Minzhi Street, Longhua District, Shenzhen, China

