



WHAT'S IN THE BOX





*



**

* Charge the speaker before first use. For safety and peak performance, use genuine JBL batteries. Non-original batteries may pose safety and reliability risks.

** Power cord quantity and plug type vary by regions.

BLUETOOTH PAIRING





< Settings Bluetooth

Bluetooth ☒

DEVICES 

JBL PartyBox ENC ESS 2 Connected 

Now Discoverable

PLAY








x1 

x2 

x3 

LIGHTSHOW






Apply lightshow presets and more with the JBL PARTYBOX app.

APP





Download and install the JBL PARTYBOX app to get more from the product.



 JBL PARTYBOX

 GET IT ON Google Play

 Download on the App Store

MICROPHONE





GUITAR





MULTI-SPEAKER CONNECTION





CHARGING






Due to local laws and regulations, the Powerbank function may be unavailable in certain regions. Please refer to local regulations. | 由于当地法律法规的限制, 移动电源功能在某些地区可能无法使用。请参考当地相关规定。


BATTERY REPLACEMENT



① Remove the Old Battery




② Insert the New Battery



Replacement batteries can be purchased from the JBL Customer Service Center.

SPLASH PROOF IPX4





Do not change your speaker until it is completely dry and clean.

