

Common Problems and Their solutions

1. The device automatically shuts down after extended use. Please recharge the battery and try again
2. If there is stuttering in Bluetooth mode, move speaker closer to the source
3. Unsuccessful Bluetooth pairing
 - a. Ensure the speaker displays on the Bluetooth menu, reboot Bluetooth if it's not listed
 - b. There may be too many devices on your Bluetooth menu. Delete inactive devices and try again

Connecting to Bluetooth

1. Select Bluetooth on the device
2. Go to settings in the device you want to pair
3. Select Bluetooth
4. Make sure Bluetooth is turned on
5. Tap the device name when it appears on screen
6. Device should be paired
7. Note: the next time the devices are used via Bluetooth there may be a delay of up to 10 seconds as the devices automatically pair. If it does not pair automatically, try reconnecting via settings by clicking on the devices in the Bluetooth menu.


Basic Parameters

Model: HBQ6PRO
Effective Distance: ~10 Meters
Power: 5Wx2
Charging Voltage: DC 5V
Frequency Range: 35Hz-16KHz
SNR: ≥80dB
Audio Input: Bluetooth, AUX, U Disk, TF Card
Speaker Unit: 4Ω

Packing List

Bluetooth Speaker
Charging Cable
Instructions
Audio Line

HotBell HBQ6PRO Operation Manual



Instructions

Power On and Volume Control

The knob turns on the device and controls the volume. Turn clockwise to turn on device and increase volume. Turn counter clockwise to turn off device and decrease volume.

Charging

Connect the USB end of the charging cable to a USB power source rated at 5V DC. Insert the micro-USB connector into the device's micro-USB charging port. The red indicator light will turn on to indicate that charging has begun.

Bluetooth Call

To use call feature, short press (symbol) to answer, long press to reject, short press to hang up.

TF Cards/Flash cards

Insert a TF card into the designated slot to enable automatic card-reading mode. Likewise, inserting a flash card into its corresponding slot will prompt the system to switch to card-reading mode automatically.

BLUETOOTH SPEAKER

Warnings and Cautions

1. For best results store and use device in normal room temperature range (68-72° F or 20-22° C)
2. Store device in a cool, dry place when not in use. Keep away from windows, heat sources, and rain. Do NOT leave in direct sunlight for an extended period.
3. To reduce the risk of fire, shock or damage to your device, do not expose your device to rain, snow or other types of moisture. Do not use your device near water or in a damp or excessively humid location (e.g., near a shower, bathtub, sink, or swimming pool, or in a damp basement).
4. Never insert metal objects or other foreign materials into any openings of the unit. Doing so may result in malfunction or risk of injury.
5. Avoid dropping your device, especially on a hard surface, as this can damage the device and/or its battery. If you suspect your device has been damaged, discontinue use.
6. Do not disassemble, open, crush, puncture, repair, and/or modify this device by yourself. Seek professionals for repair. Opening and/or repairing this device can present electric shock, device damage, fire, and/or personal injury risk up to and including death, and other hazards.
7. This device includes a built-in lithium battery. Do NOT dispose of this device in household garbage or recycling bins. This device SHOULD be taken to a separate e-waste recycling or electronics collection point. Inappropriate disposal is a fire hazard. To prevent fire, place device in a separate plastic bag for disposal or follow the directions of your e-waste recycling center.
8. Do NOT use near open flame, (e.g., lit candles, cigarettes, etc.). This device should NOT be used within 3 feet (914mm) of combustible gases, liquids or other flammable substances.
9. Do NOT use a higher voltage than specified. Only charge with the included charging cable to avoid fire and damage to the device.

Warning Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.