


User Manual

MINI Projector



Remote Control



- | | |
|---|---|
| 1. Power ON/OFF | 9. Mute |
| 2. Fast backward
T-shaped correction | 10. Fast forward
T-shaped correction |
| 3. Play/Pause | 11. Up button |
| 4. Left button | 12. Right button |
| 5. OK/Confirm button | 13. Menu button |
| 6. Down button | 14. Source button |
| 7. Back/Exit button | 15. Volume Up button |
| 8. Volume Down
button | |

Power Supply

1. Type-c interface: supports PD, QC, AFC fast charging protocol chargers/charging treasures with output of 12V/1.67A or more, and powers the projector.

2. The product's TYPE-C connector supports 12V/1.67A mobile power for outside use. (Note: If you use A port to TYPE-C data cable or C port to TYPE-C data cable, you need the corresponding power interface.)


Note: If not using the unit for a longer period of time, unplug the adaptor from the wall outlet and from the unit.

User Interface

After the projector is turned on, the following main interface will appear after the 2-5s startup screen flashes.



WiFi Setting



Click on WiFi on the homepage, select the WiFi network, and enter the password to connect to the network.


Wireless screen



Make sure your projector connect same network with your smart phone (phone or Android phone) Clik wireless screen on home page, Filow the guide to make screen mirroring with your phone/Android phone.

Special reminder: The same screen on the phone refers to the projection of the same screen as the screen played by the phone.
Mobile screen projection refers to videos on mobile apps that can be pushed to projectors. Mobile phones can also play games, read novels, chat and work without affecting each other.

Wired screen




Click on the wired screen on the homepage and follow the instructions on the projector to make it mirror your Phone/Android phone.

Note: Please use the original data cable of your phone, otherwise it may not work properly.



Option Settings:

In option settings, you can use in the settings interface, you can select options in the language, set the language, can rotate the screen, side cast or ceiling type delivery and other ways, and software system upgrades.



BT Device

On the homepage, click Settings - Open "BT Devices" Enable Bluetooth, click Search for Devices and select Bluetooth Speaker or Bluetooth Earphone for pairing.

FCC Caution.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.