


# ASSEMBLY INSTRUCTIONS

## Replacement Netting for the Roof Style Gazebo 184DGZ1-PU-25

### Netting Model # 184DGZ1-PU-25-NET





M

M	Mosquito netting	4pcs
---	------------------	------




## 1 Remove the previous netting panels

## 2 Attaching the new netting panels

- From the tiebacks on the Mosquito Netting (M), find the long side 13' and short side 10' of each panel. Attach the mosquito netting up from the inside of the garden house with hook and loop straps on the long side and the short side of frame. Slide the mosquito netting open and close and test the zippers to make sure they match and run smoothly.
- Locate the tiebacks sewn at the outer corner of the netting and always wrap around the corner posts. To hold open the netting panels to the corner posts unzip and slide the panels to the corner posts. Use the fabric tiebacks sewn to the inside of the netting corner to wrap the netting all around the corner post.



### SUGGESTED NETTING USAGES



Please contact our customer service department if you have any questions.

#### Customer Service:

Call between 8:30am to 4:30pm C.S.T.

(Monday to Friday)

Linya Outdoor Living, LLC

P.O. Box 423

Ripon WI 54971

TEL: (833) 807-3550

Customer-Service@Linyaoutdoor.com