


100 Count LED Mickey Mouse Lights

ITM. 990504590 & 990504591

Model Number: HX25052805-S

Assembly Instructions & User's Manual

 help@natures-mark.com



1-877-378-3150 (8 a.m. - 5 p.m., PST, Monday - Friday. English only.)

IMPORTANT, RETAIN FOR FUTURE REFERENCE: READ CAREFULLY

INSTALLATION:

● **TO PREVENT TANGLING, UNWIND LIGHTS FROM THE REEL DURING INSTALLATION OR FULLY UNWIND IN AN OPEN AREA. DO NOT OVERLAP.**

- Carefully remove the product and accessories from package. Keep packaging for safe storage.
- Plug to power supply with corresponding voltage based on the adapter label indicated after installation.

FEATURES:

- Three light functions are included with this product and can be adjusted using the remote control or the button on the adapter.
- A timer mode can be set for this product by pressing the timer button on remote control or long press on the adapter button held for 3 seconds. The button on the adapter will illuminate green when the timer is set successfully.
- In timer mode, the product will stay on for 6 hours, then off for 18 hours automatically and repeat the timer cycle daily.

REMOTE CONTROL USE:

- To start, remove the pull-tab from the bottom of the remote to connect battery power.
- To replace battery, push and pinch corner lock on battery door and pullout (refer to the direction that is on back of remote). Requires 1 3V CR2025 button battery.
- Distance for remote control use is up to 65.5 ft. (20 m) without obstructions.

TROUBLE SHOOTING:

If the product is not functioning, please check if the power source is disabled or the cord may be unplugged.

CAUTION: BATTERY INSTRUCTIONS

- Always purchase the correct size and grade of battery most suitable for the intended use.
- Clean the battery contacts and those of the device prior to battery installation.
- Ensure the batteries are installed correctly according to polarity (+ and -).
- Remove and immediately recycle or dispose of batteries from equipment not used for an extended period of time according to local regulations. Battery leakage can cause corrosion and damage to this product.
- Remove and immediately recycle or dispose of used batteries according to local regulations and keep away from children. Do NOT dispose of batteries in household trash or incinerate.
- Even used batteries may cause severe injury or death.
- Call a local poison control center for treatment information.
- Non-rechargeable batteries are not to be recharged.
- Do not force discharge, recharge, disassemble, heat above 50°C or incinerate. Doing so may result in injury due to venting, leakage or explosion resulting in chemical burns.
- Do not mix old and new batteries, different brands or types of batteries, such as alkaline, carbon-zinc, or rechargeable batteries.
- Always completely secure the battery compartment. If the battery compartment does not close securely, stop using the product, remove the batteries, and keep them away from children.

Battery may contain hazardous substances which could endanger the environment and human health. This symbol marked on the battery and/or packaging indicates that used battery shall not be treated as municipal waste. Batteries should be disposed of at an appropriate collection point for recycling. By ensuring the used batteries are disposed of correctly, you will help to prevent potential negative consequences for the environment and human health. The recycling of materials will help to conserve natural resources. For more information about recycling of used batteries, please contact your local municipality waste disposal service.

TECHNICAL DATA

- Input: 120V ~ 60Hz Output: 30V – 0.20A

IMPORTANT SAFETY INSTRUCTIONS:

When using electrical products, basic precautions should always be practiced including the following:

WARNING:

- READ AND FOLLOW ALL SAFETY INSTRUCTIONS.
- Read and follow all instructions that are on the product or provided with the product.
- For a cord connected or direct plug in power unit, do not use an extension cord.
- Reference the National Electrical Code, ANSI/NFPA 70, specifically for the installation of wiring and clearances from power and lighting conductors.
- Installation work and electrical wiring must be done by qualified person(s) in accordance with all applicable codes and standards, including fire-rated construction.
- Do not install or use within 10 feet of a pool.
- Do not use in a bathroom.
- WARNING: Risk of Electric Shock. When used outdoors, install only to a covered Class A GFCI protected receptacle that is weatherproof with the power unit connected to the receptacle. If one is not provided, contact a qualified electrician for proper installation. Ensure that the power unit and cord do not interfere with completely closing the receptacle cover.
- WARNING: Risk of Fire. Installation involves special wiring methods to run wiring through a building structure. Consult a qualified electrician.
- WARNING: Risk of Electric Shock. Mount the adapter at a height greater than 1 foot from the ground surface.
- WARNING: Not to use with receptacles that are weatherproof only when the receptacle is covered (attachment plug cap not inserted and receptacle cover closed).
- This is an electrical product! To avoid risk of fire, burns, personal injury, and electric shock, close supervision is necessary when the product is used by or near children.
- Keep string lights away from flammable objects.
- Always make sure that all parts have been connected properly to avoid short circuit.
- Do not connect the string lights to the power source until all of the installations have been completed.
- If this product malfunctions, do not try to repair it.
- This is not a toy, for indoor and outdoor decoration only.
- Only adapters of same or equivalent type are recommended.
- This seasonal use product is not intended for permanent installation or use.
- Unplug the product when leaving the house, when retiring for the night, or if left unattended for an extended period.
- Do not use this product for other than its intended purpose.
- Do not alter or replace the plug.
- When not in use, store neatly in a cool, dry location protected from sunlight.

SAVE THESE INSTRUCTIONS – This manual contains important safety and operating instructions for power units.

This product contains a lithium battery. Due to their small size, children can easily swallow lithium batteries. If swallowed or placed inside any part of the body, it could cause severe injury or death in just 2 hours, due to chemical burns and potential perforation of the esophagus. Seek medical attention immediately. Examine devices and make sure the battery compartment is correctly secured, e.g. that the screw or other mechanical fastener is tightened. Do not use if compartment is not secure. Dispose of used button batteries immediately and safely. Flat batteries can still be dangerous. Tell others about the risk associated with button batteries and how to keep their children safe.

⚠ WARNING	
<ul style="list-style-type: none">• INGESTION HAZARD: This product contains a button cell or coin battery.• DEATH or serious injury can occur if ingested.• A swallowed button cell or coin battery can cause Internal Chemical Burns in as little as 2 hours.• KEEP new and used batteries OUT OF REACH of CHILDREN.• Seek immediate medical attention if a battery is suspected to be swallowed or inserted inside any part of the body.	



Caution: The user is cautioned that changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

1. Reorient or relocate the receiving antenna.
2. Increase the separation between the equipment and receiver.
3. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
4. Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

Compliance information statement shall issue by a US Local Responsible Party.

Nature's Mark, LLC

5509 Stockdale Ct, Jurupa Valley, CA 92509, USA

1-877-378-3150

Distributed by Sam's West Inc.

2101 SE Simple Savings Dr.

Bentonville, Arkansas 72716-0745

Made in Cambodia