

Common Problems And Solutions

1. After extended use, the device may shut down automatically. The problem maybe that the battery is low. Charge the device and try again.
2. Stuttering while using the Bluetooth device may be caused by the distance between the Bluetooth device and the connecting device.
3. Unsuccessful pairing between devices.
 - a) Verify that the speaker is set to pair, or reboot the speaker.
 - b) There may be too many Bluetooth devices in the area making it difficult to pair. Turn off other Bluetooth devices and try again.

Cautions

1. Please store and use the product in a normal temperature environment.
2. Do not expose the product to rain or moisture.
3. Do not drop the device as it may cause damage.
4. Please do not disassemble, attempt to repair, or modify this product.
5. This device includes a built-in lithium battery. Do not improperly discard. Do not place in a fire.

Essential Parameter

Effective Distance: 10m
Output Power: 10W×2
Charging Voltage: DC 5V
Frequency Response: 45Hz-16KHz
SNR: ≥80dB
Audio Input: Bluetooth ,COAX,AUX,HDMI,USB
Speaker Unit: 4Ω

Packing List

Bluetooth Speaker×1
Charging Cable×1
Instructions×1
Audio Line×1
Remote Control×1

HotBell
HBLS490

Operation Manual



Safety Warning And Attentions:

The connection device of the product is a USB plug. The USB plug should be placed in an easy-to-access position.

1. This product is to be used in a cool , dry place. Please keep away from windows, heat sources, sunlight and prevent moisture.
2. Do not insert metal or other objects in the openings of the device. The product must not be exposed to moisture as it can cause short-circuiting, which may result in a fire, electric shock, or other injuries.
3. Do not expose the product to open flames, such as candles, cigarettes, or similar situations to avoid fire or damage to the product.
4. Only use the voltage and current specified by the port of the product. Connecting and usage of a voltage higher than the specified value may cause fire and product damage.
5. Do not leave the power connected to the product for long periods of time. Disconnect the power supply during non-use.

Instructions

- 1.M/ Power button:
Press briefly to switch between AUX/USB/coaxial/HDMI/BT/FM; Press for a 3-5 seconds to turn on/off.
2. + key:
Click to increase volume; Press for 3-5 seconds in Bluetooth mode to skip to the next song.
3. - key:
Click to decrease volume; Press for 3-5 seconds in Bluetooth mode to skip to the previous song.
4. Previous song key:
Press briefly to go to the previous song.
5. Next song key:
Press briefly to go to the next song.
6. Bluetooth connection
After entering the Bluetooth mode, search with a mobile phone or other device, and perform pairing connection with the Bluetooth device name "HBLS490", enter the Bluetooth playback mode after pairing is successful.

7.Charge:

Connect the USB socket of the micro charging cable to the USB power port with DC 5V, and connect the micro charging head to the DC 5V socket on the machine to start charging. The red indicator light will show as solid red while charging.

Warning Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.