


Kinglucky



White Noise Machine User Manual


Product Introduction

Thank you for choosing the Kinglucky White Noise Machine. This device is designed to help you relax, focus, and sleep better by providing soothing background noise. Please read this user manual carefully before using your white noise machine to ensure safe and proper use.


Product Information

Product Name	White Noise Speaker
Model	S7
Speaker Specification	40mm, 4Ω, 5W
THD+N	≤1% (1W, 1KHz)
Bottery Capacity	1800mAh
Output Power	2W
Charging Port	Type-C 5V =1A
SNR (Signal-to-Noise Rotio)	≥ 75dB
Product Dimensions	4.17 x 3.78 x1.85 inches
Product Weight	276g

Package Contents



Kinglucky White
Noise Machine



Type-C
Charging Cable



User Manual

Instructions for Use



Volume Down:

Short press to decrease the volume



Volume Up:

Short press to increase the volume



Power Button:

Press and hold for 3 seconds to turn on/off



Timer Button:

Timed light effect:

Light corresponds to 30,60,90


Timer Indicator Lights:



One light for 30 minutes,

Two lights for 60 minutes,

three lights for 90 minutes.



Troubleshooting and Precautions

1. Volume Control:

Avoid setting the volume too high; adjust appropriately to achieve optimal sound quality.

2. Unresponsive Buttons:

Try tapping lightly instead of pressing hard; clean any dust or debris around the buttons.

3. No Sound:

Check if the speaker is muted or if the volume is set too low.

4. Avoid Overcharging and Overdischarging.

Avoid using or storing the speaker for extended periods when the battery is extremely low or fully charged.

5. Storage Environment:

Store in a dry, cool, and well-ventilated place, avoiding direct sunlight and high humidity.

6. Do Not Disassemble or Modify.


Do not disassemble or modify the product to avoid affecting its normal operation.

Charging Instructions

1. Use the included charging cable to connect the product to a power adapter.
 2. The indicator light will turn on while charging and will turn off once fully charged.
 3. It is recommended to charge for 3-4 hours before first use to ensure optimal performance.
-

After-Sales Service

We provide a one-year warranty for this product, If you encounter any issues within the warranty period, please contact our customer service team, and we will be happy to assist you. Customer Service Email: **kingluckycare@gmail.com**



The product battery is a built-in rechargeable battery. Please do not disassemble and replace it by yourself. Use the correct method to charge the device. Do not place the device near fire or expose it to sunlight. Battery heating will damage the safety device and cause the battery to explode or burn.