

INCIPIO



 Bluetooth®

DashDrive

7" Dashboard Display
+ 1080P Dash Cam



INC700-BLK

USER'S MANUAL

Important Safety Precautions

When using your Incipio Dashdrive 7" Dashboard + 1080P Dash Cam, basic safety precautions should always be followed, including the following:

1. READ ALL INSTRUCTIONS BEFORE USING YOUR DISPLAY.
2. Do not use your product near water. Do not expose to any moisture or water. Clean using a dry soft cloth or paper towel.
3. Do not place the product on any wet surfaces.
4. Do not allow children or the infirm to play with the product without adult supervision.
5. Do not expose the product to excessive heat, flames or fire.
6. Always press all buttons or switches carefully. Do not manhan- dle the product.
7. Do not use in extremely dry environments, as this can lead to static discharge during usage.
8. Do not expose to temperatures above 60°C. Do not expose to direct sunlight.
9. Do not attempt to repair this product yourself.
Contact a qualified service center if the product is in need of service.
10. Do not drop, puncture or expose the product to excessive trauma.
11. The product is not intended for commercial use.
12. Do not place near objects that generate a strong magnetic field.

13. Unplug this device when not in use for long periods of time or during lightning storms.
14. The product is intended to be used in an automobile. When installing, make sure it does not block the driver's view or any passenger's airbag deployment.
15. Do not operate the product while you are driving your automobile.

Table of Contents

Introduction, Features, package contents, specifications	3
A Quick Look	4-5
Mounting	6
Powering	7
Home Interface Operation	8
Inserting a Memory Card	9
Live View Operation	10-11
Connecting to an iPhone	12-13
Connecting to an Android Device	14-15
Shortcut Guide, Bluetooth Rename	16
iPhone Mirror	17-18
Android Device Mirror	19
Setting Audio Output	20
Wi-Fi Video	21
Settings	22
Troubleshooting	23
Maintenance and Care	24
FCC Compliance Statement	25
One Year Warranty	26

Introduction

Thank you for purchasing your Incipio Dashdrive 7" Dashboard + 1080P Dash Cam, item INC700-BLK. To get the best results, please read this manual first.

Features

- 7" IPS Dashboard Display
- 1080P Dash Cam
- Mirror Link to Mobile
- Built-in Apps and Navigation
- Built-in Voice Control
- Works With Android + iOS


Package Contents

- 7" Dashboard Display
- 8 GB memory Card
- USB-C to 12 V/24 V Car Power Cable
- Mounting Bracket
- 3.5 mm AUX Cable
- User's Manual With Warranty Information


Specifications

- Bluetooth pairing name: INC700_XXXXXX
- Wi-Fi pairing name: CP70_XXXXXX
- Wi-Fi pairing password: 12345678
- Display: 7" Touchscreen
- AUX OUT connection: 3.5mm
- Car adaptor power input: 12 V/24 V

A Quick Look



A Quick Look (Continued)



Mounting

The Dashboard Display includes a mounting bracket. Connect the Dashboard Display to the mounting bracket. Push the bracket up to secure the connection. Ensure the device is properly connected and securely in place, as shown in the image below.



On the side of the mounting bracket is a knob. Rotate the knob counter-clockwise to loosen the mounting bracket's neck and adjust the angle. Rotate the knob clockwise to lock the angle into place.

At the bottom of the mounting bracket is a protective film that covers an adhesive coating. Clean the installation site on the car dashboard of any dust. Remove the protective film and press the mounting bracket onto the center of the car dashboard.

***CAUTION:** Never install the touchscreen in a location that blocks your view of the road, interferes with the mirror or controls, or obstructs the airbag.*

Powering

The Dashboard Display relies on an external power source to operate.

Plug the power cable into your car's cigarette lighter socket or a compatible 12V/24V power port. Connect the other end to the Power Port at the side of the Dashboard Display.

If the touchscreen does not power on automatically after you connect it to a power source, press and hold the Power button to turn it on/off.



Home Interface Operation



1. Date and Time
2. SD Card Status
3. Live View of the Camera
4. Enlarge Live View
5. Recording Status and Time
6. Carplay
7. Android Auto
8. Airplay

9. Miracast
10. Audio Out
11. Playback
12. screen off
13. Brightness
14. Connection
15. Audio Out
16. Setting

Inserting A Memory Card

An 8 GB memory card comes preinstalled. You can replace the SD memory card following the steps below. To avoid damage, do not insert or remove a memory card while the device is ON.

The memory card slot is spring-loaded. To correctly insert the memory card:

- 1) Push the SD memory card into the slot in the direction shown on the dash cam.
- 2) Push the SD memory card until you hear a clicking sound. This indicates the card is inserted correctly.

To remove a memory card from the memory card slot, push the edge of the card until it pops out, and then pull it from the slot.

NOTE: To ensure smooth performance and plenty of room for recording long journeys, use an SD memory card rated Class 10 or above, with at least 4GB.

CAUTION: We do not guarantee compatibility with memory cards from all manufacturers. Use only good-quality memory cards from reliable sources.

It is recommended to insert a new card or, if it is not new, to format the memory card before first using it. Formatting will permanently delete all data on the memory card, so be sure to

copy the data you want to keep to another storage device before formatting.

Live View Operation

To enter Live View mode and use the camera, press the Enlarge Live View icon on the home interface.



- | | |
|------------------------------|-------------------------|
| 1. Date | 6. Start/Stop Recording |
| 2. Time | 7. Lock/Unlock |
| 3. Memory Card Status | 8. Photo |
| 4. Return | 9. Playback Menu |
| 5. Recording Status and Time | 10. Mute/Unmute |

Recording Videos

Depending on your settings, the dashboard may start recording automatically. To start/stop recording manually, press the

Start/Stop Recording icon. While recording, the Start/Stop Recording icon will display red. If the product is recording a locked video, the icon will be yellow.

Live View Operation (Cont.)

Locking/Unlocking Recordings

As the dashboard camera records videos and takes photos, it overwrites older videos as it uses the inserted memory card. To prevent a video from being overwritten, press the Lock/Unlock icon. While a video is locked, the Start/Stop Recording icon will turn yellow. To stop recording locked videos, press the Lock/Un-lock icon. The Start/Stop Recording icon will turn red for standard recording.

Take a Photo

Press the photo icon to take a photo.

Playback Menu

To enter the playback menu, press the Playback Menu icon. You can view the photos or videos you have already taken.



Live View Operation (Cont.)

1. *Select: Press to select a photo or video. Press twice to select all.*
2. *Delete: After selecting a photo or video, press to delete the selected file.*

Mute/Unmute

press the Mute/un mute icon to turn the microphone on/off.

Connecting to an iPhone

To connect the touchscreen to an iPhone, follow the steps below.



1. Select CarPlay from the main menu of the Home Interface.

2. Turn on Wi-Fi and Bluetooth on your mobile device. Connect to the device listed as "INC700_XXXXXX". The last six digits of the pairing name are unique to each device.



3. A pop-up will display on your mobile device asking to pair. Select "Pair" in the options.



4. For full functionality, select "Allow" when asked to sync contacts and favorites.



5. Select “Use CarPlay” and select “Connect”.

Connecting to an iPhone (Continued)

When paired with the dashboard display, the mobile device will use the touchscreen's built-in Wi-Fi to stay connected and disconnect from Bluetooth. Do not connect to any other Wi-Fi.

While connected, do not turn off the Wi-Fi function on your mobile device.

Your mobile device may attempt to pair with other Bluetooth devices after pairing with the touchscreen. Disconnect from the additional devices. Connecting additional devices can cause audio issues and limit key touchscreen functions.



NOTE: Some versions of the IOS system may be incompatible with the touchscreen. Ensure you are using the most up-to-date version of the IOS system.

The touchscreen will automatically reconnect to previously paired devices if those devices have Bluetooth and Wi-Fi enabled.

Connecting to an Android Device

To connect the touchscreen to an Android mobile device, follow these steps.

- 1. Select Android Auto from the main menu of the Dashboard Display.*
- 2. Turn on Wi-Fi and Bluetooth on your mobile device. Connect to the device listed as "INC700_XXXXXX". The last six digits of the pairing name are unique to each device.*
- 3. A pop-up will display on your mobile device asking to pair. Select "Pair" in the options.*
- 4. For full functionality, select "Allow" when asked to allow messages.*



Connecting to an Android Device (Continued)

Your mobile device may attempt to pair with other Bluetooth devices after pairing with the touchscreen. Disconnect from the additional devices. Connecting additional devices can cause audio issues and limit key touchscreen functions.

NOTE: *Supported models include Android 11.0 and above; Google or Samsung phones running Android 10.0; and Samsung Galaxy S8, Galaxy S8+, and Note 8 with Android 9.0 or above.*

The touchscreen will automatically reconnect to previously paired devices if those devices have Bluetooth and Wi-Fi enabled.

Shortcut Guide

When using Apple Carplay or Android Auto, a white circle icon will appear on the right of the application, allowing for access to shortcut selection.



Select to open shortcut menu.



Select to open the default home screen menu.



Select to adjust the volume.



Select to adjust the brightness.



Select to enter video recording interface.

Bluetooth Rename


When using Apple Carplay or Android Auto, you can customize the Bluetooth pairing name as shown in the image below.



IPhone Mirror


Mirroring your device will display your mobile device's screen onto the touchscreen. To do so, follow the steps below.

1. Select Airplay in the home interface.
2. Enable Wi-Fi on your mobile device Ensure no other device is connected to the touchscreen.
3. Connect the mobile device to the Wi-Fi named "CP70_XXXXXX". The last six digits of the pairing name are unique to each device. If a password is requested, enter "12345678".
4. Enable screen mirroring on the mobile device.



iPhone Mirror (Continued)

5. Select “CP70_XXXXXX” in the screen mirroring menu options.



6. To disconnect, in the screen mirroring menu, click “stop Mirroring”.



Android Device Mirror

Mirroring your device will display your mobile device's screen onto the touchscreen. To do so, follow the steps below.

1. Select Miracast in the home interface.
2. Enable Wi-Fi on your mobile device Ensure no other device is connected to the touchscreen.
3. Download the required App "MirrorHelper" through the QR code on the touchscreen or by searching for it on the Google Play Store.
4. Connect the mobile device to the Wi-Fi named "CP70_XXXXXX". The last six digits of the pairing name are unique to each device. If a password is requested, enter "12345678".
5. Enable Floating Window Permissions for the "MirrorHelper" App.
6. Open the "Mirror Helper" App and select "Start" to enable messages.



Start recording or casting with MirrorHelper?

Entire screen

When you're sharing, recording, or casting, MirrorHelper has access to anything visible on your screen or played on your device. So be careful with things like passwords, payment details, messages, photos, and audio and video.

Cancel

Start

Setting Audio Output

After connecting your mobile device to the touchscreen, select Audio Output in the home interface. By default, the audio will be output by touchscreen's speaker.

You can select between four audio outputs.

Speaker: Select to play audio through the touchscreen's speaker.

Carplay/Audio: Select to output audio through the car's speakers using Bluetooth.

FM Transmit: Select to output audio through the car's speakers using FM radio signals. To use, set the connected device to an unused frequency. Set the car radio to the selected unused frequency. In locations with multiple radio sources, the audio may be obstructed.

NOTE: The FM Transmit only works with compatible devices.

AV IN: Select to switch to AUX. This option requires connecting the touchscreen to the car's AUX port using a compatible AUX cable.

Wi-Fi Video

You can view videos and photos on the dashboard remotely through your mobile device using the “Viidure” App. To do so, follow the steps below.

1. Select the Connection icon on the home interface.
2. Scan the QR code on the touchscreen or search for the “Viidure” App on the Apple App Store or Google Play Store.



3. Connect to the dashboard's Wi-Fi. If prompted for a password, enter “12345678”.
4. Enter the “Viidure” App and connect the dashboard. In the app, you can view the live video from the camera as long as the dashboard is powered on.

Settings

Select Settings from the home interface to access the touchscreen's settings. Below is a list of possible settings.

Resolution: 1080P

Loop Record: 1 Min/ 3 Mins/ 5 Mins

Audio: OFF/ON

Beep Sound: OFF/ON

Assistive Touch: OFF/ON

Screen Save: OFF/ 1 Min/ 3 Mins / 5 Mins

Driving Side: Left-Hand Drive /Right-Hand Drive

Language: Language Options

Date & Time: MM/DD/YYYY

HH:MM G-Sensor: OFF /Low/

Middle/ High

Frequency: 50Hz/60Hz

Forget Connection (Use to forget previous device connections)

Format (Permanently deletes files from an inserted memory card) Default Setting (Resets to factory settings)

Version (Displays version number)

Troubleshooting

Mobile device is not successfully pairing with the Display Screen:

- Ensure the mobile device supports Apple CarPlay or Android Auto.
- Ensure both Bluetooth and Wi-Fi are enabled on the mobile device.
- Turn off/on the touchscreen and/or the mobile device.
- The mobile device's operating system may need to be updated to the latest version.
- Bring the mobile device closer to the touchscreen for a stronger signal.
- If the touchscreen's Bluetooth pairing name does not display on your device, refresh the list and wait up to one minute.
- If the touchscreen shows two dots on either side, the touchscreen is already paired with another device. Unpair the touchscreen from the device and then attempt to pair again.

Car stereo does not have sound:

- Enter Audio Output through the main menu and set the preferred audio output.
- Ensure the volume on the mobile device or touchscreen is not muted or set to zero.

The volume of the touchscreen's speaker is not loud enough:

- Set the Audio Output to the car's speakers or to the phone.

Screen is frozen/unresponsive:

- Located on the back of the touchscreen is a reset button. Using a pin, press and hold the reset button. You can also remove the touchscreen from the power source and reconnect.

No sound or distorted sound using FM transmission:

- After you confirm to Switch to the FM transmission function, make sure your car's original radio tunes to the same band frequency to receive sound. Set the transmission frequency to the same on both the touchscreen and your original car radio. Also, make sure not to use the frequency band used by local radio stations.

Maintenance and Care

Before using your dashboard display, inspect the ports to ensure that they are free of dust and debris before inserting any cables.

-Use a soft cloth to clean your touchscreen. Never use harsh chemicals or detergents. Make sure your touchscreen is dry before using it.

-When your device is not used, it should be stored in a cool, dry place.

-Never tug or yank on the power cable while it is connected to your device. Connect and disconnect all cables as carefully as possible.

-Never expose the device to extremely high temperatures, extreme cold, high humidity, or excessive moisture or water.

Please recycle or dispose of your device properly according to your municipality's laws and rules. For further information, contact local recycling facilities and/or the manufacturer of your dashboard display.

FCC Compliance Statement

changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC

Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This

equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the

equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

One Year Warranty

This warranty covers the original consumer purchaser only and is not transferable.

This warranty covers products that fail to function properly UNDER NORMAL USAGE, due to defects in material or workman- ship. Your product will be repaired or replaced at no charge for parts or labor for a period of one year.

What Is Not Covered by Warranty

Damages or malfunctions not resulting from defects in material or workmanship and damages or malfunctions from other than normal use, including but limited to, repair by unauthorized parties, tampering, modification or accident.

To Obtain Warranty Service and Troubleshooting Information:

Call 1-800-592-9541 or visit our website at www.incipio.com.

To receive Warranty service along with the name and address of an authorized product service center, the original consumer purchaser must contact us for problem determination and service procedures. Proof of purchase in the form of a bill of sale or receipted invoice, evidencing that the product is within the applicable Warranty period(s), MUST be presented in order to obtain the requested service. It is your responsibility to properly package and send any defective products along with a dated

copy of proof of purchase, a written explanation of the problem, and a valid return address to the authorized service center at your expense. Do not include any other items or accessories with the defective product. Any products received by the authorized service center that are not covered by warranty will be returned unrepai red.

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

RF Exposure Information

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.



©2026 INCIPIO

195 Carter Drive

Edison, NJ 08817

Support: 800 592 9541

www.incipio.com

* All brand, product names and logos are trademarks or registered trademarks of their respective companies.

