


# SwitchBot Battery Circulator Fan 2 Pro

## User Manual




Scannen Sie den QR-Code, um die deutsche Version unseres Benutzerhandbuchs zu erhalten.  
Scannez le code QR pour obtenir notre manuel d'utilisation en version française.  
Escanee el código QR para obtener la versión en español de nuestro manual de usuario.  
Scan de QR code voor de Nederlandse versie van onze gebruikershandleiding.  
Scansionate il codice QR per ottenere la versione italiana del nostro manuale d'uso.  
Zeskanuj kod QR, aby pobrać instrukcję obsługi w języku polskim.  
<https://www.switch-bot.com/pages/switchbot-user-manual>



User Manual

### Package Contents



Battery Circulator Fan 2 Pro × 1




Remote Control × 1



Charging Cable × 1

### List of Components



Please read this user manual carefully before using your device.



## Preparation

For direct Matter pairing (e.g., to use with Apple Home):

Hold the power button for 15s to enter Matter pairing mode. Scan the Matter setup code on the device to add the device.

Scan for detailed Matter setup instructions:



How to set up Matter (iOS)



How to set up Matter (Android)

You will need:

- A smartphone or tablet using Bluetooth 4.2 or later.
- The latest version of our app, downloadable via the Apple App Store or Google Play Store.
- A SwitchBot account, you can register via our app or sign in to your account directly if you already have one.

**Please note:** if you intend to use the third-party services or voice control, you will need a SwitchBot Hub (sold separately).



iOS and Android system requirements:


<https://support.switch-bot.com/hc/en-us/articles/12567397397271>



## How to Use


### Power On

- 1 Switch the bottom switch to I.
- 2 Check the remaining battery level. Charge your fan if the battery level is too low. It will take approximately 8 to 10 hours to fully charge your fan.
- 3 Operate the control panel and let your fan work.



**Sign in to Our App**  
 Tap and sign in to your account. Tap "+" located at the top right-hand corner of the home page, select "Add Device", find the Fan icon. Then follow the instructions to add your Fan.


## Control Panel & Display



Buttons	Descriptions
	<ul style="list-style-type: none"> <li>• Press once to:               <ul style="list-style-type: none"> <li>-Turn on the fan to previous settings by default.</li> <li>-For first-time use: enter Normal mode, fan speed 1.</li> </ul> </li> <li>• Long press for 2s to enter pairing mode.</li> <li>• Long press for 15s to factory reset your fan (this will put it into Matter pairing mode).</li> </ul>
M	Press to switch fan mode.
	<ul style="list-style-type: none"> <li>• Short press to cycle through the Nightlight mode: Bright, Soft, Off.</li> <li>• Long press for 2s to enter Timer setting mode. Short press to cycle through the Timer from 0 to 9 hours.</li> </ul>
	<ul style="list-style-type: none"> <li>• Short press to activate/deactivate horizontal oscillation.</li> <li>• Long press to make the fan oscillate to the front and then stop oscillating.</li> </ul>
	<ul style="list-style-type: none"> <li>• Short press to activate/deactivate vertical oscillation.</li> <li>• Long press to make the fan oscillate to the level position and then stop oscillating.</li> </ul>
	<ul style="list-style-type: none"> <li>• Press to enter Normal Mode</li> <li>• Press to cycle through fan speed from 1 to 9.</li> </ul>

Display Icons	Descriptions
	Turbo Mode
	Natural Mode
	Sleep Mode
	Battery Level
	Horizontal Oscillation
	Vertical Oscillation
	Fan Speed and Timer Duration
h	Time Unit

## Remote Control



Buttons	Descriptions
	Power Button
M	Mode Button
	Vertical Oscillation Button
	Horizontal Oscillation Button

Buttons	Descriptions
+ -	+: Increase Fan Speed -: Decrease Fan Speed <b>Note:</b> If pressed while in Natural, Sleep, or Turbo mode, the fan switches to Normal mode at its previous speed.
	Timer Button (0 to 9 hours)
	Nightlight Mode Button

## Restoring Factory Settings

To factory reset your fan, simply long press the power button on the Control Panel for 15s. This will clear all device settings and put your fan into Matter pairing mode.

## Firmware Upgrades

In order to improve user experience, we will regularly release firmware updates to introduce new functions and solve any software defects that may occur during usage. When a new firmware version is available, we will send an upgrade notification to your account via our app. When upgrading, please make sure your product has sufficient battery or stay powered on and make sure your smartphone is within range to prevent interference.

## Specifications

Material: ABS + PC

Size: 315 × 158 × 356 mm (12.4 × 6.2 × 14 in.)

Weight: 2.1kg (74.1 oz)

Input: 100-240 V~, 50/60 Hz

Operating Temperature: 0°C to 40°C (32°F to 104°F)

Operating Humidity: 0% to 90% RH

Connectivity: 2.4GHz Wi-Fi + Bluetooth 4.2

## Warranty

We warrant to the original owner that this product will be free from defects in materials and workmanship under normal use. Please note that this limited warranty does not cover:

1. Products submitted after the original limited warranty period has expired.
2. Products that have been repaired, altered, or modified without authorization.
3. Products subjected to drops, extreme temperatures, water exposure, or other operating conditions outside the product specifications.
4. Damage caused by natural disasters, including but not limited to lightning, floods, tornadoes, earthquakes, or hurricanes.
5. Damage resulting from misuse, abuse, negligence, or accidents (e.g., fire).
6. Damage not attributable to defects in materials or workmanship.
7. Products purchased from unauthorized resellers.
8. Consumable parts, including but not limited to batteries.
9. Normal wear and tear.

## Contact & Support

Feedback: If you have any concerns or problems when using our products, please send feedback via our app through the Profile > Support page.

Setup and Troubleshooting: [support.switch-bot.com](https://support.switch-bot.com)

Support Email: [support@switch-bot.com](mailto:support@switch-bot.com)