





LED DOME SPEAKER

1



Functions Overview

1. Mode Button
2. Previous Track / Decrease Volume
3. Power On/Off / Play/Pause
4. Next Track / Increase Volume
5. LED Light Mode
6. USB Type-C Charging Port
7. USB Flash Drive Port
8. TF Card Drive Port
9. AUX-IN port
10. Indicator Light

Notice:

Please read user manual carefully and keep it for your records.

Package includes:

- 1 (One) Led Dome Speaker 4.33in. x 4.33in. x 5.15in. (10.99cm x 10.99cm x 13.1cm)
- 1 (One) USB Type-C Cable 11.8in.(30cm)
- 1 (One) User Manual

Specifications:

- Bluetooth®: V5.4
- Sound Output: 5W
- Battery type: 500 mah built-in rechargeable lithium battery
- Charge Time: up to 3 hours
- Play Time: up to 4 hours
- Standby Time: 6 hours
- Operating Range: 10m
- Input: DC 5V 1A max

Features:

- With Bluetooth®, AUX input jack; USB & TF card ports; TWS function.
- “True Wireless Stereo Function” when paired with another Led Dome Speaker.
- Bass-boosting sound.
- Colorful lights create a relaxing mood.

2 3

Charging:

Your speaker comes with a built-in rechargeable battery. Prior to using the speaker for the first time, it is recommended to fully charge the battery for 2-3 hours. When the speaker is in low power status it will emit a tone. Please recharge the battery of the speaker.

Connect the Type-C end of the provided charging cable into the Type-C charging port on the back of the speaker, and connect USB-A end of the charging cable into a compatible USB power port (DC 5V 1A max). The red Indicator Light will be illuminated while charging. It takes approximately 2-3 hours to completely charge the battery. When charging is complete, the red Indicator Light with turn off.

Instructions for Use:

1. Place speaker within 30 feet of the Bluetooth® enabled device.
2. Press the ON/OFF button.
3. On your Bluetooth® enabled smartphone, tablet or media player, navigate to the Bluetooth® setting menu, turn on the Bluetooth® feature, and search for new devices.
4. Find the model's Bluetooth® name “BY-BS-260”. Connect with the model by clicking the name on the smartphone. “Connected” message will appear to indicate it connected successfully.

4

- Long Press to decrease Volume
Short Press for previous song
- Long Press to turn ON/OFF
Short Press to Play/Pause
- Long Press to increase Volume
Short Press for next song

If the speaker doesn't connect to a Bluetooth® device, it will automatically shutdown after 5 minutes.

TWS Use:

To use this speaker as a TWS true wireless pair, you will need a second LED Dome Speaker, sold separately:

1. Turn on both speakers.
2. Connect one of the speakers to the phone.
3. Choose one of them and long press the “M” button, and the two speakers will be connected automatically. When the connection is successful, long press the “M” button again, and the connection will be disconnected (the speaker connected to the phone will continue to sound).

External Media:

To use a USB Flash Drive port, simply plug in the USB Flash Drive into the port, the speaker will change mode automatically.

To use a TF Card Drive port, press the card into the slot until it clicks and stays. The speaker will change mode automatically. To remove the card, press it in further and it will click and the spring will push it out so you can remove TF card.
*Only supports audio files in mp3 format.

FM Radio Use:

1. Insert the USB-A side of the charging cable into a USB Flash Drive Port (it will function as an FM radio antenna).
2. Press the “M” button until you hear the static of radio.
3. Press the **Play/Pause** button to begin a frequency scan. The speaker will search through the available frequencies in your area and assign each discovered frequency as a preset.
4. Now when you press the **Previous** and **Next** buttons you can search through the frequencies.
5. You can rescan the radio frequencies by pressing the **Play/Pause** button again.

LED Light:

Short press the **Light Mode** button to cycle through 6 light style modes.

5 6

AUX-IN:

Connect any aux enable audio device to play music directly through wired connection

Warnings

- Do not let small children play this product
- Do not expose the speaker to liquid, moisture or humidity to avoid the product's internal circuit being affected.
- Do not use abrasive cleaning solvents to clean the speaker.
- Store the speaker out of direct sunlight and extreme temperatures (above 45°C/113°F or below -10°C/14°F) as this may shorten the battery life, affect the operation or degrade the performance of your speaker.
- Do not dispose of the speaker in a fire to sharp objects as this will cause scratches and damage.
- Do not drop the speaker, This is may cause damage to the internal circuitry.
- If the speaker is left for long period without use, charge once per month to avoid the overconsumption of the battery.
- This appliance is for indoor use only, Please do not use or store the unit in high temperature or hazardous locations, Please do not submerge the unit into water, as this will ruin the speaker.
- The unit comes with a rechargeable battery, so please do not throw or put it in a fire to avoid explosion.
- The warranty for this product is invalidated if the products had been damaged, repaired or modified in any way.

FCC ID: 2AHN6-AUBS260

7

FCC Warning:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment. This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 0cm between the radiator and your body.

WARRANTY- 12 MONTH


Please visit our website Bytechintl.com/warranty

©2026 BYTECH NY INC.
BYTECH™ is a registered trademark of Bytech NY INC.
Bluetooth® is a registered trademark of SIG.Inc
*All Trademarks and copyrights are the property of the respective companies.
*Photos are for illustration purposes only.

USB Cable Rating Input/output 5V 1A 5W Max
CAUTION: FOR YOUR SAFETY. The charging cable included with this item is intended for use with this product only



BYTECH
Contact Info:
2585 West 13th Street,
Brooklyn, NY 11223
Bytechintl.com
© 2026 BYTECH NY INC.
MADE IN CHINA



Accordion Fold Broadside