





HKTWSBUB : User Manual

4/24

FRONT

<h3>Compliance Information</h3> <p>FCC Information This device complies with Part 15 of the FCC Rules.</p> <p>Caution: Any changes or modifications not expressly approved could void the user's authority to operate the equipment.</p> <p>Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:</p> <ul style="list-style-type: none"> Reorient or relocate the receiving antenna. Increase the separation between the equipment and receiver. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. Consult the dealer or an experienced radio/TV technician for help. <p>This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.</p> <p>Radiation Exposure Information The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.</p> <p>WARNING Li-ion Battery Inside This product is fitted with a Li-ion battery. Do not damage, open, or dismantle the battery and do not use it in damp and/or corrosive conditions. Use only with compatible chargers. Never dispose of batteries in a fire, and never expose them to high temperatures. Do not expose the product to temperatures exceeding 60°C (140°F).</p> <p>Rating Label Definitions</p> <ul style="list-style-type: none"> Direct current symbol. This symbol signifies the product must not be discarded as household waste, and should be delivered to an appropriate collection facility for recycling. Proper disposal and recycling helps protect natural resources, human health and the environment. This symbol signifies and declares that this equipment has battery charging which complies with California CEC and energy efficiency. This symbol signifies that this is a wireless device powered by Bluetooth® technology. The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. used under license. This symbol represents FCC Declaration of Conformity and compliance. 	<h3>Warranty Information</h3> <p>90-Day Limited Warranty Territory: United States</p> <p>LIMITED WARRANTY TO ORIGINAL CONSUMER This product as supplied and distributed new by an authorized retailer is warranted by Southern Telecom, Inc. to the original consumer purchaser against defects in materials and workmanship ("Warranty") as follows:</p> <p>To obtain warranty service:</p> <ul style="list-style-type: none"> Visit our customer support portal: www.customersupport123.com and select "Support". Select the brand, fill out the corresponding form (exchanges require dated proof of purchase from an authorized retailer) then submit your request. <p>Your product will be repaired or replaced, at our option, for the same or similar model of equal value if examination by the service center determines this product is defective. Products received damaged as a result of shipping will require you to file a claim with the carrier.</p> <p>Warranty service not provided This warranty does not cover damage resulting from accident, misuse, abuse, improper installation or operation, lack of reasonable care, unauthorized modification including software modifications such as the installation of custom firmware. This warranty is voided in the event any unauthorized person opens, alters or repairs this product. All products being returned to the authorized service center for repair must be suitably packaged.</p> <p>NO WARRANTIES, WHETHER EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, ANY IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, OTHER THAN THOSE EXPRESSLY DESCRIBED ABOVE SHALL APPLY. DISTRIBUTOR FURTHER DISCLAIMS ALL WARRANTIES AFTER THE EXPRESS WARRANTY PERIOD STATED ABOVE. NO OTHER EXPRESS WARRANTY OR GUARANTY GIVEN BY ANY PERSON, FIRM OR ENTITY WITH RESPECT TO THE PRODUCT SHALL BE BINDING ON DISTRIBUTOR. REPAIR, REPLACEMENT, OR REFUND OF THE ORIGINAL PURCHASE PRICE - AT DISTRIBUTOR'S SOLE DISCRETION - ARE THE EXCLUSIVE REMEDIES OF THE CONSUMER, IN NO EVENT</p>	<p>WILL DISTRIBUTOR OR ITS MANUFACTURERS BE LIABLE FOR ANY INCIDENTAL, DIRECT, INDIRECT, SPECIAL, PUNITIVE OR CONSEQUENTIAL DAMAGES (SUCH AS, BUT NOT LIMITED TO, DAMAGES FOR LOSS OF PROFITS, BUSINESS, SAVINGS, DATA OR RECORDS) CAUSED BY THE USE, MISUSE OR INABILITY TO USE THE PRODUCT. EXCEPT AS STATED HEREIN, NO OTHER WARRANTIES SHALL APPLY. NOTWITHSTANDING THE FOREGOING, CONSUMER'S RECOVERY AGAINST DISTRIBUTOR SHALL NOT EXCEED THE PURCHASE PRICE OF THE PRODUCT SOLD BY DISTRIBUTOR. THIS WARRANTY SHALL NOT EXTEND TO ANYONE OTHER THAN THE ORIGINAL CONSUMER WHO PURCHASED THE PRODUCT AND IS NOT TRANSFERABLE.</p> <p>Some countries, states or provinces do not allow the exclusion or limitation of incidental or consequential damages or allow limitations on warranties, so limitation or exclusions may not apply to you. This warranty gives you specific legal rights, and you may have other rights that vary from state to state or province to province. Contact your authorized retailer to determine if another warranty applies.</p> <p>All product names, trademarks, and registered trademarks are property of their respective owners. All company, product, and service names used in this document are for identification purposes only. Use of these names, trademarks, and brands does not imply endorsement.</p> <p> Southern Telecom Inc. 5601 1st Ave. Brooklyn, NY 11220</p> <p> HELLO KITTY® SANRIO® KURUMI® HELLO KITTY AND FRIENDS Sanrio®</p> <p>© 2020 SANRIO CO., LTD. TM and ® are the U.S. Trademarks of their respective owners. www.sanrio.com</p> <p>Designed in US Printed in China 03-2026</p>	<h2>HELLO KITTY® AND FRIENDS WIRELESS EARBUDS</h2> <p>WITH CHARGING CASE</p>  <p>User Manual HKTWSBUB</p>
--	--	---	--




BACK

<h3>Before You Begin...</h3> <p>Caution To ensure safe and proper use, read all safety information before using the device. Only use with manufacturer-approved batteries, chargers, accessories, and supplies.</p> <ul style="list-style-type: none"> THIS DEVICE IS NOT A TOY, do NOT allow children or pets to use or play with this device. Do not disassemble, modify, or repair the device. Do not expose the unit to extreme temperatures (heat or cold), open flames, humid, or wet conditions. Do not submerge in water. Low power may cause poor Bluetooth connection or sound distortion. Do not overcharge battery. If using with a USB adapter, make sure the adapter is not damaged. Do not allow the USB port or the connectors of the supplied USB cable to be exposed to dust, or water, or come into contact with any conductive materials such as liquids, metallic powders, etc. The earbuds & case contain built-in batteries and should not be disposed of with regular household waste. Please consult the local authorities on the correct way to dispose of this device. <p>In the Box</p> <ul style="list-style-type: none"> Wireless Earbuds USB-C Charging Cable Instruction Manual 	<h3>Location of Controls</h3> <p>[Multi] Sensor control: Touch + Hold: Reject incoming call, Power ON/OFF 1x Touch: Pause/resume playback, 1x Touch: Answer/end phone call 2x Touch: Previous/next track 3x Touch: Activate voice assistant 4x Touch: Dial last outgoing number</p>  <p>Earbud Charging Contact</p>  <p>Earbud Charging Ports</p> <p>Case Lid</p> <p>Case Charging LED Indicator</p> <p>Charging Port [Bottom of Case]</p>	<h3>Getting Started</h3> <p>Charging the Case Plug the small connector of the included charging cable into the charging port on the bottom of the case. Plug the large connector into a USB power source such as the USB port on a computer, or into a 5V USB wall adapter (not included).</p> <p>The case LED indicator will flash RED while charging and turn solid RED when fully charged.</p> <p>Charging the Earbuds Make sure the case is charged. To charge the earbuds, place them in the correct ports in the case. They will automatically begin charging. The earbuds' LED indicators will turn RED while charging and turn WHITE when fully charged and then turn off after 30 seconds.</p>  <p>Note: A tone will be heard when the earbuds are low on battery. Please recharge when this happens.</p>	<p>Powering ON/OFF</p> <ul style="list-style-type: none"> The earbuds will automatically power ON when removed from the case, and power OFF when replaced into the case. The earbuds can also be powered ON/OFF by pressing + holding the Multi buttons. When powered ON, will automatically pair to each other. The pair may automatically reconnect to the device they were most recently paired to, so long as that device is within connection range (30 ft.) and Bluetooth is enabled. The earbuds will automatically power OFF if they have not paired to a Bluetooth device after 2 minutes. <p>Bluetooth Pairing</p> <ol style="list-style-type: none"> Power the earbuds ON. Both of their LED indicators will quickly flash white. After a moment, a voice will be heard on the earbuds indicating that they have paired to each other. The LED indicator on the main earbud will quickly flash white, and the LED indicator on the secondary earbud will slowly flash WHITE. Set your mobile device to search for Bluetooth devices. When it appears, select HKTWSBUB from the list of found devices. Once successfully paired, a tone will be heard, and the LED indicator will slowly flash white on both earbuds. <p>Playback Playback will be controlled from your paired device, or the controls listed below.</p> <ul style="list-style-type: none"> 1x Press either Multi button to pause playback. Press again to resume. 2x press either Multi button to skip to the previous track. 3x press either Multi button to skip to the next track. <p>Phone Calls When paired to a phone via Bluetooth, you can control phone functions using the controls listed below.</p> <ul style="list-style-type: none"> 1x Press either Multi button to answer an incoming phone call. 1x Press either Multi button to end a call. 3x Press + hold either Multi button to reject an incoming phone call.
--	---	--	---



HKTWSBUB : User Manual

4/24

FRONT

<h3>Compliance Information</h3> <p>FCC Information This device complies with Part 15 of the FCC Rules.</p> <p>Caution: Any changes or modifications not expressly approved could void the user's authority to operate the equipment.</p> <p>Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:</p> <ul style="list-style-type: none"> Reorient or relocate the receiving antenna. Increase the separation between the equipment and receiver. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. Consult the dealer or an experienced radio/TV technician for help. <p>This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.</p> <p>Radiation Exposure Information The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.</p> <p>WARNING Li-ion Battery Inside This product is fitted with a Li-ion battery. Do not damage, open, or dismantle the battery and do not use it in damp and/or corrosive conditions. Use only with compatible chargers. Never dispose of batteries in a fire, and never expose them to high temperatures. Do not expose the product to temperatures exceeding 60°C (140°F).</p> <p>Rating Label Definitions</p> <ul style="list-style-type: none"> Direct current symbol. This symbol signifies the product must not be discarded as household waste, and should be delivered to an appropriate collection facility for recycling. Proper disposal and recycling helps protect natural resources, human health and the environment. This symbol signifies and declares that this equipment has battery charging which complies with California CEC and energy efficiency. This symbol signifies that this is a wireless device powered by Bluetooth® technology. The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. used under license. This symbol represents FCC Declaration of Conformity and compliance. 	<h3>Warranty Information</h3> <p>90-Day Limited Warranty Territory: United States</p> <p>LIMITED WARRANTY TO ORIGINAL CONSUMER This product as supplied and distributed new by an authorized retailer is warranted by Southern Telecom, Inc. to the original consumer purchaser against defects in materials and workmanship ("Warranty") as follows:</p> <p>To obtain warranty service:</p> <ul style="list-style-type: none"> Visit our customer support portal: www.customersupport123.com and select "Support". Select the brand, fill out the corresponding form (exchanges require dated proof of purchase from an authorized retailer) then submit your request. <p>Your product will be repaired or replaced, at our option, for the same or similar model of equal value if examination by the service center determines this product is defective. Products received damaged as a result of shipping will require you to file a claim with the carrier.</p> <p>Warranty service not provided This warranty does not cover damage resulting from accident, misuse, abuse, improper installation or operation, lack of reasonable care, unauthorized modification including software modifications such as the installation of custom firmware. This warranty is voided in the event any unauthorized person opens, alters or repairs this product. All products being returned to the authorized service center for repair must be suitably packaged.</p> <p>NO WARRANTIES, WHETHER EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, ANY IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, OTHER THAN THOSE EXPRESSLY DESCRIBED ABOVE SHALL APPLY. DISTRIBUTOR FURTHER DISCLAIMS ALL WARRANTIES AFTER THE EXPRESS WARRANTY PERIOD STATED ABOVE. NO OTHER EXPRESS WARRANTY OR GUARANTY GIVEN BY ANY PERSON, FIRM OR ENTITY WITH RESPECT TO THE PRODUCT SHALL BE BINDING ON DISTRIBUTOR, REPAIR, REPLACEMENT, OR REFUND OF THE ORIGINAL PURCHASE PRICE - AT DISTRIBUTOR'S SOLE DISCRETION - ARE THE EXCLUSIVE REMEDIES OF THE CONSUMER, IN NO EVENT</p>	<p>WILL DISTRIBUTOR OR ITS MANUFACTURERS BE LIABLE FOR ANY INCIDENTAL, DIRECT, INDIRECT, SPECIAL, PUNITIVE OR CONSEQUENTIAL DAMAGES (SUCH AS, BUT NOT LIMITED TO, DAMAGES FOR LOSS OF PROFITS, BUSINESS, SAVINGS, DATA OR RECORDS) CAUSED BY THE USE, MISUSE OR INABILITY TO USE THE PRODUCT. EXCEPT AS STATED HEREIN, NO OTHER WARRANTIES SHALL APPLY. NOTWITHSTANDING THE FOREGOING, CONSUMER'S RECOVERY AGAINST DISTRIBUTOR SHALL NOT EXCEED THE PURCHASE PRICE OF THE PRODUCT SOLD BY DISTRIBUTOR. THIS WARRANTY SHALL NOT EXTEND TO ANYONE OTHER THAN THE ORIGINAL CONSUMER WHO PURCHASED THE PRODUCT AND IS NOT TRANSFERABLE.</p> <p>Some countries, states or provinces do not allow the exclusion or limitation of incidental or consequential damages or allow limitations on warranties, so limitation or exclusions may not apply to you. This warranty gives you specific legal rights, and you may have other rights that vary from state to state or province to province. Contact your authorized retailer to determine if another warranty applies.</p> <p>All product names, trademarks, and registered trademarks are property of their respective owners. All company, product, and service names used in this document are for identification purposes only. Use of these names, trademarks, and brands does not imply endorsement.</p>   <p>Southern Telecom Inc. 5601 1st Ave. Brooklyn, NY 11220</p> <p>© 2020 SANRIO CO., LTD. TM and ® are used under license. United States License www.sanrio.com</p> <p>Designed in US Printed in China 03-2026</p>	<h2>HELLO KITTY® AND FRIENDS WIRELESS EARBUDS</h2> <p>WITH CHARGING CASE</p>  <p>User Manual HKTWSBUB</p>
--	--	--	--


BACK

<h3>Before You Begin...</h3> <p>Caution To ensure safe and proper use, read all safety information before using the device. Only use with manufacturer-approved batteries, chargers, accessories, and supplies.</p> <ul style="list-style-type: none"> THIS DEVICE IS NOT A TOY, do NOT allow children or pets to use or play with this device. Do not disassemble, modify, or repair the device. Do not expose the unit to extreme temperatures (heat or cold), open flames, humid, or wet conditions. Do not submerge in water. Low power may cause poor Bluetooth connection or sound distortion. Do not overcharge battery. If using with a USB adapter, make sure the adapter is not damaged. Do not allow the USB port or the connectors of the supplied USB cable to be exposed to dust, or water, or come into contact with any conductive materials such as liquids, metallic powders, etc. The earbuds & case contain built-in batteries and should not be disposed of with regular household waste. Please consult the local authorities on the correct way to dispose of this device. <p>In the Box</p> <ul style="list-style-type: none"> Wireless Earbuds USB-C Charging Cable Instruction Manual 	<h3>Location of Controls</h3>  <p>[Multi] Sensor control: Touch + Hold: Reject incoming call, Power ON/OFF 1x Touch: Pause/resume playback, 1x Touch: Answer/end phone call 2x Touch: Previous/next track 3x Touch: Activate voice assistant 4x Touch: Dial last outgoing number</p> <p>Earbud Charging Contact</p> <p>Case Lid</p> <p>Case Charging LED Indicator</p> <p>Charging Port [Bottom of Case]</p>	<h3>Getting Started</h3> <p>Charging the Case Plug the small connector of the included charging cable into the charging port on the bottom of the case. Plug the large connector into a USB power source such as the USB port on a computer, or into a 5V USB wall adapter (not included).</p> <p>The case LED indicator will flash RED while charging and turn solid RED when fully charged.</p> <p>Charging the Earbuds Make sure the case is charged. To charge the earbuds, place them in the correct ports in the case. They will automatically begin charging. The earbuds' LED indicators will turn RED while charging and turn WHITE when fully charged and then turn off after 30 seconds.</p>  <p>Note: A tone will be heard when the earbuds are low on battery. Please recharge when this happens.</p>	<p>Powering ON/OFF</p> <ul style="list-style-type: none"> The earbuds will automatically power ON when removed from the case, and power OFF when replaced into the case. The earbuds can also be powered ON/OFF by pressing + holding the Multi buttons. When powered ON, will automatically pair to each other. The pair may automatically reconnect to the device they were most recently paired to, so long as that device is within connection range (30 ft.) and Bluetooth is enabled. The earbuds will automatically power OFF if they have not paired to a Bluetooth device after 2 minutes. <p>Bluetooth Pairing</p> <ol style="list-style-type: none"> Power the earbuds ON. Both of their LED indicators will quickly flash white. After a moment, a voice will be heard on the earbuds indicating that they have paired to each other. The LED indicator on the main earbud will quickly flash white, and the LED indicator on the secondary earbud will slowly flash WHITE. Set your mobile device to search for Bluetooth devices. When it appears, select HKTWSBUB from the list of found devices. Once successfully paired, a tone will be heard, and the LED indicator will slowly flash white on both earbuds. <p>Playback Playback will be controlled from your paired device, or the controls listed below.</p> <ul style="list-style-type: none"> 1x Press either Multi button to pause playback. Press again to resume. 2x press either Multi button to skip to the previous track. 3x press either Multi button to skip to the next track. <p>Phone Calls When paired to a phone via Bluetooth, you can control phone functions using the controls listed below.</p> <ul style="list-style-type: none"> 1x Press either Multi button to answer an incoming phone call. 1x Press either Multi button to end a call. 3x Press + hold either Multi button to reject an incoming phone call.
--	---	--	---




HKTWSBUB: User Manual

4/24

FRONT

<h3>Compliance Information</h3> <p>FCC Information This device complies with Part 15 of the FCC Rules.</p> <p>Caution: Any changes or modifications not expressly approved could void the user's authority to operate the equipment.</p> <p>Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:</p> <ul style="list-style-type: none"> Reorient or relocate the receiving antenna. Increase the separation between the equipment and receiver. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. Consult the dealer or an experienced radio/TV technician for help. <p>This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.</p> <p>Radiation Exposure Information The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.</p> <p>WARNING Li-ion Battery Inside This product is fitted with a Li-ion battery. Do not damage, open, or dismantle the battery and do not use it in damp and/or corrosive conditions. Use only with compatible chargers. Never dispose of batteries in a fire, and never expose them to high temperatures. Do not expose the product to temperatures exceeding 60°C (140°F).</p> <p>Rating Label Definitions</p> <ul style="list-style-type: none"> Direct current symbol. This symbol signifies the product must not be discarded as household waste, and should be delivered to an appropriate collection facility for recycling. Proper disposal and recycling helps protect natural resources, human health and the environment. This symbol signifies and declares that this equipment has battery charging which complies with California CEC and energy efficiency. This symbol signifies that this is a wireless device powered by Bluetooth® technology. The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. used under license. This symbol represents FCC Declaration of Conformity and compliance. 	<h3>Warranty Information</h3> <p>90-Day Limited Warranty Territory: United States</p> <p>LIMITED WARRANTY TO ORIGINAL CONSUMER This product as supplied and distributed new by an authorized retailer is warranted by Southern Telecom, Inc. to the original consumer purchaser against defects in materials and workmanship ("Warranty") as follows:</p> <p>To obtain warranty service:</p> <ul style="list-style-type: none"> Visit our customer support portal: www.customersupport123.com and select "Support". Select the brand, fill out the corresponding form (exchanges require dated proof of purchase from an authorized retailer) then submit your request. <p>Your product will be repaired or replaced, at our option, for the same or similar model of equal value if examination by the service center determines this product is defective. Products received damaged as a result of shipping will require you to file a claim with the carrier.</p> <p>Warranty service not provided This warranty does not cover damage resulting from accident, misuse, abuse, improper installation or operation, lack of reasonable care, unauthorized modification including software modifications such as the installation of custom firmware. This warranty is voided in the event any unauthorized person opens, alters or repairs this product. All products being returned to the authorized service center for repair must be suitably packaged.</p> <p>NO WARRANTIES, WHETHER EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, ANY IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, OTHER THAN THOSE EXPRESSLY DESCRIBED ABOVE SHALL APPLY. DISTRIBUTOR FURTHER DISCLAIMS ALL WARRANTIES AFTER THE EXPRESS WARRANTY PERIOD STATED ABOVE. NO OTHER EXPRESS WARRANTY OR GUARANTY GIVEN BY ANY PERSON, FIRM OR ENTITY WITH RESPECT TO THE PRODUCT SHALL BE BINDING ON DISTRIBUTOR, REPAIR, REPLACEMENT, OR REFUND OF THE ORIGINAL PURCHASE PRICE - AT DISTRIBUTOR'S SOLE DISCRETION - ARE THE EXCLUSIVE REMEDIES OF THE CONSUMER, IN NO EVENT</p>	<p>WILL DISTRIBUTOR OR ITS MANUFACTURERS BE LIABLE FOR ANY INCIDENTAL, DIRECT, INDIRECT, SPECIAL, PUNITIVE OR CONSEQUENTIAL DAMAGES (SUCH AS, BUT NOT LIMITED TO, DAMAGES FOR LOSS OF PROFITS, BUSINESS, SAVINGS, DATA OR RECORDS) CAUSED BY THE USE, MISUSE OR INABILITY TO USE THE PRODUCT, EXCEPT AS STATED HEREIN. NO OTHER WARRANTIES SHALL APPLY. NOTWITHSTANDING THE FOREGOING, CONSUMER'S RECOVERY AGAINST DISTRIBUTOR SHALL NOT EXCEED THE PURCHASE PRICE OF THE PRODUCT SOLD BY DISTRIBUTOR. THIS WARRANTY SHALL NOT EXTEND TO ANYONE OTHER THAN THE ORIGINAL CONSUMER WHO PURCHASED THE PRODUCT AND IS NOT TRANSFERABLE.</p> <p>Some countries, states or provinces do not allow the exclusion or limitation of incidental or consequential damages or allow limitations on warranties, so limitation or exclusions may not apply to you. This warranty gives you specific legal rights, and you may have other rights that vary from state to state or province to province. Contact your authorized retailer to determine if another warranty applies.</p> <p>All product names, trademarks, and registered trademarks are property of their respective owners. All company, product, and service names used in this document are for identification purposes only. Use of these names, trademarks, and brands does not imply endorsement.</p> <p> SIL-35047 Southern Telecom Inc. 5601 1st Ave. Brooklyn, NY 11220</p> <p> HELLO KITTY® SANRIO® KURUMI® HELLO KITTY AND FRIENDS Sanrio® © 2020 SANRIO CO., LTD. TM and ® owned U.S. Trademarks Used Under License. www.sanrio.com</p> <p>Designed in US Printed in China 03-2026</p>	<h1>HELLO KITTY®</h1> <h2>WIRELESS EARBUDS</h2> <p>WITH CHARGING CASE</p>  <p>User Manual HKTWSBUB</p>
--	--	--	---










BACK

<h3>Before You Begin...</h3> <p>⚠Caution To ensure safe and proper use, read all safety information before using the device. Only use with manufacturer-approved batteries, chargers, accessories, and supplies.</p> <ul style="list-style-type: none"> • THIS DEVICE IS NOT A TOY, do NOT allow children or pets to use or play with this device. • Do not disassemble, modify, or repair the device. • Do not expose the unit to extreme temperatures (heat or cold), open flames, humid, or wet conditions. • Do not submerge in water. • Low power may cause poor Bluetooth connection or sound distortion. • Do not overcharge battery. • If using with a USB adapter, make sure the adapter is not damaged. • Do not allow the USB port or the connectors of the supplied USB cable to be exposed to dust, or water, or come into contact with any conductive materials such as liquids, metallic powders, etc. • The earbuds & case contain built-in batteries and should not be disposed of with regular household waste. Please consult the local authorities on the correct way to dispose of this device. <p>In the Box</p> <ul style="list-style-type: none"> • Wireless Earbuds • USB-C Charging Cable • Instruction Manual 	<h3>Location of Controls</h3> <p>[Multi] Sensor control: Touch + Hold: Reject incoming call, Power ON/OFF 1x Touch: Pause/resume playback. 1x Touch: Answer/end phone call 2x Touch: Previous/next track 3x Touch: Activate voice assistant 4x Touch: Dial last outgoing number</p>  <p>Earbud Charging Contact</p>  <p>Case Lid Case Charging LED Indicator Earbud Charging Ports Charging Port [Bottom of Case]</p>	<h3>Getting Started</h3> <p>Charging the Case Plug the small connector of the included charging cable into the charging port on the bottom of the case. Plug the large connector into a USB power source such as the USB port on a computer, or into a 5V USB wall adapter (not included).</p> <p>The case LED indicator will flash RED while charging and turn solid RED when fully charged.</p> <p>Charging the Earbuds Make sure the case is charged. To charge the earbuds, place them in the correct ports in the case. They will automatically begin charging. The earbuds' LED indicators will turn RED while charging and turn WHITE when fully charged and then turn off after 30 seconds.</p>  <p>Note: A tone will be heard when the earbuds are low on battery. Please recharge when this happens.</p>	<p>Powering ON/OFF</p> <ul style="list-style-type: none"> • The earbuds will automatically power ON when removed from the case, and power OFF when replaced into the case. • The earbuds can also be powered ON/OFF by pressing + holding the Multi buttons. • When powered ON, will automatically pair to each other. The pair may automatically reconnect to the device they were most recently paired to, so long as that device is within connection range (30 ft.) and Bluetooth is enabled. • The earbuds will automatically power OFF if they have not paired to a Bluetooth device after 2 minutes. <p>Bluetooth Pairing</p> <ol style="list-style-type: none"> 1. Power the earbuds ON. Both of their LED indicators will quickly flash white. 2. After a moment, a voice will be heard on the earbuds indicating that they have paired to each other. The LED indicator on the main earbud will quickly flash white, and the LED indicator on the secondary earbud will slowly flash WHITE. 3. Set your mobile device to search for Bluetooth devices. When it appears, select HKTWSBUB from the list of found devices. 4. Once successfully paired, a tone will be heard, and the LED indicator will slowly flash white on both earbuds. <p>Playback Playback will be controlled from your paired device, or the controls listed below.</p> <ul style="list-style-type: none"> • 1x Press either Multi button to pause playback. Press again to resume. • 2x press either Multi button to skip to the previous track. • 3x press either Multi button to skip to the next track. <p>Phone Calls When paired to a phone via Bluetooth, you can control phone functions using the controls listed below.</p> <ul style="list-style-type: none"> • 1x Press either Multi button to answer an incoming phone call. • 1x Press either Multi button to end a call. • 3x Press + hold either Multi button to reject an incoming phone call.
---	--	--	---




HKTWSDON: User Manual

03/26

FRONT

<h3>Compliance Information</h3> <p>FCC Information This device complies with Part 15 of the FCC Rules.</p> <p>Caution: Any changes or modifications not expressly approved could void the user's authority to operate the equipment.</p> <p>Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:</p> <ul style="list-style-type: none"> Reorient or relocate the receiving antenna. Increase the separation between the equipment and receiver. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. Consult the dealer or an experienced radio/TV technician for help. <p>This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.</p> <p>Radiation Exposure Information The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.</p> <p>WARNING Li-ion Battery Inside This product is fitted with a Li-ion battery. Do not damage, open, or dismantle the battery and do not use it in damp and/or corrosive conditions. Use only with compatible chargers. Never dispose of batteries in a fire, and never expose them to high temperatures. Do not expose the product to temperatures exceeding 60°C (140°F).</p> <p>Rating Label Definitions</p> <p> Direct current symbol.</p> <p> This symbol signifies the product must not be discarded as household waste, and should be delivered to an appropriate collection facility for recycling. Proper disposal and recycling helps protect natural resources, human health and the environment.</p> <p> This symbol signifies and declares that this equipment has battery charging which complies with California CEC and energy efficiency.</p> <p> This symbol signifies that this is a wireless device powered by Bluetooth® technology. The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. used under license.</p> <p> This symbol represents FCC Declaration of Conformity and compliance.</p>	<h3>Warranty Information</h3> <p>90-Day Limited Warranty Territory: United States</p> <p>LIMITED WARRANTY TO ORIGINAL CONSUMER This product as supplied and distributed new by an authorized retailer is warranted by Southern Telecom, Inc. to the original consumer purchaser against defects in materials and workmanship ("Warranty") as follows:</p> <p>To obtain warranty service:</p> <ul style="list-style-type: none"> Visit our customer support portal: www.customersupport123.com and select "Support". Select the brand, fill out the corresponding form (exchanges require dated proof of purchase from an authorized retailer) then submit your request. <p>Your product will be repaired or replaced, at our option, for the same or similar model of equal value if examination by the service center determines this product is defective. Products received damaged as a result of shipping will require you to file a claim with the carrier.</p> <p>Warranty service not provided This warranty does not cover damage resulting from accident, misuse, abuse, improper installation or operation, lack of reasonable care, unauthorized modification including software modifications such as the installation of custom firmware. This warranty is voided in the event any unauthorized person opens, alters or repairs this product. All products being returned to the authorized service center for repair must be suitably packaged.</p> <p>NO WARRANTIES, WHETHER EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, ANY IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, OTHER THAN THOSE EXPRESSLY DESCRIBED ABOVE SHALL APPLY. DISTRIBUTOR FURTHER DISCLAIMS ALL WARRANTIES AFTER THE EXPRESS WARRANTY PERIOD STATED ABOVE. NO OTHER EXPRESS WARRANTY OR GUARANTY GIVEN BY ANY PERSON, FIRM OR ENTITY WITH RESPECT TO THE PRODUCT SHALL BE BINDING ON DISTRIBUTOR. REPAIR, REPLACEMENT, OR REFUND OF THE ORIGINAL PURCHASE PRICE - AT DISTRIBUTOR'S SOLE DISCRETION - ARE THE EXCLUSIVE REMEDIES OF THE CONSUMER, IN NO EVENT</p>	<p>WILL DISTRIBUTOR OR ITS MANUFACTURERS BE LIABLE FOR ANY INCIDENTAL, DIRECT, INDIRECT, SPECIAL, PUNITIVE OR CONSEQUENTIAL DAMAGES (SUCH AS, BUT NOT LIMITED TO, DAMAGES FOR LOSS OF PROFITS, BUSINESS, SAVINGS, DATA OR RECORDS) CAUSED BY THE USE, MISUSE OR INABILITY TO USE THE PRODUCT. EXCEPT AS STATED HEREIN, NO OTHER WARRANTIES SHALL APPLY. NOTWITHSTANDING THE FOREGOING, CONSUMER'S RECOVERY AGAINST DISTRIBUTOR SHALL NOT EXCEED THE PURCHASE PRICE OF THE PRODUCT SOLD BY DISTRIBUTOR. THIS WARRANTY SHALL NOT EXTEND TO ANYONE OTHER THAN THE ORIGINAL CONSUMER WHO PURCHASED THE PRODUCT AND IS NOT TRANSFERABLE.</p> <p>Some countries, states or provinces do not allow the exclusion or limitation of incidental or consequential damages or allow limitations on warranties, so limitation or exclusions may not apply to you. This warranty gives you specific legal rights, and you may have other rights that vary from state to state or province to province. Contact your authorized retailer to determine if another warranty applies.</p> <p>All product names, trademarks, and registered trademarks are property of their respective owners. All company, product, and service names used in this document are for identification purposes only. Use of these names, trademarks, and brands does not imply endorsement.</p> <p> Southern Telecom Inc. 5601 1st Ave. Brooklyn, NY 11220</p> <p> © 2025 SANRIO CO., LTD. TM and ® Sanrio U.S. Trademarks Used Under License www.sanrio.com</p> <p>Designed in US Printed in China 03-2026</p>	  <p>User Manual HKTWSDON</p>
--	--	--	---




BACK

<h3>Before You Begin...</h3> <p>⚠Caution To ensure safe and proper use, read all safety information before using the device. Only use with manufacturer-approved batteries, chargers, accessories, and supplies.</p> <ul style="list-style-type: none"> • THIS DEVICE IS NOT A TOY, do NOT allow children or pets to use or play with this device. • Do not disassemble, modify, or repair the device. • Do not expose the unit to extreme temperatures (heat or cold), open flames, humid, or wet conditions. • Do not submerge in water. • Low power may cause poor Bluetooth connection or sound distortion. • Do not overcharge battery. • If using with a USB adapter, make sure the adapter is not damaged. • Do not allow the USB port or the connectors of the supplied USB cable to be exposed to dust, or water, or come into contact with any conductive materials such as liquids, metallic powders, etc. • The earbuds & case contain built-in batteries and should not be disposed of with regular household waste. Please consult the local authorities on the correct way to dispose of this device. <p>In the Box</p> <ul style="list-style-type: none"> • Wireless Earbuds • USB-C Charging Cable • Instruction Manual 	<h3>Location of Controls</h3> <p>[Multi] Sensor control: Touch + Hold: Reject incoming call, Power ON/OFF</p> <p>1x Touch: Pause/resume playback, 1x Touch: Answer/end phone call 2x Touch: Previous/next track 3x Touch: Activate voice assistant 4x Touch: Dial last outgoing number</p>  <p>Earbud Charging Contact</p>  <p>Earbud Charging Ports</p> <p>Case Lid</p> <p>Case Charging LED Indicator</p> <p>Charging Port (Bottom of Case)</p>	<h3>Getting Started</h3> <p>Charging the Case Plug the small connector of the included charging cable into the charging port on the bottom of the case. Plug the large connector into a USB power source such as the USB port on a computer, or into a 5V USB wall adapter (not included).</p> <p>The case LED indicator will flash RED while charging and turn solid RED when fully charged.</p> <p>Charging the Earbuds Make sure the case is charged. To charge the earbuds, place them in the correct ports in the case. They will automatically begin charging. The earbuds' LED indicators will turn RED while charging and turn WHITE when fully charged and then turn off after 30 seconds.</p>  <p>Note: A tone will be heard when the earbuds are low on battery. Please recharge when this happens.</p>	<p>Powering ON/OFF</p> <ul style="list-style-type: none"> • The earbuds will automatically power ON when removed from the case, and power OFF when replaced into the case. • The earbuds can also be powered ON/OFF by pressing + holding the Multi buttons. • When powered ON, will automatically pair to each other. The pair may automatically reconnect to the device they were most recently paired to, so long as that device is within connection range (30 ft.) and Bluetooth is enabled. • The earbuds will automatically power OFF if they have not paired to a Bluetooth device after 2 minutes. <p>Bluetooth Pairing</p> <ol style="list-style-type: none"> 1. Power the earbuds ON. Both of their LED indicators will quickly flash white. 2. After a moment, a voice will be heard on the earbuds indicating that they have paired to each other. The LED indicator on the main earbud will quickly flash white, and the LED indicator on the secondary earbud will slowly flash WHITE. 3. Set your mobile device to search for Bluetooth devices. When it appears, select HKTWSDON from the list of found devices. 4. Once successfully paired, a tone will be heard, and the LED indicator will slowly flash white on both earbuds. <p>Playback Playback will be controlled from your paired device, or the controls listed below.</p> <ul style="list-style-type: none"> • 1x Press either Multi button to pause playback. Press again to resume. • 2x press either Multi button to skip to the previous track. • 3x press either Multi button to skip to the next track. <p>Phone Calls When paired to a phone via Bluetooth, you can control phone functions using the controls listed below.</p> <ul style="list-style-type: none"> • 1x Press either Multi button to answer an incoming phone call. • 1x Press either Multi button to end a call. • 3x Press + hold either Multi button to reject an incoming phone call.
---	--	--	---



HKTWSDON: User Manual

03/26

FRONT

<h3>Compliance Information</h3> <p>FCC Information This device complies with Part 15 of the FCC Rules.</p> <p>Caution: Any changes or modifications not expressly approved could void the user's authority to operate the equipment.</p> <p>Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:</p> <ul style="list-style-type: none"> • Reorient or relocate the receiving antenna. • Increase the separation between the equipment and receiver. • Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. • Consult the dealer or an experienced radio/TV technician for help. <p>This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.</p> <p>Radiation Exposure Information The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.</p> <p>WARNING Li-ion Battery Inside This product is fitted with a Li-ion battery. Do not damage, open, or dismantle the battery and do not use it in damp and/or corrosive conditions. Use only with compatible chargers. Never dispose of batteries in a fire, and never expose them to high temperatures. Do not expose the product to temperatures exceeding 60°C (140°F).</p> <p>Rating Label Definitions</p> <ul style="list-style-type: none"> Direct current symbol. This symbol signifies the product must not be discarded as household waste, and should be delivered to an appropriate collection facility for recycling. Proper disposal and recycling helps protect natural resources, human health and the environment. This symbol signifies and declares that this equipment has battery charging which complies with California CEC and energy efficiency. This symbol signifies that this is a wireless device powered by Bluetooth® technology. The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. used under license. This symbol represents FCC Declaration of Conformity and compliance. 	<h3>Warranty Information</h3> <p>90-Day Limited Warranty Territory: United States</p> <p>LIMITED WARRANTY TO ORIGINAL CONSUMER This product as supplied and distributed new by an authorized retailer is warranted by Southern Telecom, Inc. to the original consumer purchaser against defects in materials and workmanship ("Warranty") as follows:</p> <p>To obtain warranty service:</p> <ul style="list-style-type: none"> • Visit our customer support portal: www.customersupport123.com and select "Support". • Select the brand, fill out the corresponding form (exchanges require dated proof of purchase from an authorized retailer) then submit your request. <p>Your product will be repaired or replaced, at our option, for the same or similar model of equal value if examination by the service center determines this product is defective. Products received damaged as a result of shipping will require you to file a claim with the carrier.</p> <p>Warranty service not provided This warranty does not cover damage resulting from accident, misuse, abuse, improper installation or operation, lack of reasonable care, unauthorized modification including software modifications such as the installation of custom firmware. This warranty is voided in the event any unauthorized person opens, alters or repairs this product. All products being returned to the authorized service center for repair must be suitably packaged.</p> <p>NO WARRANTIES, WHETHER EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, ANY IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, OTHER THAN THOSE EXPRESSLY DESCRIBED ABOVE SHALL APPLY. DISTRIBUTOR FURTHER DISCLAIMS ALL WARRANTIES AFTER THE EXPRESS WARRANTY PERIOD STATED ABOVE. NO OTHER EXPRESS WARRANTY OR GUARANTY GIVEN BY ANY PERSON, FIRM OR ENTITY WITH RESPECT TO THE PRODUCT SHALL BE BINDING ON DISTRIBUTOR. REPAIR, REPLACEMENT, OR REFUND OF THE ORIGINAL PURCHASE PRICE - AT DISTRIBUTOR'S SOLE DISCRETION - ARE THE EXCLUSIVE REMEDIES OF THE CONSUMER, IN NO EVENT</p>	<p>WILL DISTRIBUTOR OR ITS MANUFACTURERS BE LIABLE FOR ANY INCIDENTAL, DIRECT, INDIRECT, SPECIAL, PUNITIVE OR CONSEQUENTIAL DAMAGES (SUCH AS, BUT NOT LIMITED TO, DAMAGES FOR LOSS OF PROFITS, BUSINESS, SAVINGS, DATA OR RECORDS) CAUSED BY THE USE, MISUSE OR INABILITY TO USE THE PRODUCT. EXCEPT AS STATED HEREIN, NO OTHER WARRANTIES SHALL APPLY. NOTWITHSTANDING THE FOREGOING, CONSUMER'S RECOVERY AGAINST DISTRIBUTOR SHALL NOT EXCEED THE PURCHASE PRICE OF THE PRODUCT SOLD BY DISTRIBUTOR. THIS WARRANTY SHALL NOT EXTEND TO ANYONE OTHER THAN THE ORIGINAL CONSUMER WHO PURCHASED THE PRODUCT AND IS NOT TRANSFERABLE.</p> <p>Some countries, states or provinces do not allow the exclusion or limitation of incidental or consequential damages or allow limitations on warranties, so limitation or exclusions may not apply to you. This warranty gives you specific legal rights, and you may have other rights that vary from state to state or province to province. Contact your authorized retailer to determine if another warranty applies.</p> <p>All product names, trademarks, and registered trademarks are property of their respective owners. All company, product, and service names used in this document are for identification purposes only. Use of these names, trademarks, and brands does not imply endorsement.</p> <div style="display: flex; justify-content: space-around; align-items: center;">   </div> <p>Southern Telecom Inc. 5601 1st Ave. Brooklyn, NY 11220</p> <p>© 2025 SANRIO CO., LTD. TM and ® Sanrio U.S. Trademarks Used Under License www.sanrio.com</p> <p>Designed in US Printed in China 03-2026</p>	 <p>User Manual HKTWSDON</p>
--	--	--	---









BACK

<h3>Before You Begin...</h3> <p>Caution To ensure safe and proper use, read all safety information before using the device. Only use with manufacturer-approved batteries, chargers, accessories, and supplies.</p> <ul style="list-style-type: none"> • THIS DEVICE IS NOT A TOY, do NOT allow children or pets to use or play with this device. • Do not disassemble, modify, or repair the device. • Do not expose the unit to extreme temperatures (heat or cold), open flames, humid, or wet conditions. • Do not submerge in water. • Low power may cause poor Bluetooth connection or sound distortion. • Do not overcharge battery. • If using with a USB adapter, make sure the adapter is not damaged. • Do not allow the USB port or the connectors of the supplied USB cable to be exposed to dust, or water, or come into contact with any conductive materials such as liquids, metallic powders, etc. • The earbuds & case contain built-in batteries and should not be disposed of with regular household waste. Please consult the local authorities on the correct way to dispose of this device. <p>In the Box</p> <ul style="list-style-type: none"> • Wireless Earbuds • USB-C Charging Cable • Instruction Manual 	<h3>Location of Controls</h3>  <p>[Multi] Sensor control: Touch + Hold: Reject incoming call, Power ON/OFF</p> <p>1x Touch: Pause/resume playback, 1x Touch: Answer/end phone call 2x Touch: Previous/next track 3x Touch: Activate voice assistant 4x Touch: Dial last outgoing number</p> <p>Earbud Charging Contact</p> <p>Case Lid</p> <p>Earbud Charging Ports</p> <p>Charging Port [Bottom of Case]</p> <p>Case Charging LED Indicator</p>	<h3>Getting Started</h3> <p>Charging the Case Plug the small connector of the included charging cable into the charging port on the bottom of the case. Plug the large connector into a USB power source such as the USB port on a computer, or into a 5V USB wall adapter (not included).</p> <p>The case LED indicator will flash RED while charging and turn solid RED when fully charged.</p> <p>Charging the Earbuds Make sure the case is charged. To charge the earbuds, place them in the correct ports in the case. They will automatically begin charging. The earbuds' LED indicators will turn RED while charging and turn WHITE when fully charged and then turn off after 30 seconds.</p>  <p>Note: A tone will be heard when the earbuds are low on battery. Please recharge when this happens.</p>	<p>Powering ON/OFF</p> <ul style="list-style-type: none"> • The earbuds will automatically power ON when removed from the case, and power OFF when replaced into the case. • The earbuds can also be powered ON/OFF by pressing + holding the Multi buttons. • When powered ON, will automatically pair to each other. The pair may automatically reconnect to the device they were most recently paired to, so long as that device is within connection range (30 ft.) and Bluetooth is enabled. • The earbuds will automatically power OFF if they have not paired to a Bluetooth device after 2 minutes. <p>Bluetooth Pairing</p> <ol style="list-style-type: none"> 1. Power the earbuds ON. Both of their LED indicators will quickly flash white. 2. After a moment, a voice will be heard on the earbuds indicating that they have paired to each other. The LED indicator on the main earbud will quickly flash white, and the LED indicator on the secondary earbud will slowly flash WHITE. 3. Set your mobile device to search for Bluetooth devices. When it appears, select HKTWSDON from the list of found devices. 4. Once successfully paired, a tone will be heard, and the LED indicator will slowly flash white on both earbuds. <p>Playback Playback will be controlled from your paired device, or the controls listed below.</p> <ul style="list-style-type: none"> • 1x Press either Multi button to pause playback. Press again to resume. • 2x Press either Multi button to skip to the previous track. • 3x Press either Multi button to skip to the next track. <p>Phone Calls When paired to a phone via Bluetooth, you can control phone functions using the controls listed below.</p> <ul style="list-style-type: none"> • 1x Press either Multi button to answer an incoming phone call. • 1x Press either Multi button to end a call. • 3x Press + hold either Multi button to reject an incoming phone call.
--	--	--	---






HKTWSDON: User Manual

03/26

FRONT

<h3>Compliance Information</h3> <p>FCC Information This device complies with Part 15 of the FCC Rules.</p> <p>Caution: Any changes or modifications not expressly approved could void the user's authority to operate the equipment.</p> <p>Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:</p> <ul style="list-style-type: none"> Reorient or relocate the receiving antenna. Increase the separation between the equipment and receiver. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. Consult the dealer or an experienced radio/TV technician for help. <p>This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.</p> <p>Radiation Exposure Information The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.</p> <p>WARNING Li-ion Battery Inside This product is fitted with a Li-ion battery. Do not damage, open, or dismantle the battery and do not use it in damp and/or corrosive conditions. Use only with compatible chargers. Never dispose of batteries in a fire, and never expose them to high temperatures. Do not expose the product to temperatures exceeding 60°C (140°F).</p> <p>Rating Label Definitions</p> <p> Direct current symbol.</p> <p> This symbol signifies the product must not be discarded as household waste, and should be delivered to an appropriate collection facility for recycling. Proper disposal and recycling helps protect natural resources, human health and the environment.</p> <p> This symbol signifies and declares that this equipment has battery charging which complies with California CEC and energy efficiency.</p> <p> This symbol signifies that this is a wireless device powered by Bluetooth® technology. The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. used under license.</p> <p> This symbol represents FCC Declaration of Conformity and compliance.</p>	<h3>Warranty Information</h3> <p>90-Day Limited Warranty Territory: United States</p> <p>LIMITED WARRANTY TO ORIGINAL CONSUMER This product as supplied and distributed new by an authorized retailer is warranted by Southern Telecom, Inc. to the original consumer purchaser against defects in materials and workmanship ("Warranty") as follows:</p> <p>To obtain warranty service:</p> <ul style="list-style-type: none"> Visit our customer support portal: www.customersupport123.com and select "Support". Select the brand, fill out the corresponding form (exchanges require dated proof of purchase from an authorized retailer) then submit your request. <p>Your product will be repaired or replaced, at our option, for the same or similar model of equal value if examination by the service center determines this product is defective. Products received damaged as a result of shipping will require you to file a claim with the carrier.</p> <p>Warranty service not provided This warranty does not cover damage resulting from accident, misuse, abuse, improper installation or operation, lack of reasonable care, unauthorized modification including software modifications such as the installation of custom firmware. This warranty is voided in the event any unauthorized person opens, alters or repairs this product. All products being returned to the authorized service center for repair must be suitably packaged.</p> <p>NO WARRANTIES, WHETHER EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, ANY IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, OTHER THAN THOSE EXPRESSLY DESCRIBED ABOVE SHALL APPLY. DISTRIBUTOR FURTHER DISCLAIMS ALL WARRANTIES AFTER THE EXPRESS WARRANTY PERIOD STATED ABOVE. NO OTHER EXPRESS WARRANTY OR GUARANTY GIVEN BY ANY PERSON, FIRM OR ENTITY WITH RESPECT TO THE PRODUCT SHALL BE BINDING ON DISTRIBUTOR. REPAIR, REPLACEMENT, OR REFUND OF THE ORIGINAL PURCHASE PRICE - AT DISTRIBUTOR'S SOLE DISCRETION - ARE THE EXCLUSIVE REMEDIES OF THE CONSUMER, IN NO EVENT</p>	<p>WILL DISTRIBUTOR OR ITS MANUFACTURERS BE LIABLE FOR ANY INCIDENTAL, DIRECT, INDIRECT, SPECIAL, PUNITIVE OR CONSEQUENTIAL DAMAGES (SUCH AS, BUT NOT LIMITED TO, DAMAGES FOR LOSS OF PROFITS, BUSINESS, SAVINGS, DATA OR RECORDS) CAUSED BY THE USE, MISUSE OR INABILITY TO USE THE PRODUCT. EXCEPT AS STATED HEREIN, NO OTHER WARRANTIES SHALL APPLY. NOTWITHSTANDING THE FOREGOING, CONSUMER'S RECOVERY AGAINST DISTRIBUTOR SHALL NOT EXCEED THE PURCHASE PRICE OF THE PRODUCT SOLD BY DISTRIBUTOR. THIS WARRANTY SHALL NOT EXTEND TO ANYONE OTHER THAN THE ORIGINAL CONSUMER WHO PURCHASED THE PRODUCT AND IS NOT TRANSFERABLE.</p> <p>Some countries, states or provinces do not allow the exclusion or limitation of incidental or consequential damages or allow limitations on warranties, so limitation or exclusions may not apply to you. This warranty gives you specific legal rights, and you may have other rights that vary from state to state or province to province. Contact your authorized retailer to determine if another warranty applies.</p> <p>All product names, trademarks, and registered trademarks are property of their respective owners. All company, product, and service names used in this document are for identification purposes only. Use of these names, trademarks, and brands does not imply endorsement.</p> <p> </p> <p>Southern Telecom Inc. 5601 1st Ave. Brooklyn, NY 11220</p> <p>© 2025 SANRIO CO., LTD. TM and ® Sanrio U.S. Trademarks Used Under License www.sanrio.com</p> <p>Designed in US Printed in China 03-2026</p>	 <p>User Manual HKTWSDON</p>
--	--	---	---

BACK

<h3>Before You Begin...</h3> <p>Caution To ensure safe and proper use, read all safety information before using the device. Only use with manufacturer-approved batteries, chargers, accessories, and supplies.</p> <ul style="list-style-type: none"> THIS DEVICE IS NOT A TOY, do NOT allow children or pets to use or play with this device. Do not disassemble, modify, or repair the device. Do not expose the unit to extreme temperatures (heat or cold), open flames, humid, or wet conditions. Do not submerge in water. Low power may cause poor Bluetooth connection or sound distortion. Do not overcharge battery. If using with a USB adapter, make sure the adapter is not damaged. Do not allow the USB port or the connectors of the supplied USB cable to be exposed to dust, or water, or come into contact with any conductive materials such as liquids, metallic powders, etc. The earbuds & case contain built-in batteries and should not be disposed of with regular household waste. Please consult the local authorities on the correct way to dispose of this device. <p>In the Box</p> <ul style="list-style-type: none"> Wireless Earbuds USB-C Charging Cable Instruction Manual 	<h3>Location of Controls</h3> <p>[Multi] Sensor control: Touch + Hold: Reject incoming call, Power ON/OFF 1x Touch: Pause/resume playback, 1x Touch: Answer/end phone call 2x Touch: Previous/next track 3x Touch: Activate voice assistant 4x Touch: Dial last outgoing number</p> <p> Earbud Charging Contact</p> <p> Case Lid</p> <p> Case Charging LED Indicator</p> <p> Charging Port [Bottom of Case]</p>	<h3>Getting Started</h3> <p>Charging the Case Plug the small connector of the included charging cable into the charging port on the bottom of the case. Plug the large connector into a USB power source such as the USB port on a computer, or into a 5V USB wall adapter (not included).</p> <p>The case LED indicator will flash RED while charging and turn solid RED when fully charged.</p> <p>Charging the Earbuds Make sure the case is charged. To charge the earbuds, place them in the correct ports in the case. They will automatically begin charging. The earbuds' LED indicators will turn RED while charging and turn WHITE when fully charged and then turn off after 30 seconds.</p> <p></p> <p>Note: A tone will be heard when the earbuds are low on battery. Please recharge when this happens.</p>	<p>Powering ON/OFF</p> <ul style="list-style-type: none"> The earbuds will automatically power ON when removed from the case, and power OFF when replaced into the case. The earbuds can also be powered ON/OFF by pressing + holding the Multi buttons. When powered ON, will automatically pair to each other. The pair may automatically reconnect to the device they were most recently paired to, so long as that device is within connection range (30 ft.) and Bluetooth is enabled. The earbuds will automatically power OFF if they have not paired to a Bluetooth device after 2 minutes. <p>Bluetooth Pairing</p> <ol style="list-style-type: none"> Power the earbuds ON. Both of their LED indicators will quickly flash white. After a moment, a voice will be heard on the earbuds indicating that they have paired to each other. The LED indicator on the main earbud will quickly flash white, and the LED indicator on the secondary earbud will slowly flash WHITE. Set your mobile device to search for Bluetooth devices. When it appears, select HKTWSDON from the list of found devices. Once successfully paired, a tone will be heard, and the LED indicator will slowly flash white on both earbuds. <p>Playback Playback will be controlled from your paired device, or the controls listed below.</p> <ul style="list-style-type: none"> 1x Press either Multi button to pause playback. Press again to resume. 2x press either Multi button to skip to the previous track. 3x press either Multi button to skip to the next track. <p>Phone Calls When paired to a phone via Bluetooth, you can control phone functions using the controls listed below.</p> <ul style="list-style-type: none"> 1x Press either Multi button to answer an incoming phone call. 1x Press either Multi button to end a call. 3x Press + hold either Multi button to reject an incoming phone call.
--	--	---	---