



QUICK SETUP GUIDE

Slim Locator Card 2-Pack for iOS

NS-TAGSLIM2PK , RHK116 , NS-TAGSLIM ,
NS-TAGSLIM4PK

PACKAGE CONTENTS

- Slim locator card (2)
- Lanyard (2)
- Quick Setup Guide

PMN: NS-TAGSLIM2PK, NS-TAGSLIM, NS-TAGSLIM4PK, RHK116
Before using your new product, please read these instructions to prevent any damage.


FEATURES

- Compatible with Find My app
- Bluetooth technology helps you find lost backpacks, purses, and more
- Small, lightweight design with lanyard can easily be carried around
- Audible notification alerts you when in range of your missing item
- Operating range works within 65 ft. (19.81 m.) indoors and up to 164 ft. (49.98 m) outdoors

COMPATIBILITY

- Works with Find My app.
- Works with iPhone/iPad iOS 14.5 or newer and macOS 12.5 or newer

OVERVIEW



SETTING UP YOUR SLIM LOCATOR CARD

- 1 On your smartphone or tablet:
 - Turn on Bluetooth.
 - Turn on location by tapping **Settings > Privacy & Security**, then turn on **Location Services**.
- 2 Swipe down and tap **Find My** to allow access to the location, then turn on **Precise Location**.

USING YOUR SLIM LOCATOR CARD FOR THE FIRST TIME

Initially you need to pair your slim locator card with your smartphone or tablet.

- 1 Press the power button on your slim locator card briefly until you hear the beep indicating your card is in pairing mode.
- 2 Open the **Find My** app, tap **Add Item**, then choose **Other Supported Item**.
- 3 When **Insignia Slim Locator** appears on the list, tap **Connect** and follow the on-screen instructions to complete the setup.

TURNING OFF YOUR SLIM LOCATOR CARD

If you don't plan to use your slim locator card for an extended period, you should turn it off to conserve the battery.

- 1 Press and hold the power button for three seconds to switch your slim locator to power off.
- 2 To turn it back on, click the power button.

SETTING UP “LOST MODE”

To mark an item as lost when the slim locator card is out of range from the owner, you need to turn on the **Lost Mode**.

- 1 Open the **Find My** app,
- 2 Click **Items** at the bottom of the screen, then click the name of the lost item.
- 3 Under **Lost Mode**, click **Enable**. Follow the instructions on the screen and enter a phone number where you can be contacted. To enter an email address instead, click **Use Email Address**. Then click **Enable**.

Note: Make sure to allow notifications from the Apple **Find My** app.

VIEWING YOUR SLIM LOCATOR CARD ON THE MAP


- 1 Open the **Find My** app, then click the **Items** tab.
- 2 Select the **Insignia Slim Locator** you want to locate in the **Items** list.
- 3 If the slim locator card is within range of your device or the Apple **Find My** network has detected it recently, you can see it on the map. The updated location and time-stamp will be shown under its name.
- 4 If the slim locator card is out of range of your device or any devices in the Apple **Find My** network, you can see its last known location and time. To receive notifications when your slim locator card is within range of your device or detected by the Apple **Find My** network, turn on **Notify When Found** under **Notifications**.

PLAYING SOUND

- 1 Open the **Find My** app on your iPhone, iPad, or MacBook, then click the **Items** tab.
- 2 In the **Items** list, select the **Insignia Slim Locator** you want to play a sound.
- 3 Click **Play Sound**. If your slim locator card is within range of the Bluetooth signal, it will play a sound.
- 4 To stop this sound before your slim locator card stops automatically, you click **Stop Sound**.


LOCATING YOUR ITEM

The location-tracking feature operates automatically. The Find My app records the last known location where the item was detected.



FINDING YOUR ITEM

Click the item on your Apple Find My APP list. It will show you the last known location.



RESETTING YOUR SLIM LOCATOR CARD

- 1 Briefly press the button twice, holding it down on the second press for five seconds, then wait until you hear two beeps to confirm that the reset was successful. The Tag can now be paired again.
- 2 If the **Insignia Slim Locator** does not appear on the list, make sure that it is powered on, and place it close to the device you want to connect to. Then try to connect again.
- 3 The slim locator card can only be used on one Apple device at a time. If you want to add it to a new device you must remove it from the current device.

DETECTING UNWANTED PAIRING

- 1 If any tag or other Find My network accessory product is left far away from its owners and moved with you for a period of time, it can send a notification to your Apple device through the Find My app.
- 2 These features are purposely built to prevent unknowing attempts to locate you, and if you feel your safety has been threatened, contact local law enforcement.

This product has included the function of preventing unauthorized locating by others. It should not be used to locate people and property that does not belong to you. In many countries and regions around the world, it is a crime to use these products to locate someone without their consent.

SAFETY INFORMATION

- ⚠ WARNING**
1. Do not dismantlke or modify the product.
 2. Do not store the product in wet conditions.
 3. Do not use the product near heat sources.
 4. Do not let water or any other liquid flow into the inside part of the product's interface. This would cause damage to the product.
 5. Avoid direct sunlight.
 6. Keep away from children and pets to prevent accidental ingestion.
 7. Stop using the product if overheating occurs.
 8. Use a dry soft cloth to clean the surface of the product and avoid using harsh chemicals or strong detergents.

SPECIFICATIONS

- **Dimensions:** 3.34 × 2.11 × .12 in. (85.8 × 53.6 × 3.00 mm)
- **Weight:** .56 oz. (16 g)
- **Bluetooth:** BLE 5.1
- **Battery:** CR2032 / 225 mAh

LEGAL NOTICES

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Shielded cables must be used with this unit to ensure compliance with the Class B FCC limits.ISED Caution:Radio Standards Specification RSS-Gen, issue 5- English:This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:This device may not cause interference.This device must accept any interference, including interference that may cause undesired operation of the device. RF exposure statement:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

- French:Cet appareil contient des Émetteurs / récepteurs exemptés de licence conformes aux RSS (RSS) d'Innovation, Sciences et Développement Économique Canada. Le fonctionnement est soumis aux deux conditions suivantes:Cet appareil ne doit pas causer d'interférences.Cet appareil doit accepter toutes les interférences, y compris celles susceptibles de provoquer un fonctionnement indésirable de l'appareil. Déclaration d'exposition RF: L'appareil a été évalué pour répondre aux exigences générales d'exposition aux RF. L'appareil peut être utilisé dans des conditions d'exposition portable sans restriction.

ONE-YEAR LIMITED WARRANTY

Visit www.insigniaproducts.com for details.

CONTACT INSIGNIA:

For customer service, call 1-877-467-4289 (U.S. and Canada)

www.insigniaproducts.com



To use the Apple Find My app to locate this item, the latest version of iOS, iPadOS, or macOS is recommended.

The Find items app on Apple Watch requires the latest version of watchOS.

Use of the Works with Apple badge means that a product has been designed to work specifically with the technology identified in the badge and has been certified by the product manufacturer to meet Apple Find My network product specifications and requirements. Apple is not responsible for the operation of this device or use of this product or its compliance with safety and regulatory standards.

Apple, Apple Find My, Apple Watch, Find My, iPhone, iPad, iPadOS, Mac, macOS and watchOS are trademarks of Apple Inc. IOS is a trademark or registered trademark of Cisco in the U.S. and other countries and is used under license.

INSIGNIA is a trademark of Best Buy and its affiliated companies.

Distributed by Best Buy Purchasing, LLC

Richfield, MN 55423

©2026 Best Buy. All rights reserved.

V1 ENGLISH 26-0228