

成品尺寸：70x100mm 80g书纸 单色印刷 风琴折

HEAR BETTER SOUNDS sanag M15 便携式蓝牙音箱 使用指南 Operating guide	● 包装清单 音箱×1 说明书×1 Type-C充电线×1 保修卡×1	● 产品概述 Type-C充电口 模式切换键 音量+键 开/关机 播放/暂停复合键 音量-键 ● 按键功能操作 开机（长按1S）/ 关机（长按3S） 播放 / 暂停 / 接听 / 挂断（单击） FM模式频道搜索（单击） 启动手机语音助手（不打开APP状态下 双击） — 上一曲（长按）/ 减音量（短按） + 下一曲（长按）/ 加音量（短按） 拒接（长按2S） 切换蓝牙 / FM模式（长按3S） 灯光模式切换 / 打开和关闭灯效（双击） 复位（开机状态下 长按8S） + — 清除配对（开机状态下 长按“音量+”8S）
--	--	--

FCC Warning Statement:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

The device has been evaluated to meet general RF exposure requirement.