
AIR PURIFIER

USER MANUAL

- High Clean Air Delivery Rate
- 3-Stage Filtration System
- Low Noise Level
- Child Lock



Model: KJ102

CUSTOMER SERVICE

Our customer service team is standing by to assist you if you have any questions or concerns.

www.mookashops.com

support@mookashops.com

1-855-666-9955

m.me/MookaOnlineShop

CONTENT

SAFETY INFORMATION ---------- 01

PRODUCT OVERVIEW ---------- 04

ABOUT THE FILTER ---------- 05

OPERATING INSTRUCTIONS ---------- 06

BEFORE OPERATING THE AIR PURIFIER ---------- 07

OPERATING THE AIR PURIFIER ---------- 08

INSTALLING & REMOVING FILTERS ---------- 10

ADD ESSENTIAL OIL ---------- 11

CLEANING & MAINTAINING ---------- 12

TROUBLESHOOTING ---------- 13

SAFETY INFORMATION

READ AND SAVE THESE INSTRUCTIONS

WARNING

Failure to comply with the warnings listed below may result in electric shock or serious injury.

This product should be used only in accordance with the specifications outlined in this manual. Usage other than what has been specified here may result in serious injury.

1) The appliance is not to be used by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction(IEC). Children should be supervised to ensure they do not play with the appliance (IEC).

2) This appliance can be used by children aged 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved(EN). Children shall not play with the appliance(EN). Cleaning and user maintenance shall not be made by children without supervision(EN).

3)When using electrical appliances, basic precautions should always be followed to reduce the risk of fire, electric shock and injury to persons, including the following:

SAFETY INFORMATION

Read all instructions before using the appliance.

1. To avoid fire or shock hazards, plug the appliance into a proper AC electrical outlet.

2. Keep the cord out of heavy traffic areas where it will not be tripped over. To avoid a fire hazard, NEVER put the cord under rugs, near heat registers, radiators, stoves, or heaters.

3. To protect against electrical hazards, DO NOT immerse in water or other liquids. Do not use near water.

4. Children may not recognize the hazards associated with the use of electrical appliances. For this reason, always supervise children when they are near the unit.

5. Always unplug the air purifier when moving it, opening the filter cover, changing filters, cleaning, troubleshooting, or whenever the air purifier is not in use.

6. NEVER drop or insert any object into any openings.

7. DO NOT cover the cord with throw rugs, runners, or similar coverings.

8. DO NOT operate any appliance with a damaged adapter, if the motor fan fails to rotate, after the appliance malfunctions, or if it has been dropped or damaged in any manner. Contact Customer Service for assistance.

9. DO NOT use outdoors.

10. DO NOT place anything on top of the unit.

11. The appliance is only to be used with the power adapter provided.

12. NEVER block the air inlet/outlets or place on a soft surface such as a bed or sofa, as this could cause the unit to tip over, blocking the air intake or outtake opening.

13. Use the appliance only for its intended household use as described in this manual. Any other use not recommended by the manufacturer may cause fire, electric shock, or injury to persons.

SAFETY INFORMATION


WARNING: To avoid the risk of fire or electric shock:

DO NOT use this unit with any solid-state speed control device.

DO NOT use replacement parts that have not been recommended by the manufacturer (e.g., parts made at home using a 3D printer).

DO NOT attempt to repair or adjust any electrical or mechanical functions on this unit. Doing so will void your warranty. The inside of the unit contains no user-serviceable parts. All servicing should be performed by qualified personnel only.

PRODUCT OVERVIEW





Attention:

If product is damaged or missing any parts, please contact the customer service. **DO NOT** return the damaged unit to Amazon, as it may be resold.

ABOUT THE FILTER


3 Stage Filter





OPERATING INSTRUCTIONS

CONTROL PANEL



PACKAGE CONTENTS	SPECIFICATIONS	
1 * Air Purifier	Model No.:	KJ102
1* HEPA Filter (Pre-Installed)	Rated Voltage:	DC12V
1* User Manual	Rated Power:	12W
1* Power Adapter	Weight:	4.6 lb
	Dimensions:	9.25 * 5.12 * 11.8 in.

BEFORE OPERATING THE AIR PURIFIER

1. Carefully lift your air purifier from box and **remove the two plastic bags** for wrapping unit and filter.


2. Select a firm, level and flat location for the air purifier.

*For proper air flow, locate the unit at least 1 foot from any wall or furniture.

*Make sure the air inlet is not blocked.


3. Plug the supplied power adaptor into a right voltage AC outlet.

❶




Open the filter cover.

❷




Take out the filter from the air purifier.

❸



Remove the packaging bag from the filter and insert it into the unit.

❹



Put the filter cover back into the air purifier.

OPERATING THE AIR PURIFIER



POWER BUTTON

Press this button to turn on/ off the unit.



SPEED BUTTON

Press the button each time to select (sleep mode),
1 (Low), 2 (Medium) and 3 (High) speed.

Under SLEEP mode, all the lights (except sleep and power indicator) will turn off and unit working in sleep speed.



TIMER BUTTON

Cycle through timer options by press this button, the purifier can be timed to operate for 2, 4, 6, 8 hours.



NIGHT LIGHT BUTTON

Press this button to turn on / off the night light mode.

OPERATING THE AIR PURIFIER



FILTER RESET

The filter should be replaced every 3-6 months.

"  " indicator flashes when the filter replacement is needed.

After the filter has been replaced, press and hold the  button for 3 seconds to reset the filter lifetime counter.



CHILD LOCK MODE

Long press  button for 3 S to enter or exit the child lock mode.

IMPORTANT NOTE:

When the unit is not in use, please switch it off and unplug it.

INSTALLING & REMOVING FILTERS

FILTER REPLACE INDICATOR

The filter lifetime counter has been set to 1440 hours.

The FILTER RESET indicator lights up when the filter replacement is needed. Follow the instruction below to change filter and reset the program.

1. Open the filter cover.
2. Take out the old filter from the air purifier.
3. Remove the packaging bag from the new filter and insert it into the unit.
4. Put the filter cover back into the air purifier.
5. Press and hold the button for 3 seconds to reset the filter lifetime counter.


ADD ESSENTIAL OIL


To fresh your home, you can add essential oil.

1. Use your finger to press the aroma cover to open it.

2. Add 4-6 drops of essential to the aroma pad.

3. Flip the aroma cover down and press to lock it.





CLEANING & MAINTAINING

⚠ WARNING

Unplug or disconnect the appliance from the power supply before cleaning.

Cleaning the Air Purifier

Wipe the outside of the air purifier with a soft, dry cloth. If necessary, use a slightly damp cloth to wipe the surface, then dry it thoroughly. Do not clean with abrasive chemicals or flammable cleaning agents.

Cleaning the Pre-Filter

The Pre-Filter should be cleaned once a month to increase efficiency and extend. the life of your filter.

1. Remove the filter from the air purifier and clean the Pre-Filter with a soft brush or vacuum hose to remove hair, dust, and large particles.

2. Carefully peel the Pre-Filter away from the HEPA and Activated Carbon Filters.

3. Gently wash the Pre-Filter under running water. Dry completely before placing it back on the velcro tape. (Tip: Please do not use water to clean the HEPA filter.)

4. Replace filter in the air purifier.

TROUBLESHOOTING

If the appliance does not work properly, please check the most common problems you could encounter in the table below.

Problem	Possible solution
No power adapter	If you do not find the adapter inside the package, please contact customer support.
The appliance does not work	Please check if the power cord is plugged into the socket properly.
	Check to see if the power adapter is damaged. If it is, stop using the air purifier and contact customer support.
	Plug the air purifier into a different outlet.If still not working, please contact the customer support.
	The air purifier may be malfunctioning. Contact the customer support.
Odor cannot be removed.	Check if the filter is installed properly. Please ventilate the operating area before purifying.
	Switch to high speed and run the air purifier continuously.
	The filter is dirty. Please replace the filter.
" " is still on after replacing the filter.	Reset the Filter Indicator.

TROUBLESHOOTING

Strange smell coming from the air purifier	Replace the filter if necessary.
	Please replace the new aromatherapy pad.
	Make sure not to use your air purifier in an area with high humidity or while diffusing essential oils.
	Contact the customer support.
The air purifier makes an unusual noise while the fan is on.	Make sure the filter is properly in place with the plastic packaging removed.
	The filter is dirty, please replace the filter.
	The air purifier may be damaged or a foreign object may be inside, please contact customer support.
Poor air purification quality	Tap " " to increase the fan speed.
	Make sure no objects are blocking the sides or top of the air purifier (the inlet or outlet).
	Make sure the filter is removed from its packaging and properly in place.
	Close doors and windows while using the air purifier.
	Replace the filter.
	If the room too larger, air purification will take longer.

Note:

1. To effectively clean air, keep windows and doors closed while the air purifier is on.
2. If your problem is not listed, please contact Customer Support to get the solution firstly.

mooka

Beyond Elegance

www.mookashops.com

support@mookashops.com

1-855-666-9955

m.me/MookaOnlineShop

Intertek

Made in China