

Nothing X app

SCAN QR CODE TO INSTALL
Nothing X app.
請掃描二維碼安裝 Nothing X app.
请扫描二维码安装 Nothing X app.

NOTHING (R)

用戶指南
用户指南

MODEL 型號 型号 : E171

WELCOME

Bluetooth:
Please make sure Bluetooth is turned on.

App:
Get the most out of your Nothing products with the Nothing X app.
Customise EQ and gesture control settings, update firmware, and more.

Replacing ear tips
Choose ear tips in appropriate size for optimal comfort and sound quality.
Check the accessories for ear tips in different sizes.
*Buds arrive with medium size attached.

PAIR

Use with your Android devices (Google Fast Pair)
First time use or new device connection
While the buds are inside the charging case, open the charging case and place it near the Android device for on-screen setup.

Connect to other devices
With the buds in the open case, press the setup button until light blinks.
Then choose them in Bluetooth settings.

OPERATIONS

Press
Music: Play or pause.
Call: Answer or hang up a call.

Double-press
Music: Skip forward.
Call: Reject a call.

Triple-press
Music: Skip back.

Press and hold
Switch between Active Noise Cancellation and Transparency Mode.

More options in Nothing X app.
*Optional functions: play/pause, skip back, skip forward, switch noise cancellation mode, volume up, volume down and wake up voice assistant.

Wearing detection
Wear the buds. During music playback, take them off to pause music automatically. Put the buds back in within 3 minutes, music will resume automatically. If 3 minutes pass, you must play the music manually on the device.

Charging

Earbuds
Put the buds in the charging case and close the case to charge.

Ear case
Close the case and connect the case to a power supply through the power cable delivered with the buds with the buds.

If the indicator lamp of the case is flashing white, the case is charging. If it is always white, the case is fully charged.

Power level indication
White: The battery level is higher than 30%.
Red: The battery level is lower than 30%.

If the buds are placed in the case, the indicator lamp will flash the colour relating to the battery level of the buds, not the case.
Take the left and right bud out. The indicator lamp will flash the colour relating to the battery level of the case.
For Nothing phone users, you can set the widget on the lock screen or check the power status of the device in Quick Settings on the drop-down notification bar.

歡迎

藍牙:
請確認藍牙功能已經開啟。

App:
請配合 Nothing X app 使用以體驗完整的 Nothing 產品功能。App內包含了自訂EQ功能、手勢控制設定以及更新韌體等功能。

更換耳塞
選擇適當大小的耳塞以享受最佳的舒適性和完美的音質體驗。
請在耳機配件中查看不同尺寸的耳塞配件。
*耳機上的預設耳塞為中号耳塞。

配對

搭配您的 Android 裝置 (Google 快速配對)
初次使用及新裝置連接
當耳機在充電盒內時, 請打開充電盒上蓋並靠近 Android 裝置, 可直接在螢幕上進行設定。

連接到其他裝置
當耳機在打開的充電盒裡時, 持續按住設置按鈕直到提示燈燈光閃爍。然後即可於藍牙設置中設定。

操作

按一下控制按鈕
音樂: 播放 / 暫停音訊
通話: 接聽來電 / 掛斷電話

快速輕按兩下控制按鈕
音樂: 跳至下一曲目
通話: 拒接來電

快速輕按三下控制按鈕
音樂: 跳至上一曲目

持續按住控制按鈕
在主動降噪和通透模式之間切換

更多選項請前往 Nothing X app。
*可選擇的功能: 播放/暫停、下一曲目、上一曲目、切換降噪模式、音量升高、音量降低和喚醒語音助理。

佩戴檢測
戴上耳機。在音樂播放時摘下耳機, 耳機會自動暫停音樂播放。3 分鐘內將耳機放回耳內, 音樂會自動恢復播放。如果超過 3 分鐘, 您必須在播放裝置上手動播放音樂。

充電

耳機
將耳機放入充電盒內並且關上充電盒的盒蓋以進行耳機充電。
充電盒
關上充電盒, 並通過產品包裝內隨附的 USB Type-C 連接線將充電盒接上電源進行充電。
充電盒上的指示燈是白燈規律閃爍的狀態時, 表示充電盒正在充電。指示燈處於白色恆亮狀態時, 表示充電盒已經完成充電。

電量指示
白色: 電量高於 30%。
紅色: 電量低於 30%。

• 耳機放入充電盒中時, 指示燈會顯示耳機的電量, 並不會顯示充電盒電量。
• 拿出左&右耳機後, 指示燈會顯示充電盒的電量。
• 如果閣下是 Nothing Phone 的用戶, 可以在手機桌面設定Widget/小工具, 或到下拉式通知列的快速設定中查看耳機的電量狀態。

欢迎

蓝牙:
请确认蓝牙功能已经开启。

App:
请配合 Nothing X app 使用以体验完整的 Nothing 产品功能。App内包含了自定义EQ、手势控制设置以及更新固件等功能。

更換耳塞
请选择合适尺寸的耳塞以获得最佳的舒适度与最佳的音质。
请在耳机配件中查看不同尺寸的耳塞。
*耳机上的预设耳塞为中号耳塞。

配对

搭配您的安卓设备 (支持谷歌快速配对)
初次使用或新设备配对
当耳机在充电盒内时, 请打开充电盒上盖并靠近安卓设备, 按照屏幕提示操作。

连接到其他设备
当耳机在打开的充电盒里时, 长按设置按键直到提示灯灯光闪烁, 然后进入设备的蓝牙设置中进行选择。

操控

按压一次
音乐: 播放 / 暂停
通话: 接听 / 挂断电话

按压两次
音乐: 转到下一曲目
通话: 拒接来电

按压三次
音乐: 返回上一曲目

长按
在主动降噪开与通透模式之间切换

更多选项请前往 Nothing X app。
*可选择的功能: 播放 / 暂停、下一曲目、上一曲目、切换降噪模式、音量增加、音量减小和唤醒语音助手。

佩戴检测
戴上耳机。当音乐播放时, 摘下耳机即可自动暂停音乐。如在摘下3分钟内将耳机放回耳朵, 音乐将会自动恢复播放。如果摘下超过3分钟, 您必须在设备上手动播放音乐。

充电

耳机
将耳机放入充电盒内并关上充电盒的盒盖以进行耳机充电。

充电盒
关上充电盒, 并通过耳机包装内附送的 Type-C 充电线将充电盒连接电源进行充电。
如果充电盒的指示灯是白色闪烁的状态, 表示充电盒正在充电。如果指示灯处于白色常亮状态, 则表明充电盒已经完成充电。

电量指示
白色: 电量高于 30%。
红色: 电量低于 30%。

• 如果将耳机放入充电盒中, 指示灯会示意耳机的电量, 并不会示意充电盒的电量。
• 拿出左 & 右耳机后, 指示灯会示意充电盒的电量。
• 如果您是 Nothing Phone 的用户, 您可以在手机桌面设置小部件, 或在下拉通知栏的快速设置中查看耳机的电量状态。