



Digital Keyring Gauge Instructions

RTG4

- (F) Jauge numérique format porte-clé
- (D) Digitales Schlüsselanhänger-Messgerät
- (I) Calibro digitale portachiavi
- (E) Manómetro digital de llavero
- (P) Medidor digital de porta chaves
- (DK) Digital nøgleringsmåler
- (NL) Digitale meter aan sleutelhanger
- (S) Digital nyckelring mått
- (FIN) LED Ladattava kohdevalo
- (N) Digital nøkkelring måler
- (PL) Cyfrowy ciśnieniomierz do kót - breloczek
- (CZ) Přívěsek na klíče s digitálním měřidlem
- (RO) Breloc manometru digital
- (H) Kulcskarikára akasztható számjegyes mérőeszköz
- (UA) Цифровий брелок-манометр
- (RUS) Цифровой брелок-манометр




Introduction

- F Introduction
- D Einführung
- I Presentazione
- E Introducción

- P Introdução
- DK Introduktion
- NL Inleiding
- S Introduktion

- FIN Johdanto
- N Introduksjon
- PL Wstęp
- CZ Úvod

- RO Introducere
- H Bevezetés
- UA Вступ
- RUS Введение



Control layout

(F) Disposition des commandes

(P) Disposição de controlo

(FIN) Ohjainten asettelu

(RO) Dispunere comenzi

(D) Anordnung der Bedienelemente

(DK) Kontrol opsætning

(N) Kontroll-layout

(H) Vezérlő elrendezés

(I) Layout di comando

(NL) Bedieningslayout

(PL) Rozmieszczenie elementów sterujących


(UA) Улаштування щита управління

(E) Disposición de los controles

(S) Kontrollayout

(CZ) Schéma ovládní

(RUS) Компоновка щита управления



Operation

F Fonctionnement

D Bedienung

I Funzionamento

E Operación

P Operação

DK Drift

NL Bediening

S Drift

FIN Käyttö

N Drift

PL Działanie







CZ Fungování

RO Funcționare

H Működés

UA Експлуатація

RUS Эксплуатация



Battery Replacement

F Batterie de remplacement

D Batteriewechsel

I Sostituzione batteria

E Sustitución de la batería

P Substituição da bateria

DK Batteri udskiftning

NL Batterijvervanging

S Utbyte av batteri

FIN Pariston vaihtaminen

N Batteriveksel

PL Wymiana baterii


CZ Výměna baterie

RO Înlocuire baterii

H Akkumulátorcsere

UA Заміна акумуляторної батареї

RUS Замена аккумуляторной батареи







CE approved



Ring Automotive Limited,
Gelderd Road, Leeds LS12 6NA **England**

 +44 (0)113 213 2000

 +44 (0)113 213 7339

 +44 (0)113 231 0266

 autosales@ringautomotive.co.uk

 www.ringautomotive.co.uk

L440