

70 mm

70 mm

QUICK START GUIDE

USER GUIDE

Please read this user guide carefully before using the camera for the first time.

Safety Instructions

1.This product is a high-precision instrument. Do not drop or bump it.

2.Do not place the product near magnets, motors, or other objects with strong magnetic fields. Keep it away from devices that emit strong radio waves, as magnetic fields and radio waves may cause product malfunction or damage images/audio.

3.Do not expose the product to high temperatures or direct sunlight for extended periods.

4.Use a TF card from a reputable brand. Non-brand cards may not guarantee proper operation.

5.Keep the TF card away from objects with strong magnetism to prevent data loss.

6.Do not disassemble or burn the battery, as this may cause leakage or explosion.

7.Store the product in a cool, dry, dust-free place.

WHAT'S IN THE BOX

Manual

Camera

Expansion Battery

Magnetic Pendant

Magnetic snap-on attachments

USB Cable

Magnetic hat clip

CAMERA STRUCTURE

SPECIFICATIONS

Item	Specification
Lens Module	GC2083 12MP+ 140° wide-angle lens
Wi-Fi Module	2.4G-2.48G, 802.11b/g/n
Battery Capacity	490mAh rechargeable Li-ion battery
Battery Life	2 hours @ 2K30fps (camera only)
Expansion Battery	1300mAh rechargeable Li-ion battery
Battery Life	6 hours @ 2K30fps (with expansion module)
Audio Input	Built-in Single Microphone
Indicator Light	LED Charging/Working Indicator
Interface Type	TYPE-C

Memory Capacity	Supports microSD card up to 256GB (Class 10/U1 or higher)
Working Current	190mA
Charging Voltage	5V/1-2A
Video Resolution	2K30
Video Codec	H.264/H.265 MOV
Video Mode	Normal Recording, Loop Recording
Photo	Supports APP Photo
Distortion Correction	Viipulse app, Android, iOS systems
Timestamp	Manual Setting Supported
Screen Protection	Auto screen off after 1/3/5 mins of no operation

说明书正面

Warning:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

.Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

--Reorient or relocate the receiving antenna.-

--Increase the separation between the equipment and receiver

--Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

--Consult the dealer or an experienced radio/TV technician for help

NOTE: This device and its antenna(s) must not be co-located or operation in conjunction with any other antenna or transmitter

The device has been evaluated to meet general RF exposure requirement. The device

can be used in portable exposure condition without restriction.

BUTTON FUNCTIONS

Button

Long Press: Power On / Off

Short Press (Power On): Start / Stop Recording

Double Press: Turn Wi-Fi On / Off

Power On/Off

Power On: Long press the button. Blue and green lights turn on, then green light stays steady (standby mode).

Power Off: Long press the button. All indicator lights turn off.

Recording

Standby Mode

Status: Green light steady

Start Recording: Short press (Green light flashes)

Stop Recording: Short press again (Green light returns to steady)

SD Card

Locate the TF card slot on the side of the product. Ensure the metal contacts face the correct direction, then gently push in until you hear a "click".

Note: Supports 32GB-512GB TF cards. Format new cards on a computer before first use.

Indicator Lights

Blue light on: Wi-Fi enabled

Green light flashing: Recording

Red light off: Fully charged

Green light on: Standby mode

Red light on: Charging

Note: For more operation instructions, please refer to the following pages

APP FEATURES

APP DOWNLOAD

This product can be connected to smartphones and tablets (Android or iOS systems).

Wi-Fi Setup

Short press the button twice until the blue indicator light stays on. The device enters Wi-Fi connection mode.

Mobile Connection

Connect to Pocket-Pov_*****via phone Wi-Fi,enter password 12345678, then open the App to operate the device.

说明书反面

