


Overview introduction


The device integrates with Apple Find My Network providing a secure and user-friendly solution for finding belongings. Use the Find My network to easily locate wallet, keys, backpacks, suitcases, etc., and prioritize security. Apple Find My Network, experiencing a future of enhanced item finding and peace of mind. Trust it to redefine how you manage essentials effortlessly.

How To Pair


Note: iOS or macOS with the latest version.



(Figure1)



(Figure2)



(Figure3)

- 1.1 Place the device next to your Apple device like iPhone.
- 1.2 Turn on Bluetooth on iPhone and connect to Internet.
- 1.3 Long press the Find My button for about 2 seconds, hear 1 beep, the device is powered on.
- 1.4 Open the 'Find My' app.
- 1.5 In 'Find My' app, Tap '+', then 'Add Other Item'. As shown in Figure 1.
- 1.6 Once your device is located, tap 'connect'. As shown in Figure 2.
- 1.7 Enter a name and choose an emoji. As shown in Figure 3 and tap 'Continue'.
- 1.8 Find My app will ask for confirmation to add your device to your Apple ID. Tap 'Agree'.
- 1.9 Tap 'Finish' and it will be set up and ready to be used.

Battery

The device contains a coin shaped battery. During the product's lifespan, it may be necessary to replace the battery. By observing the correct negative and positive connections, only replace batteries of the same type (CR2032) and rating.

Battery replacement

- 2.1 Rotate the back cover counterclockwise
- 2.2 Pry off the back cover.
- 2.3 Replace a new battery.
- 2.4 Close back cover.

Additional Tips

- 3.1 To switch from working mode to disabled mode (airplane mode), simply press and hold the Find My button until you hear 1 tone, then 2 consecutive tones, and then 3 consecutive tones to shut down.
- 3.2 To switch from disabled mode (airplane mode) to working mode, turn it on again. After this, the devices will be paired successfully.
- 3.3 Press and hold the Find my button until you hear 1 tone, then 2 consecutive tones, and then 3 consecutive tones. Keep pressing for 5 seconds. After the long beep ends,

release the button and the device will return to factory settings.

3.4 To remove the device from your Apple devices, open the Find My app, select ' items ', Click on the item you want to remove, then scroll down and click Remove Item.

3.5 If the device fails to connect to the ' Find My ' app, follow the instructions in section 3.3 to perform a factory reset, and then restart the pairing process.

Important matters

The device contains precise electronic components, including batteries. To avoid damage, loss of function or potential injury, please avoid dropping, impact, puncture, crushing, disassembly, exposure to high temperatures or liquids, or placing it in areas with high concentrations of industrial chemicals.



WARNING: Do not swallow the battery; There is a chemical burn hazard.

Choking Hazard Warning

The device, its battery compartment door, battery, and outer casing may pose a choking hazard or cause injury to young children. Keep these items out of the reach of small children.

Medical Device Interference

The device contains components and radios that emit electromagnetic fields. These may potentially interfere with pacemakers or other medical devices. For safety, maintain a safe distance between this device and your medical device. We strongly recommend consulting your doctor and the manufacturer of your medical device for information specific to your situation. If you suspect this device is interfering with your pacemaker or any other medical device, stop using it immediately.

Important Handling Guidelines

Discoloration of the device with regular use is normal. To clean it, use a soft, dry, lint-free cloth. Avoid applying pressure to the rubber seals inside the device or the battery terminal contacts with sharp objects.

Do not allow moisture to enter any openings in the device, and do not use aerosols, solvents, or abrasive materials to clean the device.

Legal notice

Use of the Works with Apple badge means that a product has been designed to work specifically with the technology identified in the badge and has been certified by the product manufacturer to meet Apple Find My network product specifications and requirements. Apple is not responsible for the operation of this device or use of this product or its compliance with safety and regulatory standards.

Apple, Apple Find My, Apple Watch, Find My, iPhone, iPad, iPadOS, Mac, macOS and watchOS are the trademarks of Apple Inc. IOS is a trademark or registered trademark of Cisco in the U.S. and other countries and is used under license.

概述介绍

此设备与苹果的 Find My 网络集成，为追踪物品提供了一个安全且对用户友好的解决方案。使用 Find My 网络轻松定位钱包、钥匙、背包、行李箱等物品，并优先考虑安全性。使用此设备和苹果的 Find My 网络告别丢失物品，体验增强物品防丢和安心的生活方式。相信它可以重新定义您轻松管理物品。

如何配对

注：建议使用 iOS 或 macOS 最新版本。



(图 1)



(图 2)



(图 3)

- 1.1 将此设备放在您的苹果设备（如 iPhone）旁边；
- 1.2 在您的苹果设备（如 iPhone）上打开蓝牙并连接到互联网；
- 1.3 长按 Find My 按键约 2 秒，听到 1 声提示音，此时设备开机；
- 1.4 打开“查找”应用程序；
- 1.5 在“查找”应用程序中，点击添加物品-其他支持物品。如图 1 所示；
- 1.6 搜索到设备后，点击“连接”。如图 2 所示；
- 1.7 命名您的设备并选择一个表情包。如图 3 所示,点击“继续”；
- 1.8 “查找”应用程序询问是否添加此设备到 Apple ID 上，点击同意；
- 1.9 点击“完成”，即可完成配对。

电池

此设备包含一个硬币形状的电池。在产品使用寿命期间，可能需要更换电池。通过观察正确的负极和正极连接，只能更换相同型号（CR2032）和额定值的电池。

替换电池

- 2.1 逆时针旋转后盖。
- 2.2 撬开后盖。
- 2.3 换上新电池。
- 2.4 关上后盖。

其他提示

- 3.1 要从工作模式切换到禁用模式（飞行模式），只需按住 Find My 按键，直到听到 1 个提示音，然后是 2 个连续提示音，再是 3 个连续提示音关机即可。

- 3.2 要从禁用模式（飞行模式）切换到工作模式，请重新开机。在此之后，设备将成功配对。
- 3.3 按住 Find My 按键，直到听到 1 个提示音，然后是 2 个连续提示音，再是 3 个连续提示音。继续按 5s 左右。长提示音结束后，松开按钮设备将恢复到出厂设置。
- 3.4 要从您的苹果设备中删除设备，请打开“查找”应用程序，选择“物品”，点击需要移除的物品，然后向下滚动点击“移除物品”。
- 3.5 如果此设备无法连接到 Find My 应用程序，请按照第 3.3 中的说明，执行恢复出厂重置，然后重新启动配对过程。

重要事项

本设备包含精密的电子部件，包括电池。为避免损坏、功能丧失或潜在伤害，请避免跌落、撞击、刺穿、压碎、拆卸、暴露在高温或液体中，或将其放置在工业化学品浓度高的区域。



警告：请勿吞下电池；存在化学灼伤危险

窒息风险警告

本设备、其电池仓盖、电池本身及外壳可能会对幼儿造成窒息风险或伤害。请将这些物品放在幼儿接触不到的地方。

医疗设备干扰提示

本设备包含会发射电磁场的组件和无线电装置，可能对心脏起搏器或其他医疗设备产生干扰。为安全起见，请在本设备与您的医疗设备之间保持安全距离。我们强烈建议您咨询医生及医疗设备制造商，了解与您具体情况相关的信息。若怀疑本设备干扰了您的心脏起搏器或其他医疗设备，请立即停止使用。

重要使用与保养指南

设备经日常使用后出现褪色属于正常现象。清洁时，请使用柔软、干燥、无绒布。请勿用尖锐物体按压设备内部的橡胶密封圈或电池端子触点。

请勿让水分进入设备的任何开口处，且请勿使用气雾剂、溶剂或研磨性材料清洁设备。

法律公告

使用带有 Apple 徽标的作品意味着该产品已被设计为专门用于徽标中所标识的技术，并已通过产品制造商的认证，以满足 Apple Find My network 产品规格和要求。Apple 不对本设备的操作或本产品的使用或其是否符合安全和监管标准负责。

Apple、Apple Find My、Apple Watch、Find My、iPhone、iPad、iPadOS、Mac、macOS 和 watchOS 均为苹果公司的商标。IOS 是思科在美国和其他国家的商标或注册商标，并在许可下使用。

FCC Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

RF Exposure Information

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.