

car navigation – User Guide– VNT-T10

Welcome to the VANTAGE Experience This guide will help you quickly set up the device and start enjoying your game with advanced GPS, food ordering, and entertainment features.






Table of Contents


Getting Started & Setup.....	1
Understanding the Interface.....	3
On the Course: GPS & Hole View.....	4
Food & Beverage Ordering.....	5
Bluetooth Audio Setup.....	7
Course Selection.....	8
Warnings & Safety Alerts.....	9
Marshal Features (Restricted Settings).....	10

Getting Started & Setup

Power On and Connection Upon the first boot of the device, the system needs to pair with the course system.

Authorization: You may see a screen stating "This device is unauthenticated."

Tap **Send Connection Request** to pair with the web platform.




Getting Started & Setup

Map Update: The application will automatically update the map with the latest course information. Please wait while the map updates.

1



2



Start Your Round: Once the "Welcome to [Club Name]" screen appears, simply tap the Start button or move the cart to launch into Golfing Mode.

Understanding the Interface

Main Menu & Controls When Golfing Mode is active, the Home Screen serves as your central hub.

Hole Selection: Tap any number (1-18) on the map to enter the specific Hole View.

Bottom Navigation Bar:

-  **Home:** Return to the main map.
-  **Dining (Fork & Knife):** Access Food & Beverage ordering.
-  **Music (Note Icon):** Open Bluetooth pairing settings.
-  **Course (Grid Icon):** Select different course loops (e.g., Highland, Parkland).
-  **Settings (Gear Icon):** Access Restricted/Marshal settings (Requires PIN).



On the Course: GPS & Hole View

Master Your Game Tap on any hole number or drive to a tee box to view detailed GPS data.



Touching the screen(1) generates 2 distances for the user, Distance to the touched point(2), and distance from the touched point to the target(3)

Food & Beverage Ordering


Order from the Cart Hungry? Order lunch or snacks directly from the tablet.

- 1.**Open Menu:** Tap the Dining icon on the bottom bar.
- 2.**Browse Items:** Filter by "Burgers," "Beverages," or "Snacks."
Select an item (e.g., Spicy Deluxe Crispy Burger) to see details.
- 3.**Add to Cart:** Select quantity and tap Add to Cart.
- 4.**Checkout:** Tap the Cart button in the top right. Review your order total and tap Proceed to Checkout.

Food & Beverage Ordering

Payment

- **Online:** Scan the displayed QR code with your phone to pay immediately.



- **In Person:** Select Pay in Person to settle the bill at the clubhouse.

Bluetooth Audio Setup

Connect Your Music Pair your smartphone to play music or podcasts through the cart's speakers.

1.Open Bluetooth: Tap the Music icon (Note symbol) on the bottom menu.


2.Pair New Device: Ensure your phone is in pairing mode. The tablet will scan for "Available devices".

3.Select Your Device: Tap your phone's name (e.g., "iPhone 14 Pro Max") from the list to connect.


4.Success: The screen will show "The needed device is paired." You can now control audio from your phone.

5.Disconnect: Tap Unpair to disconnect your device.


1



2



3



Course Selection

Switching Courses If your club has multiple courses (e.g., 18 holes vs. 9 holes), tap the **Grid Icon** on the bottom menu. Select the correct course (e.g., Highland, Parkland, or Fairway) to update the map. Note: GPS location usually overrides this selection automatically.

Warnings and Alerts The screen may block your view with important messages:


- **Game Pace Warning (Manual):** If you fall behind schedule, a message will appear: "You are behind the pace... Please, catch up." Tap **OK** to dismiss.
- **No-Go Zone Alert (Automatic):** If you drive into a restricted area, a warning triangle appears: "You have entered a restricted zone. Please go back." This alert clears only when you move back to a safe area.

Warnings and Alerts


Warnings

When using the app, the user may receive messages sent by the connected webplatform. These will block the entire screen until dismissed. These can also show up automatically based on device location.

Warning Message (Manual)



Location Based (Automatic)



Marshal Features (Restricted Settings)

Staff & Maintenance Settings These settings are password-protected for course marshals and staff.

1.Access: Tap the **Settings (Gear)** icon.

2.Login: Enter the 4-digit PIN using the keypad.


3.Available Functions:

- o **Ignore No-Go Zones:** Toggle this ON to drive the cart into restricted areas without stopping or alarms (useful for marshals).
- o **Reset Game Session:** Tap Reset to clear the current round data, hole timers, and cart assignments. This readies the cart for the next player.
- o **Log Out:** Tap Log out in the top right to return to user mode.

Marshal Features (Restricted Settings)


Restricted Settings

Password Entry



The screenshot shows a dark-themed interface for password entry. At the top left is the text "Club name" and at the top right is the time "11:29 AM". In the center, the text "Enter PIN" is displayed above four horizontal dashes representing the PIN input. Below this is a numeric keypad with buttons for digits 1 through 9, 0, a backspace icon (an 'x' in a square), and an "OK" button. At the bottom of the screen is a navigation bar with five icons: a home icon, a fork and knife icon, a music note icon, a grid icon, and a settings icon (a gear) which is highlighted in green.

Settings



The screenshot shows a dark-themed interface for settings. At the top left is the text "Club name" and at the top right is the time "11:29 AM". Below the time is a green "Log out" button with a right-pointing arrow icon. The main content area is titled "Marshal's features" and contains two sections. The first section, "No-go zone setting", has a toggle switch for "Ignoring no-go zones" which is currently turned off; below it is the text "The system will not react to no-go zone violations". The second section, "Game session", has a "Reset" button and contains the text: "By applying this option cart will be ready for new player. No-go zones aren't ignored. Game session, hole and round time, persons and group will be reset. There are currently no started game sessions."

Takes user back to home page



This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.
- This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.