


Dashcam Manual

Three-Channel Camera



Main features



- 【🔌】 On/Off button, long press to switch off/on, short press to turn off/on the screen
- 【↔️】 Up key, short press the front and interior camera screen switching function, the menu interface is up selection, and playback is fast forward
Down arrow key, short press to turn on/off microphone, menu interface for downward selection, fast rewind for playback
- 【M】 Function keys, long press to open the menu, short press to enter the photo/video/playback front inside lens video selection.Long press to delete/unlock under playback interface
- 【OK】 Confirmation key, menu interface short press for confirmation, photo programme short press for photo, video interface short press forVideo on/off playback for play/pause
- 【R】 If the recorder crashes or operates abnormally due to unexpected reasons, press the reset button briefly to enter the POWER OFF state, and then press and hold the 🔌 button to restart the machine

FCC Warning Statement

Any changes or modifications not expressly approved by the party responsible for compliance could void the user’s authority to operate the equipment.

Note : This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instruction, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- - Reorient or relocate the receiving antenna.
- - Increase the separation between the equipment and receiver.
- - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- - Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction

Wi-Fi connectivity and APP control

Download Viidure APP


- Method 1
Scan the QR code to download Viidure APP
- Method 2
You can search for ‘Viidure’ in the Android App Store or iOS App Store and download it



Connect to Viidure APP


Method 1

【↔️】
Long press the up button, wifi on/off,see the right picture.



Method 2

【M】
Long press the Function button and press ↔️ in the menu bar to select WIFI Settings. as shown in Figure 1 on the right. Press OK to enter and select' On or Off' as in Figure 2. Scan mobile phone to download APP Make WIFI connection Input password:12345678



Press and hold 🔌 to call up the left image, 🔌to enter the left image and time setting
Press 🔌 to go to the right image, press 🔌 to set the time, and press 🔌 to confirm.

Record playback, press twice 🔌 to enter the left picture, press 🔌to select the front lens / rear lens screen, press 🔌 key to playback as the right picture, pause to exit.

To format TF card, long press 🔌 to enter the left menu 🔌key to select Format, press 🔌 key as shown in the right picture to confirm formatting TF card.

Press and hold 🔌 to bring up the menu, as in the left figure, 🔌Select cycle photography, 🔌 to confirm, as in the right figure, select cycle time 🔌 Confirm

Installation Precautions

- 1.Please test the rear view camera first, if it works well, then install it (you can ignore if you don't have rear view camera head).
- 2.Switch off the car engine.
- 3.Insert the TF card into the recorder slot.[Note] Please use a high-speed TF card (Class10 or above) with a capacity of not less than 4GB, TF card supports up to 256GB
4. Fix the recorder on the front windscreen of the car through the bracket.
5. Plug the car charger into the cigarette lighter of the car.
[Note] When wiring, lay the charging cable along the door edge and carpet extension under the car.
6. Install the rear camera at the rear of the car, paying attention to the up and down direction. The wires can be buried along the roof laying edge of the car.
[Note] There are two ways to install the rear camera:
A Adsorption on the glass above and behind the car, do-it-yourself installation (Cannot realise the function of reverse vision, only real-time recording of rear video).
- 8 Find a professional installer to install it above the licence plate, the camera needs to be connected to the power reversing light at the same time (it can achieve the reversing visual function).
7. Adjust the lens position to ensure the best viewing angle.
8. Start the engine and check whether the machine is running normally.



FCC Warning Statement: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC Radiation Exposure Statement

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.