

---

# SPL1304 User Manual

2025.10.27  
Revision 1.0

**Confidential Material:** This document contains information that is proprietary and confidential, reading and copying this document is prohibited without permission from AsiaTelco Technologies Co.

---

## List

|   |                      |   |
|---|----------------------|---|
| 1 | Status LED .....     | 3 |
| 2 | Insert battery ..... | 4 |
| 3 | Unlock .....         | 6 |

# 1 Status LED



| Signal Name | Function    | Shipping Mode | Hibernate Mode | Active Mode  |
|-------------|-------------|---------------|----------------|--------------|
| LED_ Green  | Cell LED    | off           | off            | off or blink |
| LED_ Orange | GPS LED     | off           | off            | off or blink |
| LED_ Red    | Lock LED    | off           | off            | off or blink |
| LED_ Yellow | BLE LED     | TBD           | TBD            | TBD          |
|             | Battery LED | off           | off            | off or blink |
| LED_ R/G/B  |             | off           | off            | off or blink |
|             |             | off           | off            | off or blink |



## 2 Insert battery

- A. Remove the screw on the side of the device.
- B. Push the battery latch down and remove the battery cap.
- C. Insert 5# battery into the battery cap. A total of 8 batteries are required.
- D. Press the button inward for 5 seconds. Wait until the LED lights up and then the device will power on.
- E. Lock the screw.





---

### 3 Unlock

- A. Power on the device, the device is in shipping mode, you can use pick up needle to press the following button for about 5s, and the battery led of the device will be on.
- B. Use the RD-ID card to unlock, the Lock led will be flashing on 0.5s, then you can remove the lock on the right side of the device.



---

## Safety Information

FCC Regulations: This device complies with part 15 of the FCC Rules.

Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference
- (2) This device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
  - Increase the separation between the equipment and receiver.
  - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
  - Consult the dealer or an experienced radio/ TV technician for help.
- Changes or modifications not expressly approved by the manufacturer could void the user's authority to operate the equipment.

**FCC RF Radiation Exposure Statement** This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. To comply with FCC RF Exposure compliance requirements, this grant is applicable to only Mobile Configurations.

The antennas used for the transmitter must be installed to provide a separation distance of at least 20cm from all persons and must not be co-located or operating in conjunction with any other antenna or transmitter.