



SCOUT

WIRELESS CLIP SPEAKER

MODEL: CLBT245

USER MANUAL

PLEASE READ ALL INSTRUCTIONS CAREFULLY & RETAIN FOR FUTURE USE

SAFETY INSTRUCTIONS:

Keep the unit away from heat sources, direct sunlight, humidity, water and any other liquids.

Do not operate the unit if it has been exposed to water, moisture or any other liquids to prevent against electric shock, explosion and/or injury to yourself and damage to the unit.

Do not use the unit if it has been dropped or damaged in any way.

Repairs to electrical equipment should only be performed by a qualified electrician. Improper repairs may place the user at serious risk.

Do not use the unit with wet hands.

Do not put objects into any of the openings.

Keep the unit free from dust, lint etc.

Do not use this unit for anything other than its intended use.

Keep the unit out of reach of children.

This product is not a toy. Do not use the handset at excessive volume levels, as damage to hearing may occur.

GETTING STARTED:

Remove the unit from the box. Remove any packaging from the product.

Please retain all packaging until you have checked and counted all the parts and the contents against the parts list.

ACCESSORIES:

Speaker: 1pc / Charging cable: 1pc / User manual: 1pc / Warranty Card: 1pc

HOW TO CONNECT BLUETOOTH:

Turn on the speaker unit and the Bluetooth switch on your mobile or other device and search for the speaker model name **"COLEMAN-CLBT245"** and Pair the device. Once device is paired it will automatically connect when unit is turned on subsequently.

The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc.


Other third-party brands and names are the property of their respective owners .

CHARGING:

Plug the charging cable into the speaker's charging port and connect to the power source.

The red light will be on when the unit is charging and will be off once fully charged.

OPERATION:



Item	Function	Operation
1		Long press: Power ON/OFF; Short press: Play and pause; Short press to search FM channels automatically in FM mode; After open the speaker, double press to turn on the light/ then double press to open SOS lighting mode/then double press to turn off the light; Triple press:Switch modes between BT/USB/AUX/FM.
2		Short press: Next Song in BT mode / next channel in FM mode; Long Press: Volume increase; Double press: TWS function in BT mode.
2		Short press: Previous Song in BT mode / previous channel in FM mode; Long Press: Volume decrease.
3		USB port
4		Type-C charging port

HOW TO USE TRUE WIRELESS STEREO FUNCTION:

If you have 2 units for CLBT245 speakers. Turn on both units, and double press "  " button , you will hear the sound and units will connect with each other automatically . double press "  " button again to cancel TWS connecting.
Note: True wireless stereo function only .

SPECIFICATIONS:

Bluetooth version: 5.3

Output power: 5W

Playtime: 10hrs(50% Volume/ light)

Charging time: 2-3 hrs

Battery capacity: 1500mAh

Distance: 32.8 ft

Signal to noise ratio: 80 dB

Frequency response: 150 Hz-18 kHz

FCC ID : 2AIDL-CLBT245

FCC STATEMENT

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Notes: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. In order to avoid the possibility of exceeding the FCC radio frequency exposure limits, The device has been evaluated to meet general RF exposure requirement.

Migear International Group LLC,
21 W 38th Street, 14th Floor, NY, NY 10018 USA
TEL: 929-390-4504