

4001805

Portable Speaker USER GUIDE

To ensure correct operation and avoid damage, please read this user manual carefully before using this product.


Features:

- 2.0CH portable Bluetooth speaker
- Water resistant IPX5, perfect for beach, poolside, boat and more outdoor activities
- With A2DP Bluetooth, wireless stream music from any Bluetooth-enabled device
- TWS function, achieve true wireless playing with double enhanced stereo sound
- Hands-free Mic for easy picking up the call
- USB support
- Three modes of RGB Lighting
- Line-in function, suitable for PC, MID, TV and other audio devices
- Built-in lithium rechargeable battery CCC 3.7V 2200mAh

Package Contents:

- 1x Portable Bluetooth Speaker
- 1x Type-C Charging cable
- 1x User manual

Product Details:



- ① Type-C Charging Jack
- ② USB Port
- ③ AUX Port
- ④ Backward/Volume Down
- ⑤ Forward/Volume Up
- ⑥ Mic. Hole
- ⑦ Play/Pause
- ⑧ Mode Button
- ⑨ Power Button

Bluetooth Mode:

Power Button: Long-press for Power On/Off.

Activate Bluetooth of mobile phone and pair with the speaker 4001805. If the connection is successful, the blue light stays on steadily. When disconnected, the blue light flashes sharply.

Mode Button: Short-press to switch the function modes, Long-press to pair or disconnect TWS.

Play/Pause: Short-press to play or pause, Long-press to turn the three different light modes and turn it on/off.

When there is a coming call, short press to accept the calling, long press to refuse;

When on calling, short press to end the call, long press to switch from speaker or phone.

Backward/Volume Down: Short-press for volume down, Long-press for last song.

Forward/Volume Up: Short-press for volume up, Long-press for next song.

Short-press **Backward and Forward** Button at the same time to disconnect Bluetooth connection.

TWS Mode:

Turn on 2 identical speakers, both under BT mode.

Select one speaker and Long-press Mode button to pair TWS, the speaker will make a tone to start to pair, and there will be a prompt tone again after paired successfully.

Connect the paired speaker with your phone via Bluetooth and play wirelessly.

Long-press Mode button again to disconnect TWS.

Mode Button: Short-press to switch the function modes, Long-press to pair or disconnect TWS.

Play/Pause: Short-press to play or pause, Long-press to turn the three different light modes and turn it on/off.

Backward/Volume Down: Short-press for volume down, Long-press for last song.

Forward/Volume Up: Short-press for volume up, Long-press for next song.

Short-press **Backward and Forward** Button at the same time to disconnect Bluetooth connection.

USB Playback Mode:

Power Button: Long-press for Power On/Off.

Mode Button: Short-press to switch the function modes.

Play/Pause: Short-press to play or pause, Long-press to turn the three different light modes and turn it on/off.

Backward/Volume Down: Short-press for volume down, Long-press for last song.

Forward/Volume Up: Short-press for volume up, Long-press for next song.

AUX-IN Mode:

Power Button: Long-press for Power On/Off.

Mode Button: Short-press to switch the function modes.

Play/Pause: Short-press to mute the speaker, Long-press to turn the three different light modes and turn it on/off.

Volume Down: Short-press for volume down

Volume Up: Short-press for volume up

Hands-free call:

- Under Bluetooth connection status, if there is an incoming call, user can short-press Play/Pause button to accept the call or long-press Play/Pause button to reject the call.
- During the call, user can long-press Play/Pause button to switch to talking on the phone.
- Short-press Play/Pause button to end the call.

The device will automatically power off after 10 minutes under the following three conditions:

In Bluetooth mode, when no mobile phone is connected. (The auto-off will not activate once a connection is established.)

In USB mode, after the pause button is pressed.

In AUX mode, after the pause button is pressed.

FCC STATEMENT

1. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that

may cause undesired operation.

2. Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

RF warning statement:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

FCC Warning Statement:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

The device has been evaluated to meet general RF exposure requirement.