




SILVERSTONE

Frost Mage 600 PRO

User's Manual




1.Contents

A



Heat Sink

B




Intel Clip

C



Intel Stand-off

D



Intel&AMD Clip

E




Intel Stand-off

F



Intel Screw

G



Intel Backplate

H



AMD Stand-off

I



AMD Screw



J




Thermal Grease

2. INTEL Users-LGA 1851/1700/1200/115X

1



LGA 115X/1200



LGA 1700/1851




Intel Backplate




Intel Stand-off


2



3



4



Intel Clip




Intel Screw




Thermal Grease

5



J


⑥



Heat Sink

A

⑦




3.AMD Users-AM5/AM4

①




AMD Board Screw



AMD Stand-off

②




3



AMD Clip




AMD Screw




Thermal Grease

4




5




Heat Sink

A


6




4. Fan Installation



5. Fan Cable Connection



PWM 4-Pin



Motherboard