



Quick Start Guide

N43_N43BT



In a residential environment, running this equipment may cause Radio jamming.

Parking List



Printer



Power Cord



Quick Start Guide




USB Cable

⚠ Note: the packing materials are actually based on the order.

Appearance and Components

■ Front View


Power Button Feed Button



Cover Open Lever

■ Rear View

Status Indicator




USB Port

■ Inside View

Printing Bracket Module

Moveable Label Guides



Platen

⚠ Note: the views above are for your reference. Ports vary by your choice.

FCC Warning

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:


- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

NOTE 2: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.


FCC ID: 2AUTE-4DT23SE

Loading the Paper

1. Turn the power on, adjust the paper guides to fit the width of paper.




2. Insert the paper into the entry slot. The paper will be inhaled into the path automatically.




Handling Paper Jams


1. Facing the front of the machine, use your right hand to toggle the top cover opening button.




2. Lift up the top cover.



3. After removing the jammed paper from the feed channel, replace it with new paper and discard the wrinkled paper.




4. Remove the stuck paper and proceed with normal operating paper loading.



Connection

Power Connection

①



1. Confirm that the printer power is turned off.
2. Connect the power cord to the printer.
3. Connect the other end of the power cord to a nearby socket.
4. Power on: Press and hold the "power button" for 1 second.
Power off: Long press and hold the "power button" for 3 seconds.

Bluetooth Connection (Only for N43BT)

BT Name: N43BT_**** (The last four digits of the Mac address)

BT Password: 1234

 **Note:** Please refer to the N43BT User Manual for the utility and driver installation.