

User Manual




MAGIC ARM

Phone Stand with Bluetooth Speaker

INDUCTION MODE

- 1 Press and Hold
1) Turn on the speaker by press and hold the "M" button for 2-3 seconds until the display lights up.
- 2 Play music or video on your phone
- 3 Put your phone vertically on our stand, and the sound from your phone will be perfectly amplified



Warm Reminder:

1. In "Induction mode", the phone is not suitable for horizontal placement.
2. Adjust the volume of the phone to more than 50%.
3. Long press the "M" button to switch between "Bluetooth" mode and "Induction mode"

BLUETOOTH MODE

- 1 Press and Hold
1) Turn on the speaker by press and hold the "M" button for 2-3 seconds until the display lights up.
- 2 Long press
2) Long press the "M" button to switch the Bluetooth speaker.
- 3 Look for the Bluetooth name "Magic Arm" in your device's list, then select to pair.
- 4 The phone can be in landscape or portrait orientation


Warm Reminder:

1. In "Bluetooth mode", the phone can be placed horizontally or vertically
2. Long press the "M" button to switch between "Bluetooth" mode and "Induction mode"
3. Warm Reminder: When you turn on the speaker's Bluetooth mode, it will first attempt to connect to the most recently connected device (e.g. mobile phone). If you want to connect a new device, please first "forget" or "ignore" this speaker on the currently connected phone.

STATUS INDICATORS

The display will light up automatically when the speaker is turned on, and you can turn the screen on and off by pressing the "M" button. The on-screen display allows you to check the connection status of the speaker.

Bluetooth status



Light Activity	System State
Blinks "BT"	Ready to connect
Solid "BT"	Connected

SPECIFICATIONS

- 1 Bluetooth Name.....Magic Arm
- 2 Bluetooth Version.....V5.3
- 3 Working Range.....>70ft
- 4 SNR.....>70dB
- 5 Charging Input.....DC 5V/1A
- 6 Battery Capacity.....3.7V 1200mAh
- 7 Item size.....144.5*89.5*55mm
- 8 Item weight.....393g (0.867lb)

BUTTON CONTROLS



Button	What to do	Control
	Press and Hold	Power On/Off; Decline a call
	Short Press	Play/Pause Audio; Answer/End a call
	Double Click	Bluetooth Disconnect/Reconnect
	Press and Hold	Previous Track
	Short Press	Decrease the Volume
	Press and Hold	Switch between Induction or Bluetooth mode
	Short Press	Switch lighting mode
	Double Click	Turn on or off the speaker's screen
	Press and Hold	Next Track
	Short Press	Increase the Volume
	Press and Hold	Setting the alarm clock
	Short Press	Setting the timing
	Double Click	Turn on or off the alarm clock

Note: 1: The previous and next modes of the "+" and "-" buttons can only function in Bluetooth mode


2: The volume on your phone and the volume on the product are not synchronized and need to be adjusted separately.

TIME SETTING INSTRUCTIONS

When your mobile phone is successfully connected to the speaker, the time shown on the speaker's screen will automatically be the same as the time shown on your phone. You can also use the speaker as a clock on its own.

How to set the timing

Short press the "SET" button to set the time. When the digital display flashes, use the "+" and "-" buttons to set the hour. Press the "SET" button again to set the minute. When you have finished, press the "SET" button to exit the setup.




Notes:

When not connected via Bluetooth, the speaker's screen will automatically turn off and the lights will turn off after 15 minutes. This does not happen in induction mode. If not connected to Bluetooth, it cannot be used continuously as a clock.

How to set an alarm clock

Press and hold the "SET" button for 2-3 seconds to set an alarm. You will see a clock and a bell icon flashing on the display. This means that you can set the alarm. (Refer to the timing setting instructions.)



Notes:

-If you have set an alarm, it will still go off at the set time even if the speaker is turned off.

-If you want to use it as an alarm clock for a long time, we recommend that you always use the charger. Make sure you don't switch it off because the battery is low.

Turn off the alarm
Press the "SET" button once to turn off the day's alarm.


Cancel the alarm
Double Click the "SET" button to cancel the alarm.

How to set the alarm to 'snooze'

When you have set the alarm, press any button except the "SET" button. This will put the alarm into 'snooze' mode. You will see the bell icon on the screen flashing slowly. This means that the alarm will go off again every 9 minutes. If no buttons are pressed when the alarm rings, it will automatically turn off after 5 minutes and will not ring again

Reminder: The snooze mode can only be used up to 3 times a day

Charge indicator status



Light Activity	System State
Solid Red	Charging
Light Off	Fully Charged

How to Restore Factory Settings

In Bluetooth mode, press the power button 6 times to restore to factory settings. (The default is induction mode; please long-press the "M" button to switch to Bluetooth mode first).

If the Bluetooth speaker freezes or becomes unresponsive, press and hold the power button for 8 seconds to force a shutdown.