

Project No.		Sales Rep.	Jane.Zhang	Engineer	Sita	Airzeen
Project Name	Airzeen_DC02电子日历	Design View	Outside	Output Date	2026/09/04	

名称：DC02快速指南
材质：封面封底200G铜版纸+内页105G铜版纸
印刷：四色+专色7466C
工艺：覆哑膜，骑马钉
用量：1
公差：+/-公差0.5 mm



pantone 7466C

140mm

190mm




Note: The components with fit-relationship conform to the rules of finished-dimension tolerances and meet the tightness-requirements from customer between these parts simultaneously.										For Prototyping!				05	
														04	
														03	修改1 11页内容--26/9/4--Chai
														02	修改内容, 增加内容--26/7/22--Chai
														01	更换主图和文案--260330 Sita
														00	
														Rev	Ver.1.3

GENERAL TOLERANCE TABLE (Unless otherwise specified) (mm)					Cut Crease V-groove Partial cut Annotation Generic perf Glue on outside Glue on inside Tape on outside Tape on inside	Flute/Grain Direction (Unless otherwise specified)	Drawing No.	Pack Style	Version	Scale	1: 1
Rigid Box	Card board/ plastic sheet/film	Single wall board	Double wall board	mm							
(0~100]											
(100~200]											
(200~300]											
(300~500]											
(6											

Flute/Grain
Direction
(Unless otherwise specified)

Drawing No.			
Pack Style			
Version		Scale	1: 1
Unit	mm		
O.D Assem.			

Airzeen



QUICK START GUIDE

Smart Digital Calendar for Family Schedules

Language

English ----- 01-10

Deutsch ----- 11-20



If you have any problems about the digital calendar, please feel free to contact us:

US: afterserviceUS@airzeen.com

UK: afterserviceUK@airzeen.com

DE: afterserviceDE@Airzeen.com



Please scan the QR code to access the
detailed user manual



VIDEO TUTORIALS

Watch step-by-step videos to help you get the most out of your **Airzeen** Smart Calendar.

SCAN TO WATCH



Calendar Sync Video Guide (Google/iCloud / Outlook · · ·)

How to Add Members for Kids

How to Set Up Your Smart Calendar

How to Create an Event

How to Add a Task

How to Add a Reward

How to Send Photos and Videos

How to Plan Meals

How to Create a List

MORE TUTORIALS & FEATURE UPDATES

Operating Instructions

Welcome! Digital Calendar Frame --Your Family Schedule Assistant!
Just 4 steps to connect your phone to your digital calendar frame. Let's get started.

STEP1: Plug in the Frame

Unbox the frame. Have the frame connected to an AC outlet. The calendar frame will power on.

STEP2: Select Language, Connect to WiFi, Choose City

1. Select the language after power on.
2. Connect to Wi-Fi in the Wi-Fi settings.
3. Select the time zone and adjust the time zone if necessary.

STEP3: Download the 'Whale Framely' App

1. Get your activation code.
Download the 'Whale Framely' app by scanning the QR code or search for "Whale Framely" in the App Store (iOS) or Google Play (Android) to download.

Please note:


DC03: The 21.5-inch devices support 2.4GHz and 5GHz Wi-Fi connections.



Download the Whale Framely APP




2. Create an App Account and fill in all the required information.




STEP4: Scan the QR Code on the Digital Calendar to Start.

After activating your device, you can also invite other users from:
Settings > Members > Invite New Members



Version Update

- For first-time use, please make sure your calendar version is the latest by following the path below:
- Settings → More → Upgrade → click "Check for new version".
- If "No new version" is displayed, your device is already the latest version.



Custom Dashboard Guide

Make your Digital Calendar truly yours with our Custom Dashboard features.

1. Add New Widgets

How to use: Long-press any widget, then tap “Add Widget” .


What it does: Choose from a variety of widgets, like Schedules, Tasks, Meal Reminders, or Rewards.

Size options: Each widget comes in 5 different sizes, so you can arrange your dashboard exactly how you like it.

2. Arrange Your Widgets

How to use: Long-press a widget and drag it to your preferred spot.

What it does: Place your most-used widgets where they are easiest to access, and secondary ones in less prominent areas.




Members

You can create accounts for your family members to manage daily schedules together.


Add members: No email registration required.

Invite new members: For users who want to connect to the app.



Create Rewards

Rewards are a feature that helps motivate kids by making their progress toward goals visible and trackable.






- 1) Members will earn points after completing tasks in the task section. These points will be automatically synced to the member's rewards section.
- 2) When you have collected enough stars, you can redeem our pre-agreed rewards with them! Rewards can be items or special experiences.

Note: Rewards are created by parents on the mobile app, and children can view their rewards and progress on the device.

How to Sync an External Calendar with Your Account

Before syncing the external calendar, ensure your calendar device is paired with the Whale Framely app. Sync operations can only be completed through the app. See the following pictures:



Calendar Sync
Video Guide



Calendar Sync
Troubleshooting Guide



Note: When you sync your external calendar (such as Google, iCloud, etc.) with Whale Framely, any changes made to the source calendar will be automatically updated in the Whale Framely calendar.


Important Notes for Calendar Sync

1. Google Calendar, Outlook Calendar, and iCloud Calendar support two-way sync (changes are updated in both directions). For other calendar apps (such as Cozi), syncing is one-way (from calendar to app).

2. iCloud Sync: If you can't find the "Share Link" option as prompted by the app, make sure calendar permissions are enabled in your iCloud settings. Follow these steps:

- (1) Settings > Your Name > iCloud.
- (2) Tap "See All" (or "Show All"), then select iCloud Calendar.
- (3) Turn "Use on this iPhone".

Note: Screenshots provided are for reference only. The exact layout and options may vary slightly depending on your operating system version, so some features might be located in different places.



Settings

Sleep Mode < Settings - General - Sleep Mode >

Offers a sleep mode, in which the screen turns off to reduce power consumption. The default setting turns off the screen at 20:00 and turns it back on at 08:00. To change this, simply set the start/end time for sleep mode.

Time Zone < Settings - General - Time Zone >

Set the time zone used on the calendar.

Account Protection < Settings - Calendar - Account Protection >

The Account Protection feature safeguards family accounts, preventing accidental deletion by children.

Troubleshooting Guide

1. Unable to sync calendar or photos

- **Check network connection:** Make sure the device is networked and maintains a stable network connection.
- **Check the login account:** Ensure that the device login account is the same as the synchronization account.
- **Update the app:** Make sure you are using the latest version of the app.
- **Regrant synchronization permissions:** Check and regrant synchronization permissions in Settings.

Please note:

If the above methods still fail to sync your calendar, please scan the QR code for more detailed calendar sync solutions.




2. How can I ensure that Google Calendar events sync to Airzeen Digital Calendar?

- When logging into your Google Calendar account in the Whale Framely app, enable data authorization to grant the app access to your Google Calendar data.
- **Android Devices:** After creating a new event in the Google Calendar app, you need to manually tap the "Refresh" button in the sidebar to sync the event to the Airzeen Digital Calendar.
- **iPhone:** Events created on an iPhone are automatically synced to the Airzeen Digital Calendar without additional actions.

3. Does it support syncing events from third-party calendars to Airzeen Digital Calendar?

Google Calendar, Outlook Calendar, and iCloud Calendar support bidirectional syncing with Airzeen Digital Calendar, allowing events from Airzeen Digital Calendar to be synced to Google Calendar and Outlook Calendar, and vice versa. Other calendars only support one-way syncing, meaning they only support syncing events from third-party calendars to Airzeen Calendar.



SCHNELLSTARTANLEITUNG

Intelligenter digitaler Kalender für Familienpläne

Wenn Sie Probleme mit dem digitalen Kalender haben, können Sie sich gerne an uns wenden:



US: afterserviceUS@airzeen.com
DE: afterserviceDE@Airzeen.com

UK: afterserviceUK@airzeen.com



Bitte scannen Sie den QR-Code, um das ausführliche
Benutzerhandbuch aufzurufen.



VIDEO-TUTORIALS

Sehen Sie sich Schritt-für-Schritt-Videos an, um das Beste aus Ihrem **Airzeen** Smart Calendar herauszuholen.

SCAN TO WATCH



Kalendersynchronisations-Videoanleitung (Google/iCloud/Outlook ...)

How to Add Members for Kids

How to Set Up Your Smart Calendar

How to Create an Event

How to Add a Task

How to Add a Reward

How to Send Photos and Videos

How to Plan Meals

How to Create a List

SCANNEN SIE, UM WEITERE TUTORIALS & FUNKTIONSUPDATES ANZUSEHEN

Bedienungsanleitung

Willkommen! Digitaler Kalenderrahmen – Ihr Familienplaner-Assistent!
In nur 4 Schritten verbinden Sie Ihr Telefon mit Ihrem digitalen Kalenderrahmen. Legen wir los.

SCHRITT 1: Rahmen einstecken

Nehmen Sie den Rahmen aus der Verpackung. Schließen Sie ihn an eine Steckdose an. Der Kalenderrahmen wird eingeschaltet.

SCHRITT 2: Sprache auswählen, mit Wi-Fi verbinden, Stadt wählen

1. Wählen Sie nach dem Einschalten die Sprache aus.
2. Verbinden Sie sich in den Wi-Fi-Einstellungen mit einem Netzwerk.
3. Wählen Sie die Zeitzone aus und passen Sie sie bei Bedarf an.

SCHRITT 3: Laden Sie die App „Whale Framely“ herunter

1. Holen Sie sich Ihren Aktivierungscode.
- Laden Sie die App „Whale Framely“ herunter, indem Sie den QR-Code scannen oder im App Store (iOS) oder bei Google Play (Android) nach „Whale Framely“ suchen, um sie zu installieren.

Bitte beachten Sie:


DC03: Die 21,5-Zoll-Geräte unterstützen sowohl 2,4-GHz- auch 5-GHz-WLAN-Verbindungen.



Laden Sie die Whale Framely APP herunter




2. Erstellen Sie ein Konto in der App und machen Sie alle notwendigen Angaben.




Schritt 4: Scannen Sie den QR-Code auf dem Kalender, um zu beginnen.

Nach der Aktivierung Ihres Geräts können Sie auch andere Nutzer einladen über:
Einstellungen > Mitglieder > Neue Mitglieder einladen



Versionsaktualisierung

- Für die erste Verwendung stellen Sie bitte sicher, dass Ihr Kalenderrahmen über die neueste Version verfügt, indem Sie dem folgenden Pfad folgen:
- Einstellungen → Mehr → Aktualisierung → tippen Sie auf „Auf neue Version prüfen“.
- Wird „Keine neue Version“ angezeigt, ist Ihr Gerät bereits auf dem neuesten Stand.



Anleitung zum individuellen Dashboard

Machen Sie Ihren digitalen Kalender mit unseren individuellen Dashboard-Funktionen zu Ihrem ganz eigenen.

1. Neue Widgets hinzufügen

So wird's gemacht: Berühren und halten Sie ein beliebiges Widget, tippen Sie dann auf „Widget hinzufügen“


Was es bewirkt: Wählen Sie aus verschiedenen Widgets wie Zeitpläne, Aufgaben, Essenserinnerungen oder Belohnungen.

Größenoptionen: Jedes Widget ist in 5 verschiedenen Größen verfügbar, sodass Sie Ihr Dashboard genau nach Ihren Wünschen anordnen können.

2. Widgets anordnen

So wird's gemacht: Berühren und halten Sie ein Widget und ziehen Sie es an die gewünschte Stelle.

Was es bewirkt: Platzieren Sie Ihre am häufigsten genutzten Widgets an den am besten zugänglichen Stellen und sekundäre Widgets in weniger auffälligen Bereichen.



Mitglieder

Sie können Konten für Ihre Familienmitglieder erstellen, um gemeinsam den täglichen Terminplan zu verwalten.

Mitglieder hinzufügen: ohne E-Mail-Registrierung.

Neue Mitglieder einladen: für Nutzer, die eine Verbindung zur App herstellen wollen.

☰

Übersicht

Kalender

Aufgaben

Belohnungen

Listen

Mahlzeiten

Fotos

Einstellungen

Allgemein

Kalender

Fotos

Mitglieder

WLAN

Mehr

Mitglieder

David

● >

Jack

● >

Ella

● >

Alice

● >

Mitglieder hinzufügen
Keine E-Mail-Registrierung erforderlich

>

Neue Mitglieder einladen
Whale Framely-Konto erforderlich

>

Mitglieder hinzufügen

Profilfoto

 >

Name

Bitte geben Sie einen Namen ein. >

Farbe


● >

Hinzufügen

DE-15

Belohnungen erstellen

Belohnungen sind eine Funktion, die Kinder motiviert, indem sie ihre Fortschritte auf dem Weg zu ihren Zielen sichtbar und nachvollziehbar macht.






- 1) Mitglieder erhalten Punkte, nachdem sie Aufgaben im Aufgabenbereich abgeschlossen haben. Diese Punkte werden automatisch mit dem Prämienbereich des Mitglieds synchronisiert.
- 2) Wenn Sie genügend Sterne gesammelt haben, können Sie diese gegen unsere vorab vereinbarten Prämien einlösen! Prämien können Gegenstände oder besondere Erlebnisse sein.

Hinweis: Belohnungen werden von den Eltern in der mobilen App erstellt, und Kinder können ihre Belohnungen und Fortschritte auf dem Gerät einsehen.

So synchronisieren Sie einen externen Kalender mit Ihrem Konto

Bevor Sie den externen Kalender synchronisieren, stellen Sie sicher, dass Ihr Kalendergerät mit der Whale Framely-App gekoppelt ist. Synchronisierungsvorgänge können nur über die App durchgeführt werden. Siehe folgende Abbildung:



Kalender-Sync –
Videoanleitung



Kalender-Sync –
Problemlösungen



Hinweis: Wenn Sie Ihren externen Kalender (z. B. Google, Cloud usw.) mit Whale Framely synchronisieren, werden alle Änderungen, die am Quellkalender vorgenommen werden, automatisch im Whale Framely-Kalender aktualisiert.

Wichtige Hinweise zur Kalendersynchronisierung

1. Google Kalender, Outlook Kalender und iCloud Kalender unterstützen die Zwei-Wege-Synchronisierung (Änderungen werden in beide Richtungen aktualisiert). Bei anderen Kalender-Apps (wie Cozi) erfolgt die Synchronisierung nur in eine Richtung (vom Kalender zur App).


2. iCloud-Synchronisierung: Wenn Sie die von der App angezeigte Option „ShareLink“ nicht finden können, stellen Sie sicher, dass die Kalenderberechtigungen in Ihren iCloud-Einstellungen aktiviert sind. Befolgen Sie dazu diese Schritte:

(1) Einstellungen > Ihr Name > iCloud.

(2) Tippen Sie auf „Alle anzeigen“ (oder „Alle einblenden“) und wählen Sie dann „iCloud-Kalender“.

(3) Aktivieren Sie „Auf diesem iPhone verwenden“.

Hinweis: Die Screenshots dienen nur als Referenz. Das genaue Layout und die Optionen können je nach Version Ihres Betriebssystems leicht variieren, sodass einige Funktionen möglicherweise an anderen Stellen zu finden sind.



Einstellungen

Ruhemodus < Einstellungen – Allgemein – Ruhemodus >

Im Ruhemodus schaltet sich der Bildschirm aus, um Strom zu sparen. Standardmäßig wird der Bildschirm um 20:00 Uhr aus- und um 08:00 Uhr wieder eingeschaltet. Um dies zu ändern, legen Sie die Start- und Endzeit für den Ruhemodus fest.

Zeitzone < Einstellungen – Allgemein – Zeitzone >

Legen Sie die Zeitzone fest, die für den Kalender verwendet werden soll.

Kontoschutz < Einstellungen – Kalender – Kontoschutz >

Der Kontoschutz sichert Familienkonten und verhindert versehentliches Löschen durch Kinder.

Fehlerbehebungsanleitung

1. Kalender oder Fotos können nicht synchronisiert werden

- **Netzwerkverbindung überprüfen:** Stellen Sie sicher, dass das Gerät mit dem Netzwerk verbunden ist und eine stabile Netzwerkverbindung aufweist.
- **Anmeldekonto überprüfen:** Stellen Sie sicher, dass das Anmeldekonto des Geräts mit dem Synchronisierungskonto übereinstimmt.
- **App aktualisieren:** Stellen Sie sicher, dass Sie die neueste Version der App verwenden.
- Erteilen Sie die Synchronisierungsberechtigungen erneut: Überprüfen Sie die Synchronisierungsberechtigungen in den Einstellungen und erteilen Sie sie erneut.

Bitte beachten Sie:

Falls die oben genannten Methoden weiterhin nicht zur Synchronisierung Ihres Kalenders führen, scannen Sie bitte den QR-Code, um detailliertere Lösungen zur Kalendersynchronisation zu erhalten.



2. Wie kann ich sicherstellen, dass Google Kalender-Termine mit dem Airzeen Digital Calendar synchronisiert werden?

- Aktivieren Sie beim Einloggen in Ihr Google-Kalender-Konto in der Whale Framely APP die Datenautorisierung, um der App Zugriff auf Ihre Google-Kalender-Daten zu gewähren.
- **Android-Geräte:** Nachdem Sie ein neues Ereignis in der Google Kalender-App erstellt haben, müssen Sie manuell die Schaltfläche „Aktualisieren“ in der Seitenleiste antippen, um das Ereignis mit dem Airzeen Digital Calendar zu synchronisieren.
- **iPhone:** Auf einem iPhone erstellte Ereignisse werden automatisch mit dem Airzeen Digital Calendar synchronisiert – ohne zusätzliche Schritte.

3. Unterstützt es die Synchronisierung von Ereignissen aus Drittanbieter-Kalendern mit dem Airzeen Digital Calendar?

Google Kalender, Outlook Kalender und iCloud Kalender unterstützen die Zwei-Wege-Synchronisierung mit dem Airzeen Digital Calendar, sodass Ereignisse aus dem Airzeen Digital Calendar mit Google Kalender und Outlook Kalender abgeglichen werden können und umgekehrt. Andere Kalender unterstützen nur die Einweg-Synchronisierung, das heißt, sie ermöglichen lediglich die Übertragung von Ereignissen aus Drittanbieter-Kalendern in den Airzeen Calendar.

FCC Caution

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20 cm between the radiator & your body.

Airzeen

Ver.1.3

