
DREO | Pedestal Air Circulator Fan
PolyFan 301

USER MANUAL



Thanks for Choosing DREO!

Your support means the world to us. We hope you enjoy our product as much as we did creating it.

EXTEND YOUR WARRANTY FOR FREE

Scan or visit **dreo.com/warranty**
To extend your warranty for free by registering your product. If you have any product issues, we always stand ready to help.

(888) 290-1688
Mon - Fri, 9:00 am-5:00 pm PST/PDT
support@dreo.com
www.dreo.com

CONTENTS

01 IMPORTANT SAFETY INSTRUCTIONS 1-2

02 ASSEMBLING YOUR PEDESTAL AIR CIRCULATOR 3-4

03 KNOWING YOUR PEDESTAL AIR CIRCULATOR 5

04 USING YOUR PEDESTAL AIR CIRCULATOR 6-8

05 CLEANING AND MAINTENANCE 9-12


06 TROUBLESHOOTING 13

07 DREO CUSTOMER CARE 14-15

IMPORTANT SAFETY INSTRUCTIONS

01

READ ALL CAUTIONARY MARKINGS ON THE APPLIANCE AND SAFETY INSTRUCTIONS IN THE USER MANUAL BEFORE USE.





Do not cover the air inlet and outlet while in operation.

Do not use the air circulator near flammables and combustibles.

General Safety

1. Children shall not play with the appliance. Cleaning and maintenance shall not be performed by children without supervision.
2. Use the appliance as described in the user manual only. Any other use not recommended in the user manual may cause fire, electrical shock, or personal injury.
3. This appliance can be used by children aged above 8 years and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of this appliance in a safe way and understand the hazards involved.

Operation Safety

1. Place the appliance on a flat, dry surface before use.
2. Do not immerse in water and any other liquids.
3. Do not use the appliance until the base is installed.
4. Do not insert your fingers, pencil and any other objects into the grilles under any circumstances.
5. Do not dismantle, repair, or modify. All servicing should be performed by qualified personnel.

Electricity Safety

1. Make sure that the voltage of your electricity supply is the same as that indicated on the appliance.
2. Always unplug before cleaning or leaving the appliance unused for a long period of time. Keep your hands dry when plugging/unplugging.
3. Do not operate any air circulator with a damaged cord or plug. Discard air circulator or return to an authorized service facility for examination and/or repair.

4. Do not run cord under carpeting. Do not cover cord with throw rugs, runners, or similar coverings. Do not route cord under furniture or appliances. Arrange cord away from traffic area and where it will not be tripped over.
5. WARNING: To Reduce The Risk Of Fire, Electric Shock Or Injury To Persons, Do Not Use Replacement Parts That Have Not Been Recommended By The Manufacturer (E.G. Parts Made At Home Using A 3d Printer).
6. WARNING: To Reduce The Risk Of Fire Or Electric Shock, Do Not Use This Air Circulator With Any Solid-state Speed Control Device.
7. Turn off the appliance before plugging.
8. This appliance has a polarized plug (one blade is wider than the other). To reduce the risk of electric shock, this plug is intended to fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Do not attempt to defeat this safety feature.
9. This product employs overload protection (fuse). A blown fuse indicates an overload or short-circuit situation. If the fuse blows, unplug the product from the outlet. Replace the fuse as per the user servicing instructions (follow product marking for proper fuse rating) and check the product. If the replacement fuse blows, a short-circuit may be present and the product should be discarded or returned to an authorized service facility for examination and/or repair.
10. Risk of fire. Do not replace attachment plug. Contains a safety device (fuse, AFCI, LCDI) that should not be removed. Discard product if the attachment plug is damaged.

FOR HOUSEHOLD USE ONLY READ AND SAVE THESE INSTRUCTIONS

Gentle Reminder:



Check the appliance regularly and refer to TROUBLESHOOTING or contact our customer support if it shows any of the following signs:

- Power cord or plug is damaged.
- Loud noise, unusual smell or excessive heat.

Specifications

Model No.	DR-HPF011
Power Supply	AC 120V ~60Hz
Rated Power	50W

ASSEMBLING YOUR PEDESTAL AIR CIRCULATOR


02

Assembly Instructions

When using the appliance for the first time, remove the wraps and attach the parts by following the steps below.


Pedestal Fan Assembly

1




Align and insert the threaded end to the center of the base.

2



Rotate clockwise until it is tightened.


3



Insert the fan body to the column, and rotate clockwise until tightened.


Table Fan Assembly (Optional)

❶




Align and insert the thread end to the center of the base.

❷



Rotate clockwise until it is tightened.



CAUTION


Do not operate the air circulator if the base has not been installed.


Please exercise caution and handle the base with care during installation.

KNOWING YOUR PEDESTAL AIR CIRCULATOR

03

Package Contents






User Manual

Quick Start Guide

USING YOUR PEDESTAL AIR CIRCULATOR 04


Getting the Most out of Your Air Circulator



Summer:

Use with Air Conditioner


Position the air circulator in front of your AC to circulate cold air and provide better cooling.



Winter:

Use with Heater

Send the heat to corner of the room and circulate warm air faster.




Spring & Fall:

Circulation

Make the indoors as fresh and pleasant as the outdoors.


Adding Essential Oils

1




Rotate the aroma pad container counterclockwise to take it off.

2




Add the essential oils to the aroma pad on the aroma pad container.


3



Put the aroma pad container back in place by rotating it clockwise.
(You will hear a “click”.)

General Operations






Tip: You can adjust the airflow vertical direction manually.
(0°/15°/30°/45°/60°/75°/90°)

CLEANING AND MAINTENANCE

05



Outer Surface

Gently wipe off the dust with a soft, dry cloth.

Base

The base can be disassembled in the reverse order of assembly.

Aroma Pad Container & Aroma Pad



Aroma Pad Container



Aroma Pad

Remove the aroma pad container. Take out the aroma pad, clean it with water and dry it up. Put the dried aroma pad back into the aroma pad container, and install back in place.


CAUTION

1. Always unplug the fan before any cleaning or maintenance to avoid the risk of fire, electric shock, or injury to persons.
2. Do not immerse in water or get water inside the motor housing.
3. Do not use any chemical agents when cleaning the fan.
4. Store in a cool, dry place and cover it to protect from dust.
5. It is recommended to disassemble and clean under professional guidance.
6. Clean the aroma pad container and aroma pad before adding new essential oils if it hasn't been used for a long time.
7. Keep the essential oils away from parts other than the aroma pad container (such as the grille or main unit) to avoid damage. If contact occurs, clean immediately or wipe with a dry cloth.

WARNING


To reduce the risk of electrical shock and injury to persons, turn off and unplug the appliance before any cleaning and maintenance.

1




Remove the screw on the front and rotate counterclockwise to remove the grille.

2




Remove the blade cap by rotating it as shown and take the blade assembly out of the shaft.

3




Press and hold both tabs while rotating counterclockwise to remove the rear grille.

4




Rinse cap, blades, and grilles under running water or with a clean, damp cloth.

5




Dry up all parts, and replace the rear grille by aligning the arrow marking with the open lock, then rotate clockwise until it clicks into place.

6



Insert the blade assembly back into the shaft by aligning the D-shaped points on the center.


7



Align the point on the front grille with the right point on the casing, then rotate the grille clockwise and install the screw back in place.

User Servicing Instructions (Fuse)

This appliance features a fused safety plug that protects against overload or short-circuit situations. If the fuse blows, please cut off power and follow the below instructions or consult a qualified electrician.



1. Grasp plug and remove from the receptacle or other outlet device. Do not unplug by pulling on cord.
2. Open fuse cover. Slide open fuse access cover on top of attachment plug towards blades.
3. Remove fuse carefully. Push the fuse from the other side to remove the fuse.
4. Risk of fire. Replace fuse only with 2.5 Amp.125 Volt fuse.
5. Close fuse cover. Slide closed the fuse access cover on top of attachment plug.

WARNING

Risk of fire. Do not replace attachment plug.
Contains a safety device (fuse) that should not be removed.
Discard product if the attachment plug is damaged.

TROUBLESHOOTING 06

My air circulator won't turn on!

Make sure that the cord is connected to a powered outlet and the mains voltage corresponds with the voltage indicated on the air circulator.

My air circulator is shaky and wobbling!

1. Place the air circulator on a flat, level surface.
2. Incorrect installation might also cause shakiness. Please refer to the assembly instructions in page 3-4.

My air circulator is making vibration and noise!

1. Place the air circulator on a flat, level surface.
2. Be sure not to insert anything into the air inlet and outlet.
3. It is normal for the fan to make a little noise when adjusting the fan head manually.

If your problem is not listed or still persists, please contact our Customer Support (see page 15)
View, download, or print the most current version of operation and safety instructions at https://support.dreo.com/en/support/product.

DREO CUSTOMER CARE 07

Default 12-Month Warranty

This appliance is covered by DREO warranty for 12 months from the date of its original purchase.

Extend Your Warranty

Extend your warranty by registering your new appliance on our website **https://dreo.com/warranty.**

The warranty will not apply in cases of:

1. Accident, misuse, or repairs performed by unauthorized personnel.
2. Any unit that has been tampered with or used for commercial purposes.
3. Normal wear and tear of wearable parts.
4. Use of force, damage caused by external influences.
5. Damage caused by non-observance of the User Manual, e.g. connection to an unsuitable mains supply or noncompliance with the instructions.
6. Partially or completely dismantled appliances.
7. Defects caused by or resulting from damages from shipping or from repairs, service, or alteration to the product or any of its parts that have been performed by a repair person not authorized by DREO.

We can only provide after-sales service for products that are sold by DREO or DREO authorized retailers and distributors. If you have purchased the appliance from a different place, please contact your seller for return and warranty issues.

FCC Statment

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Please note that changes or modifications of this product is not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
-Reorient or relocate the receiving antenna.
-Increase the separation between the equipment and receiver.
-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-Consult the dealer or an experienced radio/TV technician for help.

Model No.: DR-HPF011
Rev_1.2_EN

We're Here to Help!

(888) 290-1688 (Mon - Fri, 9:00 am-5:00 pm PST/PDT)
support@dreo.com
www.dreo.com
Shenzhen Hesung Innovation Technology Co., LTD
26F, Bldg A7, Creative City, Shenzhen, China

MADE IN CHINA

www.dreo.com

Looking for help?

Contact us to get expert support.

support@dreo.com (888) 290-1688 www.dreo.com

Mon - Fri, 9:00 am-5:00 pm PST/PDT