




CRWT200

Quick Start Guide

Video Walkie Talkies

Product Overview



7. Mode/Back Button

8. Antenna

9. Camera

10. Display Screen

11. Volume+

12. Volume-

7. Power Switch

8. Microphone

9. Talk Button/OK
Button

10. Charging Port

11. Charging Indicator
Light


12. Lanyard Hole

Precautions


- This product is suitable for outdoor use.
- This device is not waterproof.
- The indoor distance for this product should be such that image does not stutter.

Getting Started

1. Please charge the device to full before operation.
2. Use the included charging cable and connect it to a wall charger (sold separately). The power indicator light will turn red. When fully charged, the charging indicator light will automatically turn off.
3. Turn the power switch to “ON”. The product will turn on automatically and a four-grid menu will appear, which includes Call, Game, Camera, and Gallery.



Main Menu



Button Operation

- Press the Volume+/- buttons to navigate between the following functions: Call, Game, Camera, Gallery.
- Press the Talk Button/OK Button to execute.

Call

- Press the Talk/OK button to select Call.
- The call will begin, and the other walkie-talkie must press the Talk/OK button to accept the call.
- Voice Effects: Press and hold the Mode/Back button to switch voice effects: Normal, High Pitch, Deep Voice & Robot.
- Press the Volume+/- button to increase/decrease volume.
- Press and hold the Talk button to speak.
- Press the Mode/Back button to end the video chat.
- Press and hold the Volume+ button to switch Video window displays.

Game

- Press the Talk/OK button to select Game
- Press the Volume +/- buttons to control the spaceship.
- Press the Menu button to return to the main screen.

Camera

- Press the Talk/OK button to select Camera
- Press the Talk button to take a photo.
- Press the Menu button to return to the main screen.

Gallery

- Press the Volume +/- buttons to navigate, then press the Talk/OK button to preview the image.
- Press the Menu button to return to the main screen

Power On/Off & Automatic Shutdown Function

1. Operation: The device enters working mode upon power-on and will remain operational until manually turned off or the battery is depleted.
2. Low Battery: The device will automatically shut down when the battery is critically low.
3. Manual Shutdown: To stop using the device, please turn the power switch to the “OFF” position.
4. Restart: To restart, turn the power switch to “OFF” and then back to “ON”.

Product Pairing and Connection Method

This product uses a 2.4 GHz wireless connection to communicate directly between the two video walkie talkies. Each package includes two devices that are pre-paired at the factory and are designed to communicate only with each other.

No Wi-Fi®, Bluetooth®, app, or internet connection is required. If multiple sets are purchased, each pair operates independently and cannot communicate with other sets.

Specifications

Screen	2-Inch IPS Screen
Battery Capacity	3.7V 650mAh
Charger	5V/1A
Language	English
USB Port	Type-C®
Operating Temperature	68 °F(20 °C) ~ 140 °F(60 °C)
Storage Temperature	86 °F(30 °C)~158 °F(70 °C)
Power	5V/1A
Product Size	4.9*21*0.9 inches (124*54*23 mm)

Need Help?

For customer support regarding your device, please submit a request by emailing support@dpaudiovideo.zendesk.com. You will be provided a ticket number regarding your inquiry, which you can refer to when contacting us further.

You may also reach a Core Innovations customer service representative by calling 1-833-909-CORE (1-833-909-2673). We are available Monday - Friday, 9am - 5pm PST, except major holidays. Core Innovations strongly urges customers to email their inquiry prior to calling, as this will enable us to better assist you.

Please make sure to note the model number and a description of your inquiry.

Thank you for purchasing a Core Innovations product.

Model Number	CRWT200BW CRWT200BG CRWT200RO
Company Name	DP AUDIO VIDEO LLC
Address	PO Box 24857 Los Angeles, CA 90024
Telephone	1-833-909-2673

FCC Warning

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to

FCC Warning

try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

