



Vulcan MINIJET Spare Parts List

Bonnet #	ITW #	Description
144937	00-977002	1 way solenoid valve, 1 x 10 L/min
145587	00-977003	Drive shaft gasket + wear ring
147792	00-977004	3 way solenoid valve, 2 x 10 L/min + 1 x 5 L/min
166754	00-977005	Heating element after sales kit
300676	00-977006	Reed switch
300698	00-977007	Three-pole 25A 230V 50/60 Hz contactor
300769	00-977008	Anti-interference relay filter
300787	00-977009	Ultra fast fuse 0.2A 250V 5 x 20
300788	00-977010	Fuse 5 x 20 10 Amps
300789	00-977011	1A Temporized fuse
300790	00-977012	Fuse 2 Amps
300791	00-977013	Fuse 0.25 Amps temporized
300793	00-977014	Fuse 10A 10.3x38.1 class cc
301066	00-977015	Safety thermostat
301485	00-977016	1 point regulation probe, PT 100
304295	00-977017	Motor
304296	00-977018	Capacitor 12.5µf
304297	00-977019	Axial fan
305110	00-977020	Reducing gear with centre return spring, 85 degrees
308350	00-977021	Lighting transformer BT 230V 50HZ 12V
308491	00-977022	Transformer
308492	00-977023	Transformer 230V/24V
309407	00-977024	Fuse 3.15 Amps
309634	00-977025	FASTPAD screen card
309638	00-977026	LED strip
309644	00-977027	Coder
309663	00-977028	Output control card
314374	00-977029	Flow meter FHKC56
314379	00-977030	Pump kit
314380	00-977031	Inlet/outlet 1 way solenoid valve, 10 L/min
366461	00-977032	Heating element gasket
366572	00-977033	Door stop
384183	00-977034	Door closure mechanism
384677	00-977035	Door catch sub assembly




384677





309634


309644

VULCAN












145587




304295



366461

166754



305110