Power Bank PP91

10000mAh / 65W

Press to check the power level

Press the button to check the power level.
Indicator on: 20%-100% of power left.
Indicator off: 0%-20% of power left.

Use a suitable USB-C port to smart charge or recharge

Use a suitable USB-C port to smart charge or recharge the power bank. (Use a suitable USB-C port to smart charge or recharge the power bank.)
Input: 5V/3A, 9V/3A, 12V/3A, 15V/3A, 20V/3.25A (MAX 65W)
Output: 5V/3A, 9V/3A, 12V/3A, 15V/3A, 20V/3.25A (MAX 65W)
Indicator on: 20%-100% of power left.
Indicator off: 0%-20% of power left.
Indicator on: 20%-100% of power left.
Indicator off: 0%-20% of power left.

[If Wireless Charging] Use: Illuminate when wireless charging is working. Flash when wireless charging is paused. Flash when there is a foreign object between the surface of transmitter and power bank.

[If Fast Charging] Use: Illuminate when wireless charging is working. Flash when wireless charging is paused. Flash when there is a foreign object between the surface of transmitter and power bank.

[If Wireless Charging] Use: Illuminate when wireless charging is working. Flash when wireless charging is paused. Flash when there is a foreign object between the surface of transmitter and power bank.
[If Fast Charging] Use: Illuminate when wireless charging is working. Flash when wireless charging is paused. Flash when there is a foreign object between the surface of transmitter and power bank.

The optimal charging efficiency is recommended to use a charging cable with a power of 18W or more. Please refer to the actual product.

The optimal charging efficiency is recommended to use a charging cable with a power of 18W or more. Please refer to the actual product.
The optimal charging efficiency is recommended to use a charging cable with a power of 18W or more. Please refer to the actual product.

Note: Place the battery in cooler conditions charging during USB-C Level charging.

Note: Place the battery in cooler conditions charging during USB-C Level charging.
Note: Place the battery in cooler conditions charging during USB-C Level charging.

To wirelessly charge your AirPods, place them and press the power button to activate.

To wirelessly charge your AirPods, place them and press the power button to activate.
To wirelessly charge your AirPods, place them and press the power button to activate.

Specifications

Specifications: Input:5V/3A, 9V/3A, 12V/3A, 15V/3A, 20V/3.25A (MAX 65W) Output:5V/3A, 9V/3A, 12V/3A, 15V/3A, 20V/3.25A (MAX 65W)

Product Name	Power Bank PP91
Model Number	PP91-10000MAH
Battery Capacity	10000mAh/36.9Wh
Input	5V/3A, 9V/3A, 12V/3A, 15V/3A, 20V/3.25A (MAX 65W)
Output	5V/3A, 9V/3A, 12V/3A, 15V/3A, 20V/3.25A (MAX 65W)
Charging Time	3.5 hours
Output	Wireless: 15W Wireless: 10W Wireless: 7.5W Wireless: 5W Type-C: 5V/3A, 9V/3A, 12V/3A, 15V/3A, 20V/3.25A (MAX 65W) Type-A: 5V/3A, 9V/3A, 12V/3A, 15V/3A, 20V/3.25A (MAX 65W)
Net Weight	0.2 kg
Gross Weight	0.3 kg
Dimensions	14.5 x 7.1 x 2.2 cm

How to Use the Attached USB-C GoCord

Contact Us

Contact Us
Contact Us

3 YEARS

LIFETIME