

DRAPER[®]

Engine Stand 450kg

Stock No.53092

Part No.ES450

INSTRUCTIONS

09/2015

DRAPER[®]

SPECIFICATION

The Draper Tools policy of continuous improvement determines the right to change specification without notice.

Stock No.	53092
Part No.	ES450
Max. capacity	450kg
Width: Front	400mm
Rear	800mm
Length	800mm
Height	910mm

DRAPER[®]

WARNING

- Do not overload. Overloading could cause damage or failure of the engine stand.
- Never use the stand on an uneven floor surface as this could result in the stand tipping over.
- Always lock the rotating mechanism before applying a load.
- Ensure that the load is centered and secured to the mounting plate. An off centre or insecure load could cause the load and handle to rotate in either direction when the locking mechanism is released.
- Always release the locking mechanism slowly and carefully.
- The nuts and bolts supplied with the engine stand are all high strength and should not be substituted by inferior types.
- Before each use, ensure all nuts and bolts are correctly fitted and tight.

**FAILURE TO FOLLOW THESE INSTRUCTIONS COULD RESULT IN LOSS OF LOAD,
PERSONAL INJURY OR PROPERTY DAMAGE.**

DRAPER[®]

KNOW YOUR ENGINE STAND

