

UEC Refresher

RSR-32 Product Spec

RF

Protocol	Bluetooth 4.2
RF Type	2.4GHz

Mechanical and Electrical

Dimension (Height X Length X Width)	5.3 X 11.7 X 4.0 cm
Material	PC
Push Button	Function: When the internal button is pressed, it detects if the Refresher LED light is lit, and if so, the STATUS LED light also illuminates. If you don't do it on time, it will return to power saving mode.
Power	CR-2450 3.0V Battery 620mAh If the results are sent every five minutes, it is expected to be useful for 2 years.

Operating

Environment	Working Temperature: -20° C - 60° C Working Humidity: 10% - 90%RH
-------------	--

Operating Manual

1. First, remove the four screws on the top cover and remove the top cover to expose the battery holder on the circuit board.
2. Remove the isolation tab of the CR2450 coin cell battery and it will work.
3. Please record the time when the battery started working and stick it on the back of the cover for record.
4. Assembling Refresher Monitor to the Refresher before it is powered on
5. Press the button, and the STATUS LED will not light up because no light

source is detected.

6. When the Refresher machine is plugged in, the LED will glow when it is working properly, and if the button is pressed at this time, the STATUS LED will light up.
7. Close the top cover and lock the four screws.
8. Setup is complete.

Federal Communication Commission Interference Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- . Reorient or relocate the receiving antenna.
- . Increase the separation between the equipment and receiver.
- . Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- . Consult the dealer or an experienced radio/TV technician for help.

FCC Caution: To assure continued compliance, any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment. (Example - use only shielded interface cables when connecting to computer or peripheral devices).

FCC Radiation Exposure Statement

This equipment complies with FCC RF radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 20 centimeters between the radiator and your body.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

The antennas used for this transmitter must be installed to provide a separation distance of at least 20 cm from all persons and must not be co-located or operating in conjunction with any other antenna or transmitter.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.