


骨传导蓝牙耳机



使用指南及保修说明
Operating instructions and Warranty description

示意图



充电

该耳机使用内置可充电电池，首次使用耳机必须给电池充满电。使用中，若语音“电量低”提示音，表示电池电量低，此时需要给耳机充电。

将充电线连接到耳机的磁吸充电口，2小时左右即可充满。充电状态指示灯长亮红灯，充满电常亮蓝灯。

注意

磁吸充电有正负极对应，相互吸附可正常充电，相互排斥则无法充电甚至造成短路。



本产品的可充电电池必须妥善处理，以便回收利用。请不要将电池放入火中，以免引起爆炸。

开关机

功能	操作	指示灯
开机	长按“”3-5秒	灯亮
关机		灯灭

操作说明

功能	耳机状态	操作
增加音量	蓝牙已连接	单击“+”
减少音量		单击“-”
下一曲	播放音乐	长按“+”2秒
上一曲		长按“-”2秒
暂停播放	暂停音乐	单击“”
恢复播放		
接或挂电话	来电时	长按“”1秒
拒绝电话		
手机/蓝牙听筒切换	通话中	
游戏/音乐模式切换	蓝牙已连接	4击“”

使用说明

如何蓝牙配对

蓝牙配对: 在关机的状态下，长按“”3-5秒，指示灯进入红蓝光闪烁状态，此时即进入配对状态，打开设备上的蓝牙（手机/电脑）搜索名称“X5”，点击设备“X5”配对连接，连接成功退出，即可使用。

蓝牙/MP3模式切换: 双击“”切换蓝牙和MP3(TF卡)模式。

强调: 开机自动默认蓝牙模式。

歌曲下载: 将原装充电数据线连接电脑和耳机，即可读取U盘，将电脑歌曲复制到U盘。

MP3播放模式切换: 在MP3模式放歌时，三击“”切换 随机播放/顺序播放模式（带记忆功能）

AI智能语音控制

(手机需支持语音唤醒功能)

功能	耳机状态	操作
语音控制	蓝牙已连接	长按“”1秒松手

说明: 在蓝牙连接状态中，长按电源键1秒松手后，听到提示音后，就可以语音操控手机，节约操作手机的时间，快捷又智能。

例如您可以直接操控耳机问：

现在几点钟.....今天天气.....

导航去深圳世界之窗.....打电话给某某.....

打开网易云音乐.....播放刘德华的冰雨.....下一曲.....音量降低.....

打开美团.....打开喜马拉雅.....打开微信.....播放戏曲.....

智能运动，轻松好玩

指示灯

充电中	常亮红灯
充电完成	常亮蓝灯
搜索配对	红蓝光交替闪烁
蓝牙音乐播放	蓝灯5秒慢闪

产品参数

型号: Onesuze Free S1
充电: ≈2h
输入: 5V/150mA

蓝牙版本: 6.0
电池容量: 170mAh
连接距离: 蓝牙10m

播放: ≈5h@60%音量
协议: HFP A2DP AVRCP
音乐格式支持: MP3, WAV, WMA, APE, FLAC, AAC, M4A
防水级别: IPX8

注意事项

保养与清洁:

- 耳机不能长时间泡海水/盐水，使用后应用淡水冲洗擦干，不然充电磁吸部分容易腐蚀。
- 如何长时间不使用，请至少一个月充满一次电。
- 请不要私自拆装产品上任何部件，如发现产品有缺陷立即停止使用，联系销售方售后处理。
- 每次运动后将耳机表面的水擦拭干净，特别是充电磁吸位置，要及时处理干净，防止汗水，盐水腐蚀充电口，影响产品寿命。
- 产品远离火源、热源、冷冻源、化学品、严禁暴力撞击拆装挤压产品。
- 请使用输出5V1A及以内的充电头。

合格證
Q.C.Passed

产品保修卡

此卡为产品保修凭证，请妥善保管

产品名称:	产品型号:
购买日期:	客户名称:
联系方式:	

产品维修记录


日期	不良现象	方案

Onesuze Free S1



Instructions for usage and warranty
Operating instructions and Warranty description

Schematic diagram



Charge

The headphone uses a built-in rechargeable battery, the first use of the headphone must be fully charged to the battery. In use, if the voice prompts "low battery", the battery is low, and you need to charge the headphone.

The charging cable should be connected to the headset's magnetic charging port, about 2 hours to fill. Charging status indicator is red light, full charge often blue light.

Note

Magnetic charging has a positive and negative polarity correspondence, mutual adsorption can be charged normally, and mutual repulsion will not charge or even cause a short circuit.



The rechargeable battery of this product must be properly disposed of for recycling. Please do not place the battery in a fire to avoid explosion.

Power On/Off

Function	Operation	Indicator
On	Press “” for 3-5s	Light is on
Off		Light is off

Operating instruction

Function	Earphone status	Operation
Increase volume	Bluetooth is connected	Click “+”
Reduce volume		Click “-”
Next song	Play music	Press “+” for 2s
Previous song		Press “-” for 2s
Pause	Pause music	Click “”
Resume		
Answer the call / Hang up	Phone calls in	Press “” for 1s
Decline the call		
Phone / Bluetooth earphone switch	On the phone	4-click “”
Switch between Game/Music mode	Bluetooth is connected	

Instruction

How to pair with Bluetooth

Bluetooth pairing: In the off state, press and hold “” for 3 to 5 seconds, the indicator light will enter the red and blue light flashing state, and then enter the pairing state. Turn on the Bluetooth (mobile phone / computer) on the device and search for the device name “X5”. Click the device “X5” to pair and connect.

Bluetooth / MP3 mode switching: Double click “” free Switch bluetooth and MP3 mode.

Note: Bluetooth mode is default for boot.

Song download: Connect the magnetic charging cable to the computer and headphones, you can read the USB built-in memory card, and copy the songs from the computer to the USB.

MP3 playback mode switch: When playing audio in MP3 mode, triple-click “” to switch between shuffle and sequential playback modes (with memory function)

AI intelligent voice control

(Phone needs to support voice wake-up function)

Function	Earphone status	Operation
Voice control	Bluetooth is connected	Press “” for 1s to release.

In the Bluetooth connection state, long press the power on button for 1 second to wake up, after hearing the tone you can voice manipulate the phone, save time to operate the phone, fast and intelligent.

Indicator

Charging	Normally on red light
Finished charging	Normally on blue light
Search for a match	Red and blue lights flash alternately
Bluetooth music player	Blue light flashes once every 5 sec.

Product parameter

Model: Onesuze Free S1
Charging time: ≈2h
Input: 5V/150mA
Operating time : ≈5h@60% Volume
Profile: HFP, A2DP, AVRCP
Music format support: MP3, WAV, WMA, APE, FLAC, AAC, M4A
Waterproof grade: IPX8

Bluetooth: 6.0
Battery: 170mAh
Distance: Bluetooth 10m

Care and cleaning

- The headphones should not soak in seawater/brine for a long time, as the magnetic charge part tends to decay. When going to the beach, it's better to protect the magnetic absorption point.
- If not used for a long time, please fully charge it at least once a month.
- Do not disassemble any part of the product without permission. If you find that the earphone is defective, please stop using it.
- Keep the product away from fire, heat, freezing, and chemicals. Do not immerse the earphone in water, and do not wipe it with chemicals such as aromatherapy water.
- Store in a cool, dry place. Do not expose the product to direct sunlight for a long time.
- Please use a charging head with an output of 5V1A or less.

Certificate of conformity
Q.C.Passed

Product warranty card

This card is a product warranty certificate, please keep it properly

Product name:	Product model:
Purchase date:	Clients name:
Contact:	

Product maintenance records

Date	Bad phenomenon	Solution



75mm

55mm

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure statement

The device has been evaluatec to meel general RF exposure requirement. The device can be used in portable exposure condition without restriction.