Q1/Q2

INSTRUCTIONS

封面

Functional characteristics

1:Supports Bluetooth connection for music playback
2:360 degree surround bass
3:TF card song playback
4:Playing songs on a USB flash drive
5:DC5V charging TYPE-C port
6:Lyrics are synchronized on LCD display
7:Mini-program linkage

Key function indication

Press and hold the "⏻" key to turn on/off
Press " ⏯ " briefly to pause the play
Double-click mode switching: When there is an incoming call, briefly press " ⏯ " to answer
Double-click " ⏯ " to reject the call. After answering the call, click " ⏯ "again to hang up
Briefly press "⏮" to the previous song, long press"⏮"volume "-", and double-click the redial
Briefly press "⏭" to the next song, long press"⏭"Volume "+", and double-click"⏭" to switch to playInterface
Reset button: When the system freezes or fails to operate normally without power interruption Press the reset button to restart the device



Q1



Q2

Bluetooth connection

Turn on the device, enter the Bluetooth mode, open the Bluetooth device on your phone, and search for the display on your phone
For the (Q1/Q2) device models, simply click to pair and connect

Bluetooth call

When there is an incoming call, briefly press the " ⏯ "key to answer the call and double-click the " ⏯ "key to reject the call. After answering the call, click the" ⏯ " key again to hang up.

TF card/USB flash drive music playback

When a USB flash drive or TF card is inserted, the speaker will automatically recognize it and play the content on the USB flash drive or TF card Music files, (Music files mainly support MP3, WAV formats, USB flash drives and TF cards. The maximum capacity supports 32GB.

Charging

It can be charged both when the speaker is turned on and off. When the battery is low, it will prompt that the battery is low
Please charge it in time. Connect the charging cable to the charger for charging

Alarm clock

When the alarm clock rings, press any key to turn it off

Screen display

When the device is turned on, double-click the switch to switch between the clock interface and the playback interface

Clock interface

The up and down arrow keys and the pause key have no effect



Playback interface


Display lyrics synchronization (the song being played must have lyrics synchronization)
The playback interface defaults to four pattern interfaces: disc/star/water ripple/flame
(You can change your favorite playback interface pattern through the mobile phone applet)

Microphone explanation

Long press the " ⏻ " button to turn on the device (The red light comes on first, and the red and blue lights flash alternately. After connecting, the red light goes out, and the blue light remains on.) In the startup state, short press " ⏻ " to change the sound mode (three types: original sound, female sound, and male sound). Long press " + " to increase the microphone volume. Press " − " to decrease the microphone volume.
Short press " ↖ "key to adjust the reverb, press the reverb briefly and press it again to turn off (no reverb by factory default)

Microphone is not available in call mode

Special note: microphone reverberationadjustment needs to be adjusted after connecting to the host computer.



warning

The product has a built-in lithium battery, which cannot be replaced. Please do not discard it or put it in the fire to avoid danger

Parameters

Working voltage: 3.7V
Speaker: Ø45mm4 ohms 5 watts
Charging voltage/current: USB DC5V = 0.8-1 a
Bluetooth version: Bluetooth6.0
Signal-to-noise ratio: >76dB
Frequency response: 80Hz- 20KHz



售后服务卡

非常感谢您选择本公司产品，如需办理售后相关事宜，请先联系售后服务填写好此卡，并同产品一起寄回。

您的信息：	
会员名：	订单编号：
联系人：	联系电话：
回寄收货信息 (换货/保修需填写此项)：	
您对我们的建议：	

售后清单

产品名称	数量	申请原因	售后类型 (换机 退货 其它)

以下情况不予退/换：
1.人为损坏本产品 2.已超过退/换货申请期限 3.电池及赠送配件

因产品版本迭代更新，实物与说明书描述可能存在差异，以实物为准，最终解释权归我司所有

(How to connect to the Mini Program)

(The first step.)

Connect the mobile phone to the Bluetooth speaker
Turn on your mobile phone and connect it to Bluetooth
After a successful connection, scan the QR code of the "Wanrenmi Home" mini-program
with wechat to enter the home page

Scan the code to enter the 'WeChat Mini Program'.



(Step two)

Click to enter. First, click to initialize Bluetooth, then click to scan the device.
The device name "Q1 (Round Screen)" or "Q2 (Square screen)" will appear.
Just click the link.This operation needs to be performed every time the device is shut down or the Bluetooth is reconnected.

Turn on the speaker and then turn on the Bluetooth on your mobile phone



(Step Three)

After connection, return to the main interface: Select Zebai Noise playback. Select and replace the playback interface pattern (Please wait patiently for the image as it needs to load.You can switch on the machine only after the upload is successful

White noise function




Interface theme playback



(Alarm clock adjustment)

Click on the home page to enter the alarm clock adjustment, and click the "+" to set the alarm date you need.Adjust with the time. After adjustment, click "Save and Confirm " to complete the Settings.



(Turn off the alarm clock)

Click to close the alarm setting interface, and the screen will exit the alarm setting interface

(Album usage)

Clicking on the album allows you to upload pictures from your phone to the machine as dynamic images for the playback interface



FCC Caution:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and , if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.
If this equipment does cause harmful interference to radio or television reception,which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
-- Reorient or relocate the receiving antenna.
-- Increase the separation between the equipment and receiver.
-- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-- Consult the dealer or an experienced radio/TV technician for help.
The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

单页尺寸60mm*85mm