


Homecare Device

사용설명서

Manual



***본 제품은 의료기기가 아닌 미용기기입니다.**

This product is a beauty device, not a medical device.

Homecare Device

(주)제이엘유의 제품을 구매해 주셔서 감사합니다.

본 제품은 의료기기가 아닌 미용기기입니다.

사용감과 체감에는 개인차가 있으며, 이상 증상이 나타나면 즉시 사용을 중지하십시오.

제품의 외관 및 규격 등은 품질 개선을 위하여 사전에 통보 없이 변경될 수 있습니다.

목차

01. 주의사항	03
02. 제품 소개	
- 구성품 및 명칭	04
- 제품 사양 및 충전 안내 및 디바이스 관리 방법	05
03. 사용 방법	
- 사용 방법	07
04. 보증 및 A/S	
- 보증 및 A/S	09
- 제품 보증서	10
05. 영문 매뉴얼 ENGLISH MANUAL	12


※ 주의사항 (필독)

1. 본 제품은 의료기기가 아닌 미용기기입니다. 미용 관리 목적 외의 용도로 사용을 삼가십시오.
2. 제품 사용 전 보호 필름을 제거하고 사용하십시오.
3. 제품 사용 전 반드시 제품이 정상 작동하는지 확인한 뒤 사용하시기 바랍니다.
4. 어린이 손이 닿지 않는 곳에 보관하십시오.
5. 신체적·감각적 또는 정신적 능력이 저하된 사람(어린이 포함)이나 경험 및 지식이 부족한 사람이 사용하지 않도록 하고, 안전을 책임지는 사람으로부터 제품 사용에 관한 감독이나 지시를 받은 경우 주의하여 사용하십시오.
6. 임산부·수유 중인 자는 사용을 삼가십시오.
7. 목걸이·귀걸이 등 금속류 액세서리를 제거 후 사용하십시오.
8. 상처·감염·종기 등 피부 질환 부위는 사용을 삼가하십시오.
9. 임플란트·신경 치료·교정 등 치과 치료와의 병행은 전문 의료인의 소견에 따르는 것을 권장합니다.
10. 모든 성형 시술과의 병행은 전문 의료인의 소견에 따르는 것을 권장합니다.
11. 심장 박동기 착용·장치 이식·중증 질환 이력·통원 치료 등 건강상 주의가 필요한 자는 사용을 삼가하십시오.
12. 본 제품은 얼굴 전용 피부 관리 제품으로 얼굴 피부 외 다른 부위에 사용을 삼가하십시오.
13. 수정체(눈), 눈 주변, 갑상선이 지나는 부위는 사용을 삼가하십시오.
14. 관리 시 반드시 피부와 기기 사이가 뜨지 않도록 정확히 밀착해서 사용해 주십시오.
15. 한곳에 오래 멈추어 사용하면 피부가 자극을 받게 되므로 주의하여 사용하십시오.
16. 피부 민감도에 따라 적절한 강도를 설정하여 사용하십시오.
17. 권장사항을 지키지 않아서 발생하는 부작용에 대해서는 당사가 책임지지 않습니다.


※ 제품 관리

1. 분리형 전원 공급 장치가 제공된 경우, 제품과 함께 제공된 전원 공급 장치만 사용하십시오.
2. 제품을 개조하거나 분리·수리하지 마십시오. 사용자 임의로 개조·분리·수리 시 기간 내 무상 A/S 서비스를 받을 수 없으니 반드시 지정 A/S 센터를 이용하십시오.
3. 제품을 물에 씻거나 담그지 말고, 젖은 손으로 조작하거나 젖은 상태에서 충전하지 마십시오.
4. 제품을 습기가 있는 곳(욕실·세탁실·사우나 등)에 보관하면 고장의 원인이 될 수 있으므로, 습기에 노출되지 않도록 보관하십시오.
5. 제품에 충격을 주거나 떨어뜨리지 않도록 주의하십시오.
6. 제품 사용 후 헤드(접촉부)를 알코올로 소독하십시오. 소독 시 거친 질감의 천을 사용하거나 표면을 강하게 닦으면 스크래치 등 손상이 발생할 수 있으므로 부드러운 천을 이용하십시오.
7. 본체는 알코올 소독 시 변색·오염 등이 발생할 수 있으므로 물티슈 또는 부드러운 천을 이용하십시오.
8. 이외 자세한 제품 관리·A/S 서비스는 제조사의 품질보증 규정을 따릅니다.

구성품






본체



충전 케이블
C-TYPE

명칭



제품 사양


*본 제품의 사양은 성능 향상이나 개선을 위하여 별도의 고지 없이 변경될 수 있습니다.

*본 제품의 사양은 측정 도구 및 위치 등 측정 방법에 따라 차이가 있을 수 있습니다.

모델명	JTMC200B	제품명	피부 관리기
제품 사이즈	약 W47 x H220 x D47 mm	제품 무게	약 299g
정격 전압	DC 5V 1A	배터리	800mAh
충전 케이블	C-TYPE	충전 시간	약 120분
사용 시간	완충 시 약 2~3,000회 사용 가능	제조/판매원	(주)제이엘유
제조년월	별도 표기	고객센터	051-331-7185
KC	R-R-JLU-JTMC200B	A/S 센터	010-4505-7989

충전 안내

충전 케이블을 제품 하단의 충전 포트에 연결할 때 커넥터 부분을 완전히 밀어 넣어야 합니다. 그렇지 않은 경우 충전이 원활하지 않을 수 있습니다. 제품에 전원이 들어오지 않으면 제품 하단 충전 포트의 연결 상태를 확인해 주십시오.



충전 안내


사용 가능

5V 1A / 5V 2A 충전기




사용 불가

비규격 충전기 (5V 3A)



- 반드시 정격 전압(5V 1A / 5V 2A) 어댑터를 사용해 주십시오. 노트북 충전기, 초고속 충전기 등 규격과 다른 어댑터 사용은 불가합니다.
규격과 다른 어댑터 사용 시 충전·사용 시간이 안내된 내용과 달라질 수 있으며, 이로 인한 고장·손실은 소비자 과실로 제조사에서 책임지지 않습니다.
- 반드시 동봉된 충전 케이블을 사용해 주십시오. (또는 C to A 케이블)
- 보조배터리를 이용한 충전은 불가합니다.
- 완충 후 전원을 켜올 때, 상단 배터리가 4칸에서 3칸으로 표시될 수 있습니다.
- 이는 배터리가 덜 충전된 것이 아니라, 배터리 4칸 구간이 전압의 최고점에만 해당하도록 설계되어 있어 조금만 사용해도 3칸으로 표시되기 때문입니다.
- 실제 배터리는 완충 상태이므로 사용 시간에는 지장이 없습니다.
- 완충 직전과 방전 직후 단계에서는 배터리 안정성을 위해 미세한 전류로 천천히 충전되도록 설계되어 있어, 충전 시간이 다소 길게 느껴질 수 있습니다.
- 완충 후 충전기를 다시 연결했을 때 'CHARGING(충전 중)' 표시가 나타나는 것도 정상 동작이므로 안심하고 사용해 주세요.
- 충전 중 버튼 조작 등 디바이스 사용은 고장의 원인이 될 수 있습니다.
- 충전 단자가 올바르게 맞지 않거나, 단자에 먼지·이물질이 쌓여 있는 경우 접촉 불량 발생할 수 있으므로 주의해 주세요.

디바이스 관리 방법



알코올 소독 가능

소독 시 부드러운 천 이용

*거친 질감의 천을 사용하거나 표면을 강하게 닦으면 스크래치 등 손상이 발생할 수 있으며 사용 부주의로 인한 제품 손상은 교환·환불이 불가능합니다.

알코올 금지

디바이스 본체는 알코올 소독 시 변색·오염 등이 발생할 수 있으므로 물티슈 또는 부드러운 천을 이용해 관리해 주세요.

사용 주기	14일 전후, 폴페이스 100회 권장 *개인의 피부 상태에 따라 사용 강도와 횟수는 조절하십시오.
사용 금지 부위	수정체(눈), 눈 주변, 갑상선이 지나는 부위
주의사항	관리 시 반드시 피부와 기기 사이가 뜨지 않도록 정확히 밀착해서 사용해 주십시오. 개인에 따라 석션 압력으로 인해 약간의 멍자국이 생길 수 있습니다. (일시적 현상)

온도 센서 기능 안내

디바이스의 과열 방지를 위한 온도 센서 안전 기능이 적용되어 있습니다.

※ 위 동작은 기기 보호를 위한 정상적인 안전 제어 기능이며, 제품의 이상이나 고장이 아닙니다.

측정 온도 40°C 도달 시



온도 센서 LOCK 상태 진입

측정 온도 40°C 이상 상태



사용 제한

측정 온도 40°C 미만 상태



사용 가능

자이로 센서 기능 안내

디바이스의 오작동 및 과열을 방지하기 위해 움직임 감지 자이로센서 기능이 탑재되어 있습니다.

작동 중 움직임이 감지되지 않으면 안전을 위해 전원이 자동으로 꺼집니다.

이후 다시 사용하려면 전원 버튼을 눌러 디바이스를 재작동해 주세요.

1분 이상 움직임 X



전원 OFF

주의사항


*방수·습기 및 화장품 사용 시 주의

1. 본 제품은 방수가 되지 않으니 욕실, 세탁실, 사우나 등 습기가 많은 장소에서 보관하거나 사용하는 것은 피해 주세요.
2. 물기나 습기에 노출될 경우 제품 고장의 원인이 될 수 있습니다.
3. 화장품을 디바이스에 직접 짜서 사용할 경우, 내용물이 제품의 틈 사이 또는 충전 연결부로 유입될 수 있으며, 제품 고장의 원인이 될 수 있습니다. 이로 인한 고장·손실은 소비자 과실로 제조사에서 책임지지 않습니다.

내용물 유입 주의



헤드 연결부



제품 틈 사이



제품 틈 사이



헤드 연결부





STEP 01

세안 후 얼굴의 물기를 제거한 상태에서 사용해 주세요.

*본 제품은 화장품과 같이 사용하지 않습니다.

STEP 02

전원을 켜고 모드, 파워 단계, 석션 강도를 설정해 주세요.

STEP 03

아래턱, 볼 등 광대 아래 부위를 위주로 관리해 주세요.

STEP 04

석션의 압력으로 피부가 잡혔다가 다시 풀릴 때까지 기다린 후, 다음 부위로 이동하며 사용해주세요


사용 TIP!

- *석션이 작동한 상태에서 억지로 떼어내거나 이동하지 마십시오.
- *석션이 해제된 후 다음 부위로 이동해 주세요.
- *동일 부위에 연속적으로 사용하면 피부 자극이 발생할 수 있으므로 주의하십시오.
- *개인에 따라 석션 압력으로 인해 약간의 멍자국이 생길 수 있습니다. (일시적 현상)

작동법

전원 ON	전원 버튼을 3초 이상 누르면 화면과 함께 전원이 켜집니다.
전원 OFF	전원이 켜진 상태에서 전원 버튼을 3초 이상 누르면 화면과 함께 전원이 꺼집니다.
모드 설정	MODE 버튼을 짧게 눌러 모드를 설정합니다.
강도 설정	전원 버튼을 짧게 눌러 파워 단계를 설정합니다. (1~5단계)
석션 설정	INTEN 버튼을 짧게 눌러 석션 강도를 설정합니다. (1~3단계)
메모리 확인	MODE 버튼을 길게 눌러 누적 사용량을 확인할 수 있습니다.
일시 정지	시작/정지 버튼을 누르면 일시정지가 가능합니다.

화면 표시



본 보증 규정은 당사가 정한 보증기간과 조건의 범위에 한하여 적용되며, A/S서비스는 제품 구매처 또는 본사 A/S 센터로 문의하여 주십시오.

※ 보증기간

제조일로부터 1년 이내, 정품 등록 시 무상 유지보수

보증기간 중 장비 본체의 제조상 결함이 확인될 경우, 무상 A/S 서비스를 제공받을 수 있습니다.

※ 유상 A/S 대상

1) 보증 범위 외 제품

- 보증기간이 지난 제품
- 정상적인 사용에 따른 배터리 성능 저하 및 소모품 마모

2) 소모품 및 액세서리

- 소모품 (도자, 카트리지, 케이블, 어댑터, 핸드피스, 카트 등)
- 별도 제공 액세서리 (거치대, 크레들 등)

3) 소비자 과실 및 관리 미흡

- 낙하충격·개조·수리로 인한 제품 고장
- 비공식 소프트웨어·펌웨어 변경으로 인한 문제
- 천재지변(화재, 지진, 홍수 등)에 의한 파손

※ 예외 사항 (A/S 불가)

분실 또는 도난

※ A/S 배송비

택배로 진행되는 서비스의 배송비는 판매사와 소비자가 각각 부담합니다.

- 수리 전 발송 : 소비자 부담
- 수리 후 발송 : 판매사 부담

※ A/S 센터

- 대표 번호 : 010-4505-7989
- 운영 시간 : 오전 9시 ~ 오후 6시 토/일/공휴일 휴무 (점심시간 오후 12시 ~ 1시)
- 주소 : 부산광역시 북구 효열로 111 부산지식산업센터 4층 411호 (주)제이엘유

제품 보증서

(주)제이엘유의를 제품을 구매해 주셔서 감사합니다.

본 제품은 본사에서 제조한 정품으로
엄격한 품질 관리 및 검사 과정을 통과한 후 출하된 제품입니다.

홈페이지를 통해 정품 등록을 완료하시면
보증기간 내 무상 서비스가 가능합니다.

A/S 센터 : 010-4505-7989

[정품 등록 방법]

자사몰 접속 (www.jlu.kr) → 정품 등록 페이지 → 로그인 → 제품 시리얼 넘버 입력

*제품 시리얼 넘버 : 본체 별도 표기

Homecare Device

Thank you for purchasing a product from JLU Co., Ltd.

This product is a beauty device, not a medical device.

Please note that the user experience and perceived effects may vary by individual. If any abnormal symptoms occur, discontinue use immediately.

Table of Contents

01. Caution	-----	13
02. Product Introduction		
- Components & Name	-----	14
- Product Specifications & Charging Information & Device Care Method		15
03. Usage Method		
- Usage Method	-----	17
04. Warranty & A/S		
- Warranty & A/S	-----	20
- Product Warranty	-----	21


※ CAUTION

1. This product is a beauty device, not a medical device. Please refrain from using it for any purpose other than beauty care.
2. Remove the Protective film before using the device.
3. Before using the product, please make sure it is functioning properly.
4. Please keep out of reach of children.
5. Not intended for use by individuals with reduced physical-sensory, or mental capabilities (including children) or those lacking experience and knowledge, unless supervised or given instructions on device use by a responsible person.
6. Avoid use on pregnant-breastfeeding women.
7. Remove metal accessories such as necklaces-earrings etc., before use.
8. Avoid use on areas with skin diseases such as wounds-infections-boils.
9. It is recommended to consult with a medical professional when using with dental treatments such as implants-nerve treatments-orthodontics.
10. It is recommended to consult with a medical professional before undergoing any cosmetic procedures.
11. Avoid use on people who require health precautions, such as having pacemaker-device implants-history of severe illness-outpatient treatment.
12. This product is a skin care device intended for use on the face only. Avoid using it on any area other than the face.
13. Avoid use on pupils(eyes), around the eyes and where the thyroid gland passes.
14. During use, make sure the device is in full contact with the skin.
Do not leave any space between the device and the skin.
15. Use carefully, as prolonged use on one area may cause skin irritation.
16. Set the appropriate power based on the skin sensitivity.
17. We are not responsible for any side effects that may occur as a result of not following our recommendations.


※ Product Care

1. If a detachable power supply is provided, only use the device with the power supply provided with it.
2. Do not modify or disassemble-repair the product. If the user modifies-disassembles-repairs the product, free A/S service cannot be provided within the warranty period, therefore be sure to use the designated A/S center.
3. Do not touch with wet hands, do not wash or immerse the product in water. Be careful as it may cause electric shock-malfunction.
4. Do not store the product in humid environments (bathrooms-laundry rooms-saunas etc), as this may cause malfunction. Store it in a dry place, away from moisture.
5. Avoid dropping the product or subjecting it .
6. Disinfect the head(contact area) with alcohol after use. Use a soft cloth for disinfection, as rough cloths or strong wiping can cause scratches or damage.
7. Use wet tissues or a soft cloth to clean the main body, as using alcohol may cause discoloration-contamination.
8. For detailed product care-A/S services, follow the manufacturer's warranty regulations.

Product Components




Main Body



Charging Cable
C-TYPE

Product Name




Product Specifications

- *This product's specifications may be subject to change without separate notice for performance improvement.
- *The specifications of this product may vary depending on the measurement method, such as the measuring instruments and measurement locations.

Model Name	JTMC200B	Product Name	Skin care device
Product Size	About W47 x H220 x D47 mm	Product Weight	About 299g
Input	DC 5V 1A	Battery	800mAh
Charging Cable	C-TYPE	Charging Time	About 120 minutes
Usage Time	Around 2~3,000 uses on a full charge	Manufacturer/Seller	JLU Co., Ltd.
Date of Manufacture	Separate Notation	Customer Center	+82 51-331-7185
FCC	2BHHE-JTMC200B	A/S Center	+82 10-4505-7989

Charging Information


When connecting the charging cable to the charging port on the bottom of the device, push the connector in completely. If not, charging may not proceed smoothly. If the device does not power on, check the connection of the charging port on the bottom of the device.



Charging Information


Usable

Charger 5V 1A / 5V 2A




Not usable

Non-standard charger (5V 3A)



1. Please be sure to use an adapter with the rated voltage (5V 1A / 5V 2A). Adapters that do not meet the specifications such as laptop chargers or ultra-fast chargers must not be used. If a non-compliant adapter is used, charging and usage time may differ from the stated information, and any malfunction or damage resulting from this will be considered consumer negligence. The manufacturer will not be held responsible.
2. Please make sure to use the included charging cable. (or a C-to-A cable)
3. Charging using a power bank is not allowed.
2. Please make sure to use the included charging cable. (or a C-to-A cable)
3. After the device is fully charged, if you turn it on and then connect the charger again, the battery indicator at the top may change from 3 bars to 2 bars.
4. This does not mean the battery is insufficiently charged. The 3 bar level is designed to correspond only to the highest voltage range, so even brief use may cause the indicator to display 2 bars.
5. The battery is still fully charged, and this does not affect the actual usage time.
6. Near full charge or right before complete discharge, the device is designed to charge slowly with a micro-current for battery safety. Because of this, charging may feel slightly longer than expected.
7. Do not operate the device while charging (e.g., pressing buttons), as this may cause malfunction.
8. If the charging port is not properly aligned, or if dust or foreign substances accumulate on the connector, poor contact may occur. Please check carefully before charging.

Device Care Method



Alcohol Disinfection Allowed

(Use a soft cloth for disinfection)

*Using a rough cloth or wiping the surface too hard may cause scratches or damage. Product damage due to user negligence is not eligible for exchange or refund.

Alcohol Prohibited

Use wet tissues or a soft cloth to clean the device body, as using alcohol may cause discoloration-contamination.

Usage Cycle	Approximately every 14 days, 100 for full-face use is recommended. *Depending on your skin condition, adjust the intensity and frequency of use.
Prohibited Areas of Use	Pupils (eyes), around the eyes, and the area where the thyroid gland passes
Precautions	During use, be sure to use the device while keeping it accurately and firmly attached so that there is no gap between the skin and the device. Depending on the individual, slight bruising may occur due to suction pressure. (Temporary phenomenon)

Temperature Sensor Function Guide

A temperature sensor safety function is applied to prevent device overheating.
* The above operation is a normal safety control function for device protection and is not a malfunction or defect.

When the measured temperature reaches 40°C	▶▶	Enters Temperature Sensor LOCK state
When the measured temperature is 40°C or higher	▶▶	Use is restricted
When the measured temperature is below 40°C	▶▶	Use available

Gyro Sensor that Detects Movements

To prevent malfunction and overheating, the device is equipped with a movement detector gyro sensor. If no movement is detected during operation, the power will automatically turn off for safety. To resume use, please press the power button to restart the device.

No movement for more than 1 minute	▶▶	Power OFF
------------------------------------	----	-----------



Caution


*Precautions for Water·Moisture, and the Use of Skincare

1. This product is not waterproof. Please avoid storing or using it in humid environments such as bathrooms, laundry rooms, or saunas.
2. Exposure to water or moisture may cause product malfunction.
3. If skincare are applied directly onto the device, the contents may seep into gaps in the product or into the charging port, which may cause malfunction. Any damage-loss resulting from this will be considered consumer negligence, and the manufacturer will not be responsible.

Prevent liquid from entering the device



Head (Contact area)



Gaps in the product



Gaps in the product



Charging port



03. Usage Method - Quick Guide

19



STEP 01

After cleansing, dry your face and use the device.

*This product is not used together with cosmetics.

STEP 02

Turn on the power and set the mode, power level, and suction level.

STEP 03

Please focus on caring for the area below the cheekbones, such as the lower jaw and cheeks.

STEP 04

Wait until the skin is held by suction pressure and then released again, then move to the next area and continue use.


Usage TIP!

- *Do not forcibly detach or move the device while suction is operating.
- *After suction is released, please move to the next area.
- *If used continuously on the same area, skin irritation may occur, so please be cautious.
- *Depending on the individual, slight bruising may occur due to suction pressure. (Temporary phenomenon)

Operation

POWER ON	Press the power button for more than 3 seconds and the device will turn on with the screen.
POWER OFF	When it turns on, press the power button for more than 3 seconds to turn it off.
Mode Setting	Press the MODE button briefly to set Mode.
power Level Setting	Press the power button briefly to set the power level. (Levels 1~5)
suction level setting	Press the INTEN button briefly to set the suction level. (Levels 1~3)
Memory Check	Press and hold the MODE button to check the accumulated usage.
Pause	It is possible to pause with the start/stop button.

Display



04. Product Warranty & A/S

20

This warranty policy applies only within the warranty period and conditions specified by our company.
For A/S service, please contact the place of purchase or our headquarters A/S center.

※ Warranty Period

Within 1 year from the date of production

if the product is registered as genuine and a manufacturing defect of the main device is confirmed during the free maintenance warranty period, free A/S service will be provided.

※ Paid A/S

1) Products outside the warranty scope

- Products past the warranty period
- Battery performance degradation and wear of consumables due to normal use

2) Consumables and accessories

- Consumables (head, cartridge, cable, adapter, handpiece, cart, etc.)
- Separately provided accessories (stand, cradle, etc.)

3) Customer negligence or improper management

- Failures caused by dropping-impact-disassembly-modification-repair
- Issues due to unofficial software-firmware changes
- Damage caused by natural disasters (fire, earthquake, flood, etc.)

※ Exceptions (A/S is not available)

Lost or stolen

※ A/S Shipping Fee

For services conducted via courier, shipping costs are shared between the seller and the customer.

- Before repair : Customer bears the cost
- After repair : Seller bears the cost

※ A/S Center

- Contact Number: +82 10-4505-7989
- Operating Hours: 9:00 AM – 6:00 PM Closed on Sat/Sun/public holidays (Lunch break 12:00 PM – 1:00 PM)
- Address: JLU Co., Ltd. 411 office, Busan Knowledge Industry Center, 111, Hyoyeol-ro, Buk-gu, Busan, Republic of Korea

Product Warranty

Thank you for purchasing JLU products.

This product is a genuine product manufactured by the headquarters and shipped after passing strict quality control and inspection processes.

Free service within the warranty period is available if you complete the product registration through the homepage.

A/S Center : +82 10-4505-7989

[How to Register the Product]

Visit the official website (www.jlu.kr) → Go to the Product Registration page
→ Log in → Enter your product serial number

*S/N : Separate notation on the product

FCC Compliance Statement

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC Interference Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Caution

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.