



AIR DOOR ACTUATOR

**ACTUADOR PARA
COMPUERTA DE AIRE**

**ACTIONNEUR DE CLAPET
D'AIR**

NEED HELP?

Please call our Technical Support team for assistance from our team of certified automotive experts.

1-866-933-2911



ENGLISH

Air door must be aligned ("indexed") to the replacement air door actuator to install and function correctly. The included alignment tool can be used with a 1/4" drive ratchet to assist in this critical step.

ESPAÑOL

La compuerta de aire debe estar alineada ("sincronizada") con el actuador de la compuerta de aire de reemplazo para que se instale y funcione correctamente. La herramienta de alineación incluida se puede utilizar con un trinquete de 1/4" para ayudar en este paso crítico.

FRANÇAIS

Le clapet d'air doit être aligné (« indexé ») avec l'actionneur de clapet d'air de rechange pour qu'il soit installé et qu'il fonctionne correctement. L'outil d'alignement inclus peut être utilisé avec une clé à rochet à entraînement de 1/4 po pour vous assister dans cette étape cruciale.