



## 3D Active Shutter Glasses **Operation Manual**

Changhong Electric (Australia) Pty Ltd  
2/251 Ferntree Gully Rd, Mt Waverley, VIC, 3149  
**Website:** [www.changhong.com.au](http://www.changhong.com.au)  
**Customer Assistance:** 1300796688



**Model:G100**

Dear Customer:

Thank you for purchasing our products. Please read the User Guide carefully and keep this Guide in a proper manner. We shall assume no responsibility for any accident as a result of failure to violate the precautions and operating instructions stated in this manual.

Precautions:

- \* Disassembly and modification must be performed by professional technicians.
- \* Keep this product away from chemicals.
- \* Do not shake this product vigorously.
- \* Do not use this product in the areas those are exposed to optical radiation and thermal radiation.
- \* Do not use this product during the movement of body.
- \* Clean the glasses gently with clean and soft dedicated glass cleaning cloth; rubbing is not allowable.
- \* Do not scratch, knock and collide the glasses with hard objects or rub them with various abrasive materials.

## Contents

Technical Specification of 3D Glasses.....	3
Identifying Controls.....	4
Basic Operation.....	5
Charging.....	6
Troubleshooting.....	7
Packing List.....	8
Warranty.....	9

**Technical Specification of 3D Glasses:**

Product name: 3D Active Shutter Glasses

Weight: 48g

Working current: 5mA

Battery type: lithium-polymer battery


Carried standard: Q/02 RSR608-2010

Operating environment: working temperature 5-35°C

Working humidity: 20%-80% RH

Atmospheric pressure: 86kPa-106kPa

**Identifying Controls:**



The appearance of glasses shall be subject to change.

**Basic Operation:****Turn on:**

Push the switch button forward and then align the infrared signal reception window on the glasses with the 3D TV (IR emitter) indicator light (blue light); "normally ON" stands for normal operation status.

**Turn off:**

Push the switch backward and the indicator lamp would go off (i.e. turn off). The operation of glasses would stop working in this case.

Note: in case the glasses receive no IR sync signals in 15 minutes, they would be turned off automatically. To active the glasses, turn the power switch of glasses off first, then turn on the power switch on, The glasses will work again.

**Charging:**

You may charge the battery in the glasses through mobile phone charger with MiniUSB charge port, The USB port of PC, or the USB port of television ( this charging method is not recommended due to the high current of TV USB interface ).

The indicator light (red) would be normally ON during the charging process and would go off upon the full of charging. The full charging of battery would take about 1.5 hours.

**Troubleshooting:**

1.The glasses fail to work even if the power switch has been set to the ON position.

- (1) Check if there is still some electricity energy in the battery;
- (2) Recheck if the indicator lamp is still blue, normally ON or flashes regularly after the power adaptor is connected.

2.The LED indicator lamp of glasses keeps flashing.

Check if the glasses have received sync signals. Please charge the Technical 3D Glasses before restart if the indicator lamp continues to flash near sync signal source.

3.The 3D effect of image is poor or abnormal.

Press the left-right-eye power switch of 3D sync IR transmitter to switch the eye status.

**Packing list :**

NO.	Parts	Quantity
1	3D Active Shutter Glasses	1
2	Nose clip	3
3	Glasses bag	1
4	Glasses cleaning cloth	1
5	USB cable	1

**Please read this manual carefully before Operating the Set and retain it for future reference!**

**Warranty:**

1. Read the warranty carefully,
2. If you wish to make a claim under warranty, contact Changhong Electric (Australia) Pty. Ltd.
3. Changhong Electric (Australia) Pty. Ltd. suggest you attach your original purchase documents to this card, and keep in a safe, accessible place as it will assist Changhong Electric (Australia) Pty. Ltd. to process your claim.
4. Your product is fragile. If you need to, or are required to send your product to Changhong Electric (Aust) Pty. Ltd. or one of its authorised service centres, please ensure that it is packed appropriately. Changhong Electric (Australia) Pty. Ltd. accepts no responsibility for your product until it reaches it or its authorised service agent.
5. The cost of sending your product to Changhong Electric (Australia) Pty. Ltd. or its authorised service centre and the cost of the return of that product to you must be paid by you. Changhong Electric (Australia) Pty. Ltd. does not accept any obligation for the delivery of goods to it, its authorised service centre or return of those goods to you. Changhong Electric (Australia) Pty. Ltd.

**Warranty:**

will not accept any liability for damage done to goods because those goods have been mishandled by you or any third party in any manner whatsoever. Changhong Electric (Australia) Pty. Ltd. has the unfettered discretion to determine whether goods have been mishandled and damaged.

6. The warranty periods listed below are for **domestic use only**. For further details on commercial use warranty conditions please contact Changhong Electric (Australia) Pty. Ltd.

Models	Items	Warranty Period	Warranty Type
G100	3D Active Shutter Glasses	12 Months	Repair or Replacement

Changhong Electric (Australia) Pty Ltd  
 ABN: 32 095 276 181  
 2/251 Ferntree Gully Rd, Mt Waverley, VIC, 3149  
**Website:** <http://www.changhong.com.au>  
**Customer Assistance:** 1300796688  
**Tel:** 61 3 8545 7388 Fax: 61 3 8545 7343  
**Email:** [service@changhong.com.au](mailto:service@changhong.com.au)

**IMPORTANT**

**PLEASE READ THIS WARRANTY CARD AND COMPLETE THE WARRANTY REGISTRATION FORM.**  
**KEEP THIS WITH YOUR ORIGINAL PROOF OF PURCHASE FOR ANY CLAIM UNDER WARRANTY.**