SereneLife

SLMPR50RD - SLMPR50BK
SLMPR50USA

50W megaphone





visit our website

SCAN ME
serenelifehome.com

Unique Elements:

- 1,500-Yard Long-Range Audio Projection
- Weather-Resistant for Indoor & Outdoor Use

Features:

- 50W Loudspeaker Power
- Compact and Portable Design
- Built-in Mic, Siren, Modes for Crowd Control
- AUX Input for External Audio
- 12V DC Power Input
- Adjustable Volume Control
- USB-C Rechargeable for Fast Charging
- Lightweight, Ergonomic Handheld Design
- Power Saving OFF Switch
- Adjustable Shoulder Strap
- Ideal for Outdoor Use and Public Speaking
- Suitable for School Events, Rallies and Crowd Control

What's in the Box

- 50W Megaphone
- Wired Microphone
- USB-C Charging Cable
- Adjustable Shoulder Strap

Technical Specs

- Construction Materials: Durable ABS
- Power / Wattage: 50W
- Voltage: 7.4V (Battery-operated)
- Battery Type: Built-In 18650 Li-Ion Battery, 1800mAh or Requires (8) x C Batteries (Not Included)
- Charging Time: 3 hours
- Charging Voltage: DC 5V 1A
- Service Time: 5–6 Hours Continuous
- Charging Options: USB-C or 8 x C batteries (not included)
- Multiple Modes: Voice and Siren
- Max Sound Output: 108–110dB
- Response: 200–15,000 Hz
- Range: Up to 1,500 Yards
- Item Weight: 2.24 lbs
- Product Dimensions (L x W x H): 13.7 x 9.06 x 9.06 Inches

CALIFORNIA PROP 65 WARNING

⚠WARNING:

This product may expose you to chemicals, which is known to the state of California to cause cancer, birth defects and other reproductive harm. Do not ingest.

For more info go to: **www.P65warnings.ca.gov**

questions? comments?

We are here to help!

Phone: 1.718.535.1800

serenelifehome.com/contact us

IMPORTANT SAFETY WARNING

Do not point the megaphone horn directly at human or animal ears during operation. Exposure to high sound levels may cause hearing damage.

OPERATING INSTRUCTIONS

How to Use the Megaphone

Option 1 – Handle Trigger Operation

Press and hold the talk button located at the bottom of the handle to activate voice amplification. Speak clearly into the microphone opening on the megaphone.

Option 2 – External Microphone Operation

Slide the switch on the left side of the external microphone to the ON position to activate voice amplification. Speak clearly into the external microphone.

3 Position Switch: The unit is equipped with a 3-position operating switch

- **SIREN:** Activates the built-in siren.
- **OFF:** Turns the unit off.
- **MIC:** Enables microphone operation and AUX audio input.

Microphone Operation

- Pull the handheld microphone trigger to speak.
- Press and hold the side TALK button on the microphone to speak.
- Slide the LOCK switch upward for continuous broadcasting without holding the TALK button.
- Adjust the microphone volume using the volume control located on the opposite side of the microphone.

For Best Performance

Use the megaphone in open or outdoor areas for maximum sound projection and clarity.

CLEANING, MAINTENANCE, AND STORAGE

Before cleaning, turn the unit OFF. Wipe the exterior with a soft, dry cloth. Do not use water, solvents, or abrasive cleaners.

To maintain optimal performance, recharge the battery regularly and inspect the charging cable and charging port for damage before use. Do not attempt to disassemble the unit.

When not in use, store the megaphone in a cool, dry place away from direct sunlight and excessive heat. If using C batteries, remove them before long-term storage to help prevent battery leakage.

Register Product

Thank you for choosing SereneLife. By registering your product, you ensure that you receive the full benefits of our exclusive warranty and personalized customer support. Complete the form to access expert support and to keep your SereneLife purchase in perfect condition.

Start Here

Serenelifehome.com/pages/register