





H07

Ultra-long range
Air conduction wireless earphones

H07 Instructions



Air conduction wireless earphones

Compatible with Bluetooth enabled electronic products such as iOS and Android smartphones/tablets

First Pairing Of Earphones


1. Take the earphones out of the packaging box and wear them properly
2. Press and hold the Volume key "+" for 2 seconds until you hear the sound "Power On"
3. Turn on the Bluetooth function of your phone, search for device H07, click and complete pairing
4. Once you've connected the device, it will automatically connect when you turn the earphone on in future use, no need to pair them again.

Note: If necessary, please turn off the headphones and repeat the above steps to reconnect


Product Charging Precautions

1. Use the original magnetic suction dedicated charging cable to connect the 5V-1A charger to charge the headphones.
2. If there is no mobile phone charger with corresponding charger parameters, other Dc5V charging adaptor can also be used to charge the product.
3. Note: the power of the mobile phone charging should be less than 24W (such as 9V --2A power 18W), exceeding this power can easily damage the battery. Do not use wired charging such as car charging, seat charging, USB wall charging, USB plug in, fast charging power bank, etc, as the output power is high and unstable, which is prone to abnormal power consumption (shortened battery life), and even unstable signals.
4. If the magnetic suction charging contact is dirty, please wipe it clean and dry before charging
5. The magnetic suction charging wire has a demagnetization design inside to prevent the positive and negative poles from being inserted backwards. It should be pulled in smoothly and not forcibly charged in the opposite direction. Operate as shown in the following figure.

Correct illustration



Error demonstration



Advantages

IPX5 waterproof, ENC Call noise reduction, Extra Long Range Diamond cutting technology, LED digital display, Low game latency, Skin friendly soft rubber memory head bow which does not deform

Function Explanation

ENC call noise reduction: when answering a call, this function will automatically turn on without manual operation;

Game low latency mode: Users can manually switch from music mode to game mode while playing games, improving the synchronization of sound and picture, this mode can greatly accelerate the transmission of Bluetooth data.

One drag two function: Earphones can support connecting two phones at the same time.

Voice Assistant: When connected and working, long press key "+" for 2 seconds, release the key when you hearing "beep".

Product Specifications

Model: H07

Bluetooth Version: 5.4

Power input: DC 5V

Charging interface: Magnetic contact charging

Battery capacity: 100mAh

Charging time: about 1 hour

Supporting agreement: HSP/HFP/A2DP/AVRCP

Play time: 15 hours (volume determines battery life)

Packing List

1. Air conduction wireless earphones
2. Dedicated magnetic suction charging wire
3. User manual

Precautions

1. If not necessary, please do not cover the earphones with your hands to prevent human obstruction from seriously affecting the transmission of wireless signals.
2. When wearing and using, there must be no strong signal interference obstacles between the phone and the earphones, and it is necessary to ensure the distance between the two to avoid affecting the signal transmission between the phone and the earphones.
3. During daily use, if there is an occasional disconnection issue, it is a normal phenomenon as it belongs to wireless signal transmission, just like WiFi networks, occasional instability is a normal phenomenon, and the signal transmission may be interfered with at this time, Please wait for a moment or change the position to solve it.

After-sale service

The warranty period is 12 months. During the warranty, if any malfunction is caused by the quality of the product itself, please contact us for help.

Non Warranty Regulations

1. Nomal wear and dirt caused by daily use, such as scratches, damage caused by contact with chemical reagents,sharp objects, etc
2. Damage caused by self disassembly;
3. Mechanical damage such as malfunctions caused by water ingress, falling, or squeezing.
4. Failure or damage caused by force majeure;
- 5.The warranty period has expired:
6. The situation does not comply with the performance faults listed in the "Earphone Performance Fault Table": Due to other abnormal use, this product and accessories have performance faults listed in the "Earphone Performance Fault Table".

Earphone performance fault table

1. Earphones cannot hear sound
2. During a call, the other party cannot hear sound
3. Unable to charge earphones
4. Earphones cannot be turned on and used

Function Explanation

1. Please read this user manual carefully and keep it properly before using the product.
2. Forfirst use, please fully charge this product first, If the product needs to be unused for more than one month, please fully charge it before storing it properly. During this period, it is recommended to fully charge it every month, which can greatly extend the service life of the product. Otherwise, the batteries inside the product will continue to self discharge due to their own characteristics. Excessive discharge will cause complete damage to the product, making it unusable and not covered by the warranty.
3. You must choose a charger produced by a legitimate manufacturer and certified by the National CCC to charge the product.
4. If the phone is unable to search for earphones, please confirm whether the earphones are in the state of waiting for pairing on. If the earphones are not successfully paired or connected for a long time, the earphone pairing function will be turned of (turned off), and the earphones need to be restarted and in the pairing state, if there is an error in the phone program, please restart the phone. if there is an error in the earphone program, please restart the earphones.

Warning

1. Do not remove or repair or modify headphones for any reason, as this may cause a fire, electronic breakdown, or even complete damage to the product. This behavior is not related to our company and the consequences will be borne by the buyer.
2. Do not place the device in an environment with a temperature below 0 ° C or above 45 °C.
3. Do not use this device in thunderstorm weather, as thunderstorms may cause the device to malfunction.
4. Do not use oil or other volatile chemical liquids to wipe the surface of this product, but alcohol can be used for daily cleaning and maintenance of the product.