


KOUO S1

Smart Wireless Stereo Bluetooth Headphones



User Manual

Please read before use

Thank you for choosing our smart product.
To fully understand the device's features, we recommend that you read this manual carefully. This smartwatch offers a range of new practical features and services designed to enhance your user experience. Please note: The smart earbuds primarily connect to your device via Bluetooth.
We reserve the right to update the contents of this manual at any time without prior notice. We will not provide free warranty service for damage resulting from failure to follow the instructions provided. We remind you that if the headphones are damaged due to improper use, we will not provide free warranty service.

Basic Specifications

Name: Bluetooth Wireless Headphones
Model: KOUO S1

Headphone Case Specifications			
chip	AB	Touch	COF
Memory	16MB	Hall	Support
BT	BT5.4	button	Support
Screen size	1.83	Battery	40mAh+400mAh
Resolution	240*284	Charging Methods	TYPE-C


Headphone Specifications			
chip	AB	Noise reduction	Support
BT	BT5.4	In-ear testing	Not supported

Product Overview



App Connection Guide

Scan the QR code below or search for it in the app store to download and install the "zwsivb" app, then register and log in.



Headphone User Manual



Automatic startup	Power on	The earbuds turn on automatically when removed from the charging case
	Pairing	1. Place the earbuds in the charging case and turn on the screen. After about 15 seconds, the screen will turn on and the earbuds will pair automatically. 2. Place the earbuds in the charging case, turn on the screen, and press and hold the power button on the case for about 3 seconds to pair manually.
	Return to Pair	Remove the phone that was previously connected and take it out of the charging case. It will automatically reconnect to the last phone it was connected to.
Automatic shutdown	Shut down	If the headphones are not connected to a phone for 3 minutes, they will automatically turn off.
	Automatically reconnect on startup	After turning on the device, pair the earbuds first, then reconnect to your phone. (This will only work if the device has been connected to your phone before.)
	Disconnect	The headphones are connected to the phone; the phone's Bluetooth is turned off, or the headphones are out of range of the phone.
MFB Multifunction button	Shut down	Place it in the charging case; closing the lid will automatically turn it off.
	Play	While in standby mode, press the left or right earbud once. Launch the music player to start playing music.
	Pause	While music is playing, press the left or right earbud once to pause the music.
	Previous Track	While music is playing, double-tap the left earbud to skip to the previous track.
	Next Song	While music is playing, double-tap the right earbud to skip to the next track.
	Turn down the volume	While music is playing, tap the left earbud three times to lower the volume.
	Turn up the volume	While music is playing, tap the right earbud three times to increase the volume.
	Voice Assistant	While in standby or music mode, press and hold the left or right earbud for 2 seconds to switch voice assistants.

	Answer	When a call comes in, click the left or right ear to answer it.
	Block calls	When a call comes in, double-tap the left or right ear to reject it.
	Hang up	During a call, double-tap the left or right earbud to end the call.
	Restore Factory Settings	Remove the headphones from your phone's paired devices.
	Charging	Once the earbuds are placed in the charging case, the case's screen turns off and the earbuds enter charging mode.


Note: The MFB button can be configured in the earbud case under Menu > Button Settings or on the app's home screen under Button Settings.

Headphone Case Features


1. First-time startup
Press and hold the Power button for 3 seconds to turn on the device, select a language, then scan the QR code or search for it in the app store to download and install the "zwsivb" app to connect.

























2. Dial Settings
Press and hold the watch face for 3 seconds to switch to more watch faces.



3. Phone
Includes call history, contacts, dial pad, and SOS.



4. Headphone Button Settings
(1) Normal: Supports synchronized or independent operation for the left and right ears. Available gestures include single tap, double tap, and long press. Configurable functions include voice assistant, previous track, next track, volume up, volume down, pause/play, and low-latency mode.
(2) Incoming Call: Call Control: Includes single tap, double tap, and long press. Available functions include hang up and answer. (3) During Call: Control methods include single tap, double tap, and long press. Available functions include hang up.



FCC Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

RF Exposure Information

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.