


We are a brand specializing in the development of hairdressing tools. We have 15 years of experience in the industry in designing and manufacturing hair dryers, straighteners, curling irons and other products. For after-sales problems, please contact our official website or FB, we will provide excellent after-sales service. Thank you for choosing AINA!

www.ainahair.com

Made in China



1

16

3

14

5

12

7

10

Scan the FB QR code,contact us. Get 1 year warranty & a free hair dryer holder



Free gift-Hair Dryer Holder

2

15

4

13

6

11

8

9

Warnungen

Um Stromschlag, Feuer und andere Verletzungen durch unsachgemäßen Gebrauch zu vermeiden, lesen Sie bitte die Gebrauchsanweisung vor dem Gebrauch sorgfältig durch und beachten Sie sie an einem sicheren Ort auf. Bitte lesen Sie die Gebrauchsanweisung vor dem Gebrauch sorgfältig durch und bewahren Sie sie für spätere Nachschlagzwecke auf.

-Dieses Produkt sollte nicht von körperlich, sinnlich oder geistig behinderten Personen oder Personen ohne entsprechende Erfahrung und Kenntnisse (insbesondere Kindern) verwendet werden, es sei denn, sie werden von einer Aufsichtsperson beaufsichtigt oder angeleitet, um die sichere Verwendung des Produkts zu gewährleisten.

-Verhindern Sie, dass Kinder das Produkt anfassen oder es als Spielzeug benutzen. Besondere Vorsicht ist geboten, wenn das Produkt in der Nähe von Kindern verwendet wird. Kinder dürfen das Gerät nicht ohne Aufsichtspersonen reinigen oder warten.

-Wenn das Netzkabel beschädigt ist, muss es von einem Fachmann des Herstellers, seines Kundendienstes oder ähnlichem ausgetauscht werden, um Gefahren zu vermeiden.

-Tauchen Sie das Gehäuse des Haartrockners, das elektrische Teile enthält, nicht in Wasser oder andere Flüssigkeiten ein, um es zu reinigen, ziehen Sie sofort den Netzstecker, wenn der Haartrockner ins Wasser fällt, und vermeiden Sie ihn nicht weiter, auch wenn er getrocknet ist.

-Wenn der Haartrockner im Badezimmer verwendet wird, ziehen Sie nach dem Gebrauch den Netzstecker, da die Nähe von Wasser eine Gefahr darstellt, auch wenn der Schalter des Haartrockners ausgeschaltet ist.

-Das Gerät ist mit einer nicht selbst rückstellenden thermischen Sicherheitsabschaltung ausgestattet, um eine Überhitzung zu verhindern. Sollte sich das Gerät aufgrund von Überhitzung abschalten, ziehen Sie den Stecker aus der Steckdose und lassen Sie es weiterlaufen. Wenn sich das Gerät aufgrund von Überhitzung ausschaltet, ziehen Sie den Netzstecker aus der Steckdose und lassen Sie es abkühlen.

Product Features

110.000 U/min Hochgeschwindigkeitsmotor, keine hohe Temperatur erforderlich und schnelles Haartrocknen
Ausgestattet mit AINA büsenlosem Hochgeschwindigkeitsmotor der zweiten Generation, 110.000 U/min, 60 m/s Windgeschwindigkeit. Starker Luftstrom, keine Notwendigkeit für hohe Temperaturen, schnelles Trocknen der Haare.

57°C Intelligente konstante Temperatur für die Haarpflege
100mal pro Sekunde Temperaturerfassung, Echtzeitanpassung, um sicherzustellen, dass die Luftaustrittstemperatur konstant 57°C beträgt.


zehn Millionen negative Ionen, weiches Haar
Eingebauter Emittor für negative Ionen, durch den Hochgeschwindigkeits-Luftstrom werden zehn Millionen negative Ionen ausgestoßen, die das Haar neutralisieren.

Heiße und kalte Luftzirkulation
Abwechselnd warme und kalte Winde reduzieren den Hitzezustand, vermeiden Überhitzungsschäden, trocknen schnell, ohne zu schütten, und helfen, die Schuppen zu reduzieren.
Lässt Schuppen schrumpfen und heilt das Haar auf.

Geräuschrückführendes Design
60-fache Optimierung des Luftflusses und des elektromagnetischen Designs 0.3mg Luftauftrieb dynamisches Gleichgewicht

-Das Gerät ist mit einer nicht selbst rückstellenden thermischen Sicherheitsabschaltung ausgestattet, um eine Überhitzung zu verhindern. Sollte sich das Gerät aufgrund von Überhitzung abschalten, ziehen Sie den Stecker aus der Steckdose und lassen Sie es weiterlaufen. Wenn sich das Gerät aufgrund von Überhitzung ausschaltet, ziehen Sie den Netzstecker aus der Steckdose und lassen Sie es abkühlen.

Produkt



- 1. Umschlag Rückseite
- 2. Netzschalter
- 3. Modus-Umschalttaste
- 4. This indicator light is blue for natural air mode
- 5. 57°C This indicator light is yellow for 135°F thermostat mode
- 6. This indicator light is not for hot air mode
- 7. This indicator light is green for hot/cold cycle mode
- 8. Luftauslass
- 9. Handgriff

Dieses Symbol auf dem Körper bedeutet, dass es nicht in der Badewanne oder Dusche verwendet werden darf.

About Us

In order to avoid electric shock, fire and other accidental injuries caused by improper use, please read the instructions carefully before use. Accidental injury, please read the instructions carefully before use and keep it in a safe place for future reference. Please read the instruction manual carefully before use and keep it in a safe place for future reference.

-This product should not be used by physically, sexually or mentally handicapped persons or persons without relevant experience and knowledge (including children) unless supervised or instructed by a guardian to ensure the safe use of the product.

-Prohibit children from handling the product or using it as a toy. Close attention is required when using the product in the vicinity of children. Children are prohibited from cleaning or maintaining the product without a guardian.

-If the power cord is damaged, it must be replaced by a professional from the manufacturer, its service department or similar in order to avoid danger.

-Do not immerse the body of the hair dryer containing electrical parts in water or other liquids to clean it, unplug the hair dryer immediately when it falls into water, and do not continue to use it even after it has dried.

-When the hair dryer is used in the bathroom, unplug it after use, as proximity to water remains a hazard even after the hair dryer switch is disconnected.

-The product is fitted with a non-self-resetting thermal safety cut-out to prevent overheating. If the product cuts off due to overheating, remove the plug from the mains socket and allow it to run. If the product cuts out due to overheating, unplug it from the mains socket and allow it to cool down.

Note: To avoid danger from false resetting of the thermal protector, the appliance must not be powered from an external switching device, e.g. a switching device on the outside of the appliance. The appliance must not be supplied with power from an external switching device, e.g. a timer or a device connected to the mains. Circuits that are switched on and off at regular intervals by general-purpose components.

After-sales Service and Support

Warranty Policy

Within 30 days from the next day after your signature, this product appears "AINA high-speed hair dryer performance failure table" listed in the performance failure of the situation, as determined by the AINA after-sales service center testing, can be free of charge to enjoy the replace service.

Within 90 days from the next day after you sign for the product, the product appears "AINA high-speed hair dryer performance failure table" listed performance failure, by the AINA after-sales service center testing to determine, can enjoy free exchange services.

Within 12 months from the next day after you sign for the product, the product appears "AINA high-speed hair dryer performance failure table" listed in the performance failure of the product, as determined by the AINA after-sales service center testing, can be free to enjoy the repair service.

Non-warranty Regulations

Unauthorized maintenance, misuse, collision, neglect, abuse, fluid ingress, accident, alterations, incorrect use of non-product accessories, or removal or alteration of the labeling, anti-counterfeiting mark.

It has exceeded the validity period of the three packages.

Damage caused by force majeure.

Failure to comply with the "AINA high-speed hair dryer performance fault table" listed performance Failure of the situation.

The product and its accessories have suffered a failure of performance as listed in the AINA High Speed Hair Dryer Performance Failure Chart due to man-made causes. Hair dryer performance failure table" listed in the performance failure.

Product Features

110,000rpm high speed motor, no need for high temperature and fast hair drying

Equipped with AINA second-generation high-speed brushless motor, 110,000 rpm, 60m/s wind speed
Strong airflow, no need for high temperature, fast dry hair

57°C Intelligent constant temperature for hair care

100 times per second temperature detection, real-time adjustments to ensure that the air outlet temperature is a constant 57°C

Ten million negative ions, soft hair

Built-in negative ion emitter, through the high-speed airflow jet out of the ten million negative ions, neutralize the hair
The positive charge on the surface of hair is neutralized by the high-speed airflow, which softens the hair without frizz


Hot and cold air circulation

Alternating hot and cold winds reduce heat buildup, avoid overheating damage, dry quickly without sweating, and help shrink the scales
Shrinks scales and brightens hair

Noise Reduction Design

60 times impeller and electro magnetic design optimization
0.3mg impeller dynamic balance

Product




This symbol on the body means "not to be used in the bath or shower".

List of Accessories

Product	AINA High Speed Hair Dryer
Voltage	240V
Frequency	50Hz
Power	1600W
Product Size	240x84x67mm
Model	2000WE
Product Weight	368g(don't include cord&472g(include cord)


Cleaning and Maintenance



Gear Function


Switch/Wind speed level

Before connecting the power plug, make sure the on/off button is in the off position. Push up and down to quickly switch between two wind speeds.



Temperature Gear

Short press the cycle switch "natural air, warm air, hot air, hot & cold cycle alternating wind" 4 models temperature




Nozzle Function

Equipped with easy loading and unloading nozzle with magnetic suction, align the bottom of the nozzle with the air outlet, it will be automatically attached. The nozzle can be rotated 360° for easy use. The nozzle can be easily removed by holding the nozzle and


Smooth Air Nozzle

Produces a wide airflow with soft and gentle airflow for quick drying and smoothing.



Air Diffuser(Not included, optional)


The high volume of air is used to create a three-dimensional, voluminous hairstyle.




Common Troubleshooting

Common Failure	Possible Reasons	Solution
Boil up but not working	Damaged circuit boards	Repair at the factory
No power on	No power on	Check whether the power plug is plugged in or whether there is a loose connection that there is no abnormality. Please the product after it is fully cooled. If the fault is not eliminated, return the product to the factory for repair.
White light flashing alarm	Abnormal power cord	
Yellow light flashing alarm	Outlet or Heat Abnormal	Check whether the outlet has no foreign matter, after confirming that there is no abnormality. Please the product after it is fully cooled. If the fault is not eliminated, return the product to the factory for repair.
Red light blinking alarm		
Internal coil reddening	Abnormal heating wire	
Indicator light does not come on		
Abnormal light effect display	Damaged keypad	
Buttons not working		Repair at the factory
Power Cord / Power Supply	ALCI plug damaged	
Abnormal overheating of the plug		
Smells burnt in use	Damage to internal parts	

Verwenden Sie zur Reinigung des Edelstahlfilters kein Wasser, da dies zu Fehlfunktionen führen kann. Verwenden Sie ein trockenes, fusselfreies Tuch, eine Bürste mit weichen Borsten, eine Zahnbürste oder ein anderes Werkzeug, um Anhäufungen am Lufteinsaugfilter zu entfernen.



Installieren Sie nach der Reinigung des Rückluftfilters.



Allgemeine Fehlersuche

Gemeinsames Scheitern	Mögliche Gründe	Lösung
Hochfahren, aber nicht funktionieren	Beschädigte Leiterplatten	Reparatur im Werk
Weißes Blinklicht Alarm	Kein Strom eingeschaltet	Prüfen Sie, ob der Netzstecker an der Steckdose eingesteckt ist oder ob er fest ist. Prüfen Sie, ob es keine Anomalien gibt. Prüfen Sie, ob die Sicherung der Sicherung nicht überschritten ist. Wenn der Fehler nicht beseitigt werden kann, wenden Sie sich an den Kundendienst.
Gelbes Blinklicht Alarm	Ablass oder Einlass Anomalie	Prüfen Sie, ob der Luftstrom richtig ist. Wenn der Luftstrom nicht richtig ist, wenden Sie sich an den Kundendienst.
Rotes Licht Blink Alarm	Abnormaler Heizdraht	Prüfen Sie, ob der Heizdraht richtig ist. Wenn der Heizdraht nicht richtig ist, wenden Sie sich an den Kundendienst.
Interne Röhre der Spule	Abnormaler Heizdraht	Prüfen Sie, ob der Heizdraht richtig ist. Wenn der Heizdraht nicht richtig ist, wenden Sie sich an den Kundendienst.
Anzeigelampe leuchtet nicht auf	Abnormaler Lichtflutalarm	Reparatur im Werk
Abnormaler Lichtflutalarm	Beschädigtes Tastenfeld	
Schaltflächen funktionieren nicht		
Ungewöhnliche Überhitzung des Steckers	ALCI-Stecker beschädigt	
Richt bei Gebrauch verbrannt	Beschädigung von Innenteilen	

Produkt-Garantiekarte

Name	
Adresse	
Rufnummer	
Modell	
Bestellnummer	
Zeit bestellen	

Aufzeichnungen zur Wartung

Fehlerbeschreibung und Ersatzteile	Reparaturdatum