



INSTRUCTION MANUAL



VEGETABLE GRATER - A911

Please read this manual carefully before using the product and keep it properly. This product is only used in family or similar places.

susteas.shop@gmail.com

ASSEMBLY

Please check the spare parts before use.



1. Place the product on a flat surface and turn the button clockwise to lock the suction base.



2. Press and hold the round button, align it with the base slot to install the transparent tube.



3. Place the blade barrel into the transparent tube and push it to the bottom.



4. Hold the silver button on the handle against the blade barrel to secure the blade.



5. Put in the food pusher, the installation completed.



6. As shown in the picture, the product assembly is complete and it is ready for food processing.

ASSEMBLY OF BLADES



1. Press and hold the silver button on the handle, then remove the blade barrel.



2. Secure the round blade rack, pull outward on both sides, and remove the two blades.



3. Select the required blade and clip the bottom of blade into the round blade rack.



4. Push the upper side inward, and you will hear a click sound, indicating that the blade has been successfully installed.

Notices:

1. The blades are very sharp. Please exercise caution when using or cleaning them.
2. Keep the product out of reach of children.
3. Keep the product away from fire.
4. Be careful when loading and unloading the blades.
5. Remove the product packaging and clean the product before the first use.
6. When attaching the base, keep it and the tabletop clean and smooth.
7. All parts must be hand washed. Do not use in dishwasher.



Do not exceed 158°F/70°C for high-temperature disinfection, or the product may be damaged.

SELECT THE BLADES

Wavy Slicing Blade



POTATO



CARROT



SWEET POTATO

Slicing Blade



CUCUMBER



RADISH



CARROT


Shredding Blade



PEANUT



CHEESES



CHOCOLATE

SELECT THE BLADES

Fine Julienne Blade



ONION



POTATO



GARLIC

Coarse Julienne Blade



CUCUMBER



CARROT



ZUCCHINI

Ice Crusher Blade



SMOOTHIE

MATERIAL DETAILS

Component name	Material
Body	ABS+S/S+PP+PET
Blades	SUS304

12-MONTH SERVICE WARRANTY

Please ensure that you keep your purchase order number information, as the SUSTEAS team provides a one-year after-sales warranty based on your order details. For non-human-induced product damage, we offer a no-questions-asked return and refund service.

Thank you for your support of the SUSTEAS brand.



Amazon Official Flagship Store

Ecommerce Website Customer Service Email:
susteas.shop@gmail.com

<https://susteas.com/>