

UGREEN

AC1300 High-Gain Dual-Band Wireless Adapter


Model: CM493 | P/N: 50341

User Manual | Das Benutzerhandbuch | Manuel de l'Utilisateur
Manual de Usuario | Manuale dell'Utente | ユーザーマニュアル
用户手册 | دليل المستخدم

Product Overview

DE: Produktübersicht | FR: Détail du Produit | ES: Detalles Del Producto

IT: Panoramica del Prodotto | JP: 商品紹介 | CN: 产品展示 | AR: نظرة عامة على المنتج




Package Contents

DE: Packungsinhalt | FR: Contenu de l'Emballage | ES: Contenidos del Paquete

IT: Contenuto del Pacchetto | JP: パッケージ内容 | CN: 包装清单 |


AR: محتويات الحزمة



1x AC1300 High-Gain Dual-Band
Wireless Adapter



1 x CD Drive




1x User Manual


How to Use (Take Windows 10 as an Example)

Step 1. Driver Installation

1. Plug the device into the USB port of your PC.



2. Insert CD into the CD drive of your PC.




Note:

If the CD-ROM is unavailable in your computer, you can also install or update the driver from:


<https://www.mediafire.com/file/225dxupjysojb0v/RTL8822BU.zip/file>

3. Double click Setup.exe and run it, then follow up the steps to finish the installation.



Tip:

If the popup window doesn't show up, please select "This PC" and double click "Ugreen Wireless" icon.




Note:

"This PC" may have different names on different Windows systems: Windows 8.1/10 "This PC", Windows XP "My Computer", Windows Vista to Windows 8 "Computer".

Step 2. Connect Your Wi-Fi

1. Click on  at the lower right corner of your PC device.
2. Select your WiFi name and enter password to proceed.
3. Once you have finished all steps, you'll be able to use the wireless network.



Specifications

DE: Spezifikationen | FR: Spécifications | ES: Especificaciones | IT: Specifiche
JP: 商品仕様 | CN: 产品参数 | AR: مواصفات

Hardware	Port	1 × USB 3.0
	Antenna	2 × External high-gain antenna
Wireless	Transfer Rate	400Mbps Max (2.4GHz) / 867Mbps Max (5GHz)
	Wireless Standard	IEEE 802.11b/g/n (2.4GHz) / IEEE 802.11a/n/ac (5GHz)
Software	Operating Mode	Adapter mode, AP mode
	Compatible Systems	Windows/ macOS/ Linux

Notes

DE: Hinweise | FR: Notes | ES: Notas | IT: Note | JP: ご注意 |
CN: 注意事项 | AR: ملاحظات

EN

- Do not leave the product in the moist environment.
- Do not forcibly plug or unplug the product in case of connector damage.
- Keep out of reach of children.

DE

- Lassen Sie das Produkt nicht in der feuchten Umgebung.
- Bitte ziehen Sie den Stecker nicht gewaltsam ein oder aus, da dies zu Schäden an der Steckdose führen kann.
- Bewahren Sie dieses Produkt außerhalb der Reichweite von Kindern auf.

FR

- Ne pas laisser le produit dans un environnement humide.
- Ne pas brancher ou débrancher le produit de force pour éviter d'endommager le connecteur.
- Veuillez garder le produit hors de portée des enfants.

ES

- No use este producto en un ambiente húmedo.
- No enchufe ni desenchufe el producto con fuerza para evitar daños.
- Mantenga este producto fuera del alcance de los niños.

IT

- Non lasciare il prodotto in un ambiente umido.
- Non inserire o scollegare forzatamente il prodotto in caso di danneggiamento del connettore.
- Tenere fuori dalla portata dei bambini.

JP

- 製品を多湿の環境に放置しないでください。
- 無理に抜き差ししないでください。コネクタが破損する原因となります。
- 小児の手の届かない場所に保管してください。

CN

- 请保持设备干燥。请勿在潮湿的环境中使用。
- 请勿暴力插拔，以免导致插口损坏。
- 请将本产品放置在儿童接触不到的地方。

AR

- لا تترك المنتج في بيئة رطبة .
- لا تقم بتوصيل المنتج أو فصله بالقوة في حالة تلف الموصل .
- يحفظ بعيدا عن متناول الأطفال .