

OneMira C1

Button & Port

1

Button

- Press and hold for 3 seconds to enter Bluetooth pairing mode
- Press again into recording state instantly.
- Press and hold for 10 seconds to restart the device.

2

Microphone

3

USB-C Port

4

LED Indicator

Solid White – Recording is progress or fully charged.

Solid Red – Charging in progress, low battery.

Breathing White – Bluetooth pairing mode is active.

Off – Standby mode.

Quick Start

- 1

Press and hold for 3s to power on, and 8s to power off

Or connect to power to automatically power on
- 2

Install the OneMira Desktop App

- Download and install the OneMira desktop application on your Mac or Windowscomputer: <https://onemira.com/download>
 - Download for Mac
 - Download for Windows
- 3

Activate Your Device

- Launch the OneMira desktop app.
 - Press and hold the Multi-Function Button for 3 seconds until the LED Breathing White, which means Bluetooth pairing mode is active.
 - Follow the instructions in the app to activate your device.
 - If activation fails, please repeat the steps above or contact OneMira Support.



Recording

- Features

- Record from the device, desktop app, or scheduled tasks.
 - Dual omnidirectional microphones with up to 30 ft (10 m) true pickup range.
 - Supports offline recording and automatic synchronization.

Start Recording

Press the Button once.

LED: Solid White

Stop Recording

Press the Button again.

LED: Off

Troubleshooting

Device Not Found	Ensure the device is powered on. Press and hold the Multi-Function Button for 3 seconds until the LED flashes white, then keep the device within 5 m (16 ft) of your computer during pairing.
Bluetooth Permission Denied	Ensure the device is powered on. Press and hold the Multi-Function Button for 3 seconds until the LED flashes white, then keep the device within 5 m (16 ft) of your computer during pairing.
Model Download Failed	Check your internet connection and click Retry Deployment to continue the download.
AI Tool Not Detected	Restart your AI tool and try again. If the issue persists, go to Settings → AI Access → Rescan to verify the settings.
Firmware Updates	Firmware update notifications will appear automatically in the OneMira desktop app when a new version is available.

Safety Information & Privacy

- Safety

- Do not use damaged cords or charging accessories.
 - Do not disassemble, modify, or attempt to repair the device.
 - Keep the device away from excessive heat, liquids, and open flames.
 - Operating temperature: 0°C to 35°C (32°F to 95°F).

Maintenance

Do not clean the device with chemicals or reagents, as they will damage the surface of the device and corrode it.

- Battery Safety & Disposal

- This device contains a built-in rechargeable lithium-ion battery. Do not disassemble, puncture, crush or short circuit the battery.
 - Do not expose the device or battery to open flame or high-temperature environments.

- Charge only with the included USB-C cable and standard power adapters complying with 5V-0.5A.
 - Stop using the device immediately if the battery appears swollen, deformed, or is leaking.
 - If the product is not used for a long time, please charge and discharge the product once every three months to prevent battery damage.
 - Follow local regulations for the disposal and recycling of electronic products and batteries.

Privacy Policy & Protection

We care about your privacy. For more details, please visit <https://onemira.com/policies/privacy-policy> for more information.

Local Processing: Audio is processed locally on your computer. Recording files are stored locally and automatically removed after processing.

Data Storage: All data is only stored on the device or computer if you do not use the cloud services.

Product Disclaimer

Legal Restrictions: Please strictly abide by the relevant laws and do not use this product illegally. This device is intended

for legal audio recording only. You must comply with all applicable local, state and federal privacy and recording laws. The company does not make any commitments or take any responsibility for the consequences of illegal acts or any illegal use of this device.

Data Safety: The company is not responsible for the loss or damage of personal data caused by the mishandling of hardware, software, product maintenance, battery replacement, or other unexpected situations. It does not take liability for other indirect losses caused by this.

Product Settings

The actual settings and usage of this product may be inconsistent with this manual due to the upgrade of the firmware program. Please understand that changes may occur due to the performance and function of this product without prior notice.

Storage Capacity

The system software will occupy a small portion of the storage space. The actual usable capacity will be slightly smaller than the capacity indicated in the specifications.

FCC Compliance, Warranty & Support

FCC Compliance

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference.

(2) This device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.

Limited Warranty

12-Month Worry-Free Warranty

OneMira warrants this product against defects in materials and workmanship for a period of 12 months from the date of purchase. This warranty does not cover damage caused by accident, misuse, liquid exposure, or unauthorized modification.

Warranty Service

For warranty service, please provide a valid device serial number and proof of purchase, and contact dtc@onemira.com.

Legal Rights

This limited warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

Support

OneMira Digital Intelligence Technology (Hongkong) Co., Limited
Room 617A, 6/F, International Trade Centre, 1 Sha Tsui Road, Tsuen Wan, Hong Kong
dtc@onemira.com

Quick Start Guide & Package Contents

OneMira C1 Quick Start Guide

Package Contents

