

智能AI毛绒玩具快速操作指南

Operation Manual

*使用产品之前请认真阅读本快速操作指南

• 情绪识别功能

- 1.通过每一次对话,捕捉孩子的开心、难过、生气等等多维度情绪。
- 2.孩子异常、危险情绪,自动触发正向引导话术,同步推送家长端预警。

• 兴趣发现

- 1.通过每日对话内容分析,自动生成孩子感兴趣图谱,并推荐个性化内容让家长更了解孩子。

• 分龄教育

- 1.3-6岁行为习惯、7-12岁认知发展,针对孩子年龄分阶段成长模型,内容表达方式分层。
- 2.家长定制-手动创建孩子成长任务,在之后沟通中以AI玩具角色进行合适的表达和引导。

• 特色功能

- 1.声音克隆-用户可以录入自己声音,也可录制现有音频,打造专属声音:进入App音色选择页面,选择我的,进行声音克隆。
记忆卡-AI玩具具有长期记忆功能,记得孩子的名字与爱好,记录与孩子长的点点滴滴。

1 下载安装涂鸦手机端APP

请使用手机扫描右方二维码,直接下载涂鸦最新版本APP。



也可以在应用宝、安卓市场、GooglePlay、Apple Store中搜索关键字涂鸦下载。

涂 鸦



1-9

4 设备分享



- 1.点击右上角设置选择右上角“...”



- 2.点击“共享设备”



- 3.点击“添加”输入好友涂鸦账号或者通过下端链接即可分享给好友。



- 4.点击“确认分享”即可分享成功

6-9

2 联网步骤



- 1.点击“一键登录”,或点击右上角即可密码登陆注册即可登陆成功。



- 2.底部开机键开机,需要重置配网则需按压中间圆点键5秒。



- 3.点击APP首页右上角“+”再点击“添加设备”即可。

2-9

5 常见问题

① 问: 无法与手机配对?

答:可能是蓝牙未打开、玩具与手机距离过远、玩具未进入配对模式或已与其他设备连接
请确保手机蓝牙已打开,将玩具与手机保持在10米以内。

② 问: 网络连接失败?

答:产品配网时仅支持手机在2.4G WiFi下配网,无法支持5G WiFi。

③ 问: 语音识别不准确?

答:环境噪音大、说话语速过快或不清晰、玩具麦克风被遮挡、未进行语音训练等,需在相对安静的环境中使用,适当放慢语速。

④ 问: 玩具发热?

答:长时间使用、内部电路故障、散热不良等会引起发热,避免玩具长时间连续使用,让其适当休息;检查玩具是否放置在通风良好的位置。

7-9



- 4.跳转到“添加设备”界面,点击设备,首次配网是直接配网,后续解绑之后配网会有提示音“我已进入配网状态,开始配网吧”



- 5.在此页面稍等片刻,即可进入配网模式。



- 6.选择到自己WiFi,输入密码点击下一步即可。
注:网络一定要是2.4G无线网



- 7.点击完成、连接成功后,蓝灯常亮。听到提示音“我已联网,让我们开始对话吧”后,即可开启对话体验。

3-9

6 安全须知

- 1、儿童使用时须有成年人从旁监督并加以指导,且对使用者的安全能承担责任;
- 2、使用前务必检查外观是否完好,安装是否到位,机器运转是否正常,如有问题,请联系售后;
- 3、切勿碰撞、冲击、挤压或刺穿;
- 4、切勿自行拆解、修理或改装;
- 5、切勿在本产品或配件损坏和断裂时使用;
- 6、请勿连续充电超过4小时;充电亮红灯,充满亮绿灯;充电时须确保有人在场,外出或长时间离开时请勿充电;
- 7、请务必定期检查本产品,如发现充电线异常,请立即停止使用,否则有漏电,短路或引发火灾风险;
- 8、切勿在开机或充电过程中清洁本产品;

8-9

3 模式介绍

休眠/唤醒模式

- 1.开机后30秒未接收到说话声音,设备将进入休眠模式
- 2.设备进入休眠模式后,需按左手[唤醒键]1下进行唤醒,唤醒后可继续正常对话。

聊天模式

开机后自动进入聊天模式,用户可以直接对话问题,有两种对话模式:

1.按键唤醒对话回合制模式

按下对话按键,唤醒设备,进行对话。当设备说完话后,可以继续连续对话;如需打断,再次按左手唤醒键即可打断。

2.语音唤醒对话模式

语音说出唤醒词,唤醒设备,进行对话。当设备说完话后,可继续连续对话;如需打断对话,再次说出唤醒词即可。

4-9

保修卡

产品名称		型号	
购买日期		经销商	
顾客姓名		邮箱	
联系电话		邮编	
故障原因			
故障处理情况			
联系地址			

9-9

Smart AI PLUSH TOY

Qucik Operation Guide

Operation Manual

*Please read this operation manual carefully before using the product

Emotion Recognition

- Capture children's multi-dimensional emotions (e.g., happiness, sadness, anger) through every conversation.

- Automatically activate positive guidance dialogues when abnormal or dangerous emotions are detected, while sending real-time alerts to the parent app.

Interest Discovery

- Analyze daily conversations to generate a child's interest profile and recommend personalized content, empowering parents to better understand their child's preferences.

Age-Specific Education

- Provide stage-based growth models tailored to age groups: behavior habits for ages 3-6 and cognitive development for ages 7-12, with content delivered through layered methods.

- Parent Customization: Let parents manually design developmental tasks, which the AI toy then guides through age-appropriate interactions and expressions.

Special Features

- Voice Cloning: Users can record their own voice or existing audio to create a unique voice. Navigate to the " My Voice " section in the app's sound settings to enable cloning.

Memory Card: The AI toy retains long-term memory of the child's name, hobbies, lestones, preserving every moment of their growth journey.



1 Download and install the Tuya mobile app

Please use your mobile phone to scan the QR code below to directly download the latest version of the Tuya APP




You can also search for Tuya in the App, Android Market, GooglePlay, or Apple Store.



1-9


4 Device sharing



1. Click Settings (bottom-right corner) Select " .. " (top-right)



2. Choose "Share Device"



3. Click "Add" → Enter friend's Tuya account or share via link below



4. Click "Confirm Sharing" and the sharing will be succesful .

6-9

2 Create an account



1.Click "Sign Up", select your region, and enter your email address to complete account registration.



2.Press the bottom button to power on.
To reset the network configuration, press the circular button in the center for 5 seconds.



3.On the app's home page, click the "+" in the top-right corner, then select "Add Device".

2-9

5 FAQ

Q: Unable to pair with phone?

A: Possible reasons:Bluetooth disabled on phone;Distance between toy and phone exceeds 10m not in pairing mode;Already connected to another device
Solution: Enable phone Bluetooth, keep within 10m range.

Q: Network connection failed?

A: Product only supports 2.4GHz Wi-Fi for initial setup.
Note: 5GHz Wi-Fi networks are incompatible.

Q: Inaccurate voice recognition?

A: Potential causes:Background noise interference;Rapid/unclear speech Obstructed microphone;Not get voice training conducted.
Solution: Use in quiet environments, speak clearly at moderate pace, ensure microphone is uncovered.

Q: Device overheating?

A: Common triggers:Prolonged continuous usage;Internal circuit malfunction;Poor ventilation
Prevention: Limit continuous operation, allow periodic rest periods, ensure proper airflow around device.

7-9

3 Mode Introduction

Sleep / Wake-up

After booted, the device enters sleep mode if no speech is detected for 30 seconds. While in sleep mode, press the left hand [Wake-up Button] once to wake the device and resume normal conversation.

Chat Mode

The device automatically enters to chat mode after booting. Users can directly have conversations and ask questions. There are operations modes available:

1.Press-to-Talk Mode;Press the talk button to wake the device.

After the device finishes speaking, you may continue continuous conversation;
To interrupt, press the left hand button again.

2.Voice Wake-Up Mode

Say the wake-up word to activate the device.

After the device finishes speaking, you can keep continuous conversation remains available.
To interrupt, say the wake-up word again.

4-9

6 Safety Tips

1. Children must be supervised and guided by adults when using the device, and they must be responsible for the safety of the user;

2. Before use, be sure to check whether the appearance is intact, whether the installation is in place, and whether the machine is operating normally. If there is any problem, please contact after-sales service;

3. Do not collide, impact, squeeze or puncture;

4. Do not disassemble, repair or modify by yourself;

5. Do not use this product when it is damaged or broken;

6. Do not charge continuously for more than 4 hours,Red light: Charging

Green light: Fully charged;make sure someone is present when charging, and do not charge when going out or leaving for a long time;

7. Please be sure to check this product regularly. If you find that the charging cable is abnormal, please stop using it immediately, otherwise there is a risk of leakage, short circuit or fire;

8. Do not clean this product during booting or charging;

8-9

Warranty Card

Product name		Model	
Purchase date		Dealer	
Customer name		Mail	
Contact number		Zip Code	
Failure Cause			
Troubleshooting			
Contact Address			

9-9

FCC Caution:

This device complies with part 15 of the FCC Rules.

Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be

Med in portable exposure condition without restriction.