








A	1. 名称:U2 中性英文说明书 2. 材质:128g铜版纸 黑白印刷 风琴折 3. 尺寸:60*80mm 4.印刷字印清晰,不断线、拖笔画不得有重线,杂点等缺陷。 5. 尺寸公差±0.2mm	REVISION		ISSUE	ZONE	DESCRIPTION	DATE	REVISER																																																															
				A			2026/03/05																																																																
B																																																																							
C		 INSTRUCTIONS WIRELESS KINETIC SWITCH Product Description Wireless Kinetic Switch is a push-button self-powered switch with MEA (Micro Energy Acquisition) module inside, which transform mechanical energy into electricity to drive RF chipset work. It is able to control the wireless receiving controller after pairing with it. Product Parameters Work Type: Push-Button Type Number of Button: 2 buttons Power Supply: Self-powered Working Frequency: RF 433MHz Lifetime: >100,000 times Modulation Mode: FSK Dimensions: L107*W36*H17mm Operating Temperature: -20°C~+55°C Control Distance: 60m(outdoor) 25m(indoor) Use Method: Pairing with wireless receiving controller Note: The effective distance data is measured by Lab and it will vary due to the changes of the environment in the actual use. Directional Pairing with Controller In order to meet the user's habits of the switch and to ensure that the multiple controllers can be turned on and off at the same time in the one-to-multiple mode, we design the directional pairing mode on the U2 Wireless Kinetic Switch. The directional pairing method is: press and hold the pairing button on the controller for 3 seconds, and release the pairing button when the light is flashing, and then press one of the U2 Wireless Kinetic Switch 4 times (in 1 seconds). The indicator light goes off, which means pairing is successful. After directional pairing is successful, press the bottom button to turn off the light, and press the top button to turn on the light. Press and hold the bottom button to dim, and press and hold the top button to brighten.  Ordinary Pair with Controller The Wireless Kinetic Switch need to be paired with wireless receiving controller. The ordinary pairing method is: press and hold the pairing button on controller for 3 seconds, release the pairing button when the indicator light flashes, and then press one button of the Wireless Kinetic Switch once. The indicator goes off, which means that the pairing is successful. Then you can control the wireless receiving controller by this button. (More detailed steps, please refer to the receiving controller instruction.) Installation Instructions 																																																																					
D		FCC Warning This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: —Reorient or relocate the receiving antenna. —Increase the separation between the equipment and receiver. —Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. —Consult the dealer or an experienced radio/TV technician for help. Note: The Grantor is not responsible for any changes or modifications not expressly approved by the party responsible for compliance. such modifications could void the user's authority to operate the equipment. The device has been evaluated to meet general RF exposure requirements. To maintain compliance with FCC's RF exposure guidelines, the distance must be at least 20 cm between the radiator and your body, and fully supported by the operating and installation. Product Dimensions  CERTIFICADO INSPECCIONADO																																																																					
E																																																																							
F		<table><tr><td>tem \ Dimension</td><td>0 ~ 10</td><td>0 ~ 50</td><td>50 ~</td><td rowspan="2">广东易百珑智能科技有限公司</td><td>MODEL NO.</td><td>PART NO.</td><td>DWG.DATE</td><td>MATERIAL</td><td>PART NAME</td><td>UNIT</td><td>mm</td></tr><tr><td>center distance (metal)</td><td>±0.05</td><td>±0.10</td><td>±0.15</td><td>U2</td><td>SW1A7440EB010</td><td></td><td></td><td></td><td>SCALE</td><td></td></tr><tr><td>center distance(resin)</td><td>±0.08</td><td>±0.10</td><td>±0.15</td><td rowspan="3"></td><td>DESIGN</td><td>CHECKED</td><td>SAFETY</td><td>APPROVED</td><td>REV.DATE</td><td>FILE NO.</td><td>DRAWING NO.</td><td>SIZE</td><td></td></tr><tr><td>general dimensions(metal)</td><td>±0.05</td><td>0.10</td><td>±0.15</td><td rowspan="2">陈萍</td><td></td><td></td><td></td><td></td><td></td><td>20260112</td><td>REV.</td><td></td></tr><tr><td>general dimensions(resin)</td><td>±0.08</td><td>±0.10</td><td>±0.15</td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td>+0-0.2mm</td></tr></table>								tem \ Dimension	0 ~ 10	0 ~ 50	50 ~	广东易百珑智能科技有限公司	MODEL NO.	PART NO.	DWG.DATE	MATERIAL	PART NAME	UNIT	mm	center distance (metal)	±0.05	±0.10	±0.15	U2	SW1A7440EB010				SCALE		center distance(resin)	±0.08	±0.10	±0.15		DESIGN	CHECKED	SAFETY	APPROVED	REV.DATE	FILE NO.	DRAWING NO.	SIZE		general dimensions(metal)	±0.05	0.10	±0.15	陈萍						20260112	REV.		general dimensions(resin)	±0.08	±0.10	±0.15								+0-0.2mm
tem \ Dimension	0 ~ 10	0 ~ 50	50 ~	广东易百珑智能科技有限公司	MODEL NO.	PART NO.	DWG.DATE	MATERIAL	PART NAME	UNIT	mm																																																												
center distance (metal)	±0.05	±0.10	±0.15		U2	SW1A7440EB010				SCALE																																																													
center distance(resin)	±0.08	±0.10	±0.15		DESIGN	CHECKED	SAFETY	APPROVED	REV.DATE	FILE NO.	DRAWING NO.	SIZE																																																											
general dimensions(metal)	±0.05	0.10	±0.15		陈萍						20260112	REV.																																																											
general dimensions(resin)	±0.08	±0.10	±0.15										+0-0.2mm																																																										
	1	2	3	4	5	6	7	8	9																																																														